

产品规格 • 蓝牙版本： Bluetooth V5.3 • 电池规格： 耳机3.7V 35mAh; 充电仓3.7V 250mAh • 支持模式： HFP/HSP/A2DP/AVRCP • 灵敏度： 105dB ± 3dB S.P.L at 1KHz • 信号距离： 10米（无任何较大障碍物的理想环境中） • 播放时间： 约 3 小时 • 通话时间： 约 3 小时 • 待机时间： 约 80 小时 • 充电时间： 给充电盒充电约1.5小时，充电盒给耳机充电约1小时 • 充电仓给耳机充电次数： 约2.5次 功能操作说明 1、开机 将耳机从充电仓拿出自动开机或长按左右耳机多功能键3秒开机。 2、关机 将耳机放入充电仓自动关机/长按左右耳机多功能键5秒关机。 3、开机回连 当配对成功后，第二次开机时蓝牙耳机优先进入回连状态自动回连已连接过的手机。 4、播放/暂停 在待机状态下，单击左右耳机多功能键均可直接播放音乐，播放时单击左右耳机多功能键均可暂停播放。	5、切换歌曲 播放音乐时三击左右耳机多功能键切换上下曲。 6、音量加减 双击左右耳机多功能键加大减小音量 7、来电接听 手机来电时，单击左右耳机多功能键均可接听电话。 8、来电挂断 手机通话时，单击左右耳机多功能键均可挂断电话。 9、来电拒接 手机来电时，长按左右耳机多功能键2秒均可拒接来电。 10、启动语音助手 长按耳机多功能键1.5秒即可启动Siri或谷歌语音助手进行语音控制手机操作。	配对方式 普通配对方式 1. 从充电仓取出或者同时长按左、右耳机多功能键3秒开机, 自动配对 2.启动手机或者其它设备的蓝牙功能.点击进入配对 3.两只耳机也可单独与手机进行配对使用, 操作方法可按上步骤 2 操作手法进行操作. 充电操作 1. 将Micro USB充电线一头插上充电盒的USB口一头插上充电器即可给充电盒充电，当充电盒电量在对应指示灯的指示范围时,该位置的蓝色指示灯间隔2秒闪一次，直至该指示灯的电量范围充满后则长亮进入下一电量范围的指示灯闪烁，全部充满后所有指示灯长亮。 2. 给耳机充电：将耳机放入充电仓即可自动充电，充电时耳机指示灯为红色，充满电后熄灭；充电仓蓝色指示灯长亮（充电仓满电时，4个电量指示灯全亮，当充电仓电量下降达到相应电量时，对应的指示灯则熄灭），当耳机充满电后充电仓蓝色指示灯全部熄灭。
--	--	--

Product specifications •Bluetooth version: Bluetooth V5.3 •Battery specification: Headset 3.7V/45mAh; Charging box 3.7V/280mAh •Support mode: HFP/HSP/A2DP/AVRCP •Sensitivity: 105dB ± 3dB S.P.L at 1KHz •Transmission distance: 10 meters (in an ideal environment without any major obstacles) •Play time: About 2.5 hours •Call time: About 3 hours •Standby time: About 80 hours •Charging time: Charge the charging compartment for about 1.5 hours, and charge the headset for about 1 hour •Charging box to charge the headset: About 2.5 times Functional operation instructions 1、Boot Take the headset out of the charging compartment and automatically turn it on or press and hold the left and right headset multiunction button for 3 seconds 2、Shut down Put the headset into the charging compartment and turn it off automatically. Press and hold the left and right headset multifunction button for 5 seconds to shut down 3、Boot back: When the pairing is successful, the Bluetooth headset preferentially enters the connected state when the second time is turned on, and automatically connects back to the connected mobile phone 4、Play / Pause In the standby state, click the left and right earphone multi-function keys to	directly play music, and click the left and right earphone multi-function keys during playback to pause the playback. 5、Switch songs When playing music, three-click the left and right earphone multi-function keys to switch between up and down music. 6、Volume addition and subtraction Double-click the left and right earphone multi-function keys to increase or decrease the volume 7、Call answering When the mobile phone calls, click the left and right earphones multi-function button to answer the call 8、Call hang up When the phone is talking, click the left and right earphones multi-function button to hang up the phone 9、Call rejection When the mobile phone calls, long press the left and right headphones multi-function button for 2 seconds to reject the call 10、Start voice assistant Long press the headset multi-function button for 1.5 seconds to start Siri or Google voice assistant for voice control of mobile phone operations.	Pairing method 1. Take it out of the charging compartment or press and hold the left and right earphone multi-function buttons for 3 seconds to turn on the phone, Automatic pairing 2. Start the Bluetooth function of the mobile phone or other device, click to enter the pairing 3. The two earphones can also be paired with the mobile phone separately, and the operation method can be pressedStep 2 Operation method to operate. Charging operation 1. Plug one end of the Micro USB charging cable into the USB port of the charging box and the other end of the charger to charge the charging box. When the power of the charging box is within the indication range of the corresponding indicator light, the blue indicator light at this position will be separated by 2 seconds. Flashes once, until the indicator's power range is fully charged, it will stay on. The indicator light that enters the next power range will blink, and all indicators will stay on when fully charged. 2. Charge the earphones: Put the earphones into the charging compartment to automatically charge. The earphone indicator will be red when charging, and it will go out after fully charged; the blue indicator light is the charging compartment will be on (when the charging compartment is fully charged, 4 battery indicator lights) All lights are on, when the charge level of the charging compartment drops to the corresponding level, the corresponding
---	--	--

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.