


6.0"

4.0"

QUICK START GUIDE

2XL Robot 51330



Congratulations on your purchase of the 2XL Toy Robot! This innovative and interactive Deep Learning AI robot will provide endless fun and companionship for your child. Please read this user manual carefully to ensure proper setup and usage.

Enjoy your journey with 2XL!


SCAN FOR ALL THE LATEST UPDATES AND FEATURES




Quick Start Guide



WHAT'S INCLUDED:

01

2XL TOY ROBOT

02

USB CHARGING CABLE

03

QUICK START GUIDE

Remarks:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm
FCC ID: 2BC3951331

UNBOXING AND POWERING ON

01 CHARGING 2XL


- For charging your 2XL please use the charging cable provided. In the event the cable is lost or defective and needs to be replaced please only charge your 2XL specifically with a USB-A to USB-C connection cable. We also recommend the following adapter for fastest charging of your 2XL: Output: 5W / Power: 5V $\Rightarrow$ 1A or Output: 10W / Power: 5V $\Rightarrow$ 2A only
- Connect the USB charging cable to the robot's charging port and the other end to a USB power source adapter plugged into any outlet.
- While charging, the robot's LED indicator will glow. Once fully charged, the LED indicator will turn off.

02 POWER ON / OFF

- To turn 2XL ON, hold center button for 7 seconds.
- To turn 2XL OFF, hold center button for 3 seconds.

02 START YOUR CONVERSATION

- Simply start talking with your 2XL about anything you want and let the fun begin.



DOWNLOADING THE 2XL APP

01 SCAN THE QR CODE:

- Scan the QR code below or go to the My2XL.com website to find the My2XL app.



02 OPEN THE APP STORE OR GOOGLE PLAY STORE:

03 SEARCH AND DOWNLOAD THE MY2XL APP

- Tap the search tab and type in My2XL AI Robot
- From the search results select the **My2XL AI Robot Companion App**
- Click "Get/Install" and confirm to download the app.



CUSTOMIZING THE 2XL APP

01 CREATE AN ACCOUNT:

- Follow the on-screen instructions in the app.

02 CUSTOMIZE YOUR PREFERENCES:

- Explore the settings and customize the 2XL app according to your preferences. 2XL Customization allows for individual profiles, notification settings, moderation levels, themes, language, three talk modes, security & privacy options. You may also enable a PIN number to limit access to customized settings.

03 SAVE YOUR SETTINGS:

- Save your settings and you are ready to start your journey with 2XL.

04 ADDITIONAL 2XL CREDITS:

- Your 2XL Robot comes preloaded with 65,000 credits for 650+ free interactions. When those run out, choose from a selection of low-cost in-app credit options to continue enjoying your 2XL robot without interruption. Additional credits can be purchased by simply clicking the Credit icon in the upper right hand corner of your app screen.

WIRELESS PAIRING

01 ENABLE WIRELESS SETTINGS ON YOUR PHONE/TABLET

- Using your device, make sure Wireless is "On".

02 PAIR 2XL WITH YOUR PHONE/TABLET

- Turn on 2XL . NOT CONNECTED
- While wireless on your phone/tablet is enabled, open the My2XL app. Your 2XL will automatically connect to your phone through the My 2XL iOS or Android application. If this is your first time connecting, you will receive a request to allow 2XL to use wireless. Click "allow" on each of the screens to complete the connection process.

03 CONFIRM YOUR 2XL IS CONNECTED

- Once you see 2XL's "Start Up" face you and your 2XL are ready to talk, learn and explore the universe.



Important Note
The App must remain open & running on the screen of the device while interacting with 2XL.

USING 2XL SETTING A SECURITY PIN

SETTING A PIN

If you wish to limit access to customized profile settings you may enable a PIN. This will ensure that any customized settings can not be turned off or modified by anyone without PIN access. To enable PIN protection follow the instructions below.

01 ENABLING PIN PROTECTION AND SETTING A PIN NUMBER

- Enabling Pin Protection** - Navigate to Account and click "Pin Protection". Click "Edit PIN". If this is your first time setting the pin, enter and confirm PIN number you'd like to enable. Click "Save PIN". From now on when entering your account settings you will be asked to verify your identity by entering your pin and clicking "unlock". You may return to PIN Protection settings at any time to delete or edit your PIN settings. When you are done modifying PIN settings click to lock button at the top of the app screen to re-lock and exit settings.




Attention: Sensitive Content accessible



CARE & MAINTENANCE

CLEANING

- Wipe 2XL's surface with a soft ,damp cloth to clean it.
- Avoid using harsh chemicals or abrasive materials that could damage the robot's exterior.



BATTERY LIFE

- A full charge provides several hours of playtime. Charge your 2XL when the battery is low to ensure uninterrupted fun.

STORAGE

- Store 2XL in a cool ,dry place when not in use .
- Keep it away from direct sunlight and extreme temperatures.

SAFETY PRECAUTIONS

1. Age Recommendation:

- This robot is suitable for children aged 5+. Adult supervision is recommended.

2. Small Parts:

- The robot contains small parts that could pose a choking hazard for young children. Keep these parts away from infants and toddlers.


3. Volume Control:

- Adjust the robot's volume to a comfortable level

4. Caution:

- Avoid dropping the robot, as it could result in damage.
- Do not disassemble or attempt to repair the robot yourself. Contact customer support for assistance.
- Do not use 2XL in or around water .

This product contains a battery that is non-replaceable.



CONTACT US:

If you have any questions or need assistance, please contact our customer support:
Email: customersupport@Mego2-XL.com

We hope you enjoy many joyful and interactive moments with your 2XL Toy Robot!

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.



51330-US-1

762.0 毫米

101.6 毫米

Front

Back