


LED Pixel Screen Power Bank



User Manual


Full-color LED screen / Customized editing

Product Presentation



1. Please turn on Bluetooth and location services

Download & Install App





Scan the QR code below to download and install app with your mobile phone, or enter Google Play/App Store and search for "iPixel Pro" to download




Scan the QR code and download the APP

2.If you don't have APP Store/Google Play, please click the third one to download from Local Server



3. Connect to Bluetooth devices




Note:

1: When you first open the APP, there is an option to allow permissions. Please select "Allow" for all.



2: Please click "Device Connection" to add the device.

3: If your phone cannot detect the device, please check if the location function is enabled!


4. Creative Graffiti





5.Creative Animation





6.Text



7. Alarm Clock



8.Schedule





Choice/Delete

Add Schedule



Initial Schedule

9.Stopwatch



Reset/Start/End



10.Countdown



Time setting

Reset/Start/End

11.Scoreboard






Reset



Preview Display

Number addition
and subtraction

12.Preset Phrase



13.Mode/Clock





Effect Preview

12/24 HourSystem
/Date Adjustment

Color Disc

Brightness Adjustment


14.Mode/Light/Light Effect



15.Mode / My Materials / Equipment Materials






Material Library



Total Play Time/Delete



Send

16.Cloud Material



Edit/
Download
to MyMaterial
/Download to
Equipment
Material

17.Rhythm





Microphone

Mobile
Microphone



18.Settings



Language

Energy Saving Mode

Device Information

Set Password

Reset Device

Flip Up and Down

Brightness Adjustment

App Version

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Safety Procedures and Instructions:

Before use, please read the following instructions. Incorrect usage may cause overheating, fire, cracking, and damage.

1. Do not store this product in an environment with a temperature above 45 °C. Do not expose it to direct sunlight. Do not immerse this product in fire or place it in any other overheated environment.
2. Do not disassemble this product or attempt any form of repair or modification. Do not attempt to replace any part of this product.
3. Do not drive nails into this product or use a hammer to strike or knock it.
4. Do not immerse this product in water or allow it to get wet when stored.
5. During use, this product will have a certain degree of heating, with a temperature below 45 °C, which does not affect the product's performance. Please use it with confidence.
6. All products have passed strict quality assurance inspections before leaving the factory. If you find that this product is overheating, emitting an abnormal smell, deforming, wearing out, or experiencing other abnormalities, please stop using it immediately and contact the manufacturer or product agent.
7. If the purchaser buys this product for use by minors, before use, the purchaser should provide detailed instructions and warning information to them. If the purchaser fails to fulfill the obligation of providing instructions, the manufacturer shall not be held responsible for any consequences caused by improper or incorrect use by minors (This power bank is not suitable for people with physical, sensory, and mental disabilities (including children) to use. It is not recommended for people lacking relevant experience and knowledge, unless there is a person specifically responsible for their safety supervision or guidance when using this device. Take good care of children to ensure they do not play with it as a toy).
8. This product should be stored in a cool and dry environment.



RoHS




LED像素屏充电宝




使用说明书

全彩LED屏/自定义编辑

产品介绍



1.请打开蓝牙和定位，下载安装App





手机扫描下面二维码进行下载安装
或者进入Google Play/APP store
搜索“iPixel Pro”进行下载




扫码下载APP

2、如果你没有APP Store/Google Play，请点击第三个从本地服务器下载




3.连接蓝牙设备



注:

- 1:第一次打开APP,有是否允许权限选项,请都选择允许
- 2:请点击“设备连接”,添加设备
- 3:若手机无法搜索到设备,请检查是否打开定位!


4.创意涂鸦



5.创意动画



6.文字编辑



删除/保存

输入文本

设置背景、特效

标准色


色盘

调节亮度

调节速度

发送

7. 闹钟功能



设定具体时间

日期设定

添加图案


蜂鸣器开关

蜂鸣器时长

8.日程安排





初始日程安排



选择/删除


添加日程安排

9.秒表



复位/开始/结束


10.倒计时




时间设定

复位/开始/结束



11. 计分板




12.预设短信



13.模式/时钟



14.模式/灯光/灯效




调色盘

添加我的素材

标准色

调节亮度

黄光/正白/暖白



效果预览

重置/
添加到我的素材


标准色/添加/删除

色盘


亮度调节

速度调节

15.模式/我的素材/设备素材






素材库



轮播时间/删除



发送

16.云素材



编辑/下载到
我的素材/下
载到设备素材

17.律动



18.设置



切换语言

节能模式

设备信息

设置密码

重置设备

屏幕画面上下翻转

调节屏幕亮度

App版本号

联邦通信委员会警告

本设备符合美国联邦通信委员会（FCC）第 15 部分规则。使用时须满足以下两个条件：

（1）本设备不得造成有害干扰；（2）本设备必须接受所收到的任何干扰，包括可能导致其无法正常工作的干扰。

注 1：本设备已通过测试，符合美国联邦通信委员会（FCC）第 15 部分关于 B 类数字设备的限制要求。这些限制旨在为住宅安装提供合理的防干扰保护。本设备会生成、使用并可能辐射无线电频率能量，若未按照说明进行安装和使用，可能会对无线电通信造成干扰。但无法保证在特定安装中不会发生干扰。如果本设备确实对无线电或电视接收造成干扰（可通过关闭和开启设备来确定），建议用户尝试通过以下一种或多种措施来解决干扰问题：

- 重新调整或移动接收天线的位置。
- 增大设备与接收器之间的距离。
- 将设备连接到与接收器不同电路的插座上。
- 咨询经销商或有经验的无线电/电视技术人员寻求帮助。

注 2：未经负责合规的一方明确批准，对本装置所做的任何更改或修改都可能导致用户操作设备的权限失效。

该设备已通过评估，符合一般射频辐射暴露要求。该设备可在便携式辐射暴露条件下无限制使用。

安全规程及使用说明:

使用前请阅读以下说明，不正确的使用将导致变热，着火，破裂，损坏。

- 1、请勿将本产品存放于45°C以上高温环境，亦不可以置于太阳下暴晒，请勿将本产品投入火中或置于其他过热环境。
- 2、请勿拆解本产品或尝试对其进行任何形式的维修或改动，勿尝试更换本产品任何部分。
- 3、不能将钉子钉入本产品或用锤子砸或敲打。
- 4、不能将本产品浸于水中或存放时浸湿电源。
- 5、本产品在使用过程中会有适当的发热现象，温度在45°C以下，并不影响产品性能，请放心使用。
- 6、所有产品出厂前均通过了严格的质量保证检验。如您发现本产品过热、出现异味、变形、磨损、破损或出现其它异常情况，请立即停止使用，并联络制造商或产品代理商。
- 7、如购买人购买本产品供未成年人使用，在使用前，购买人应向其提供详细说明及警示信息。如购买人未能履行说明义务，制造商不对未成年人使用不当或误用造成的后果承担任何责任（此移动电源不适合生理，感知和心智能力低下的人（包括小孩）使用，也不建议缺乏相关经验和知识的人士，除非有专门的人负责他们的人生安全的人士监督或指导他们使用此设备。应看管好小孩，以确保他们不当作玩具来玩）
- 8、本产品应储存在阴冷干燥环境中。



RoHS



