



Thank You

for choosing a quality product from 4smarts

1 Safety Instructions

Please read this manual and the safety instructions carefully before using the device for the first time. We accept no liability for damage caused by failure to observe these operating instructions and the safety instructions.

1.1 General safety instructions

- Avoid strong vibrations, shocks or extension, protect the instrument from sun and rain during transport.
- The device should be stored in a clean, cool and dry room, avoid direct sunlight and contact with corrosive substances.
- Do not use the device with damaged cables, damaged or missing parts, or if there is damage or failure of the device.
- The device and accessories contain small parts. Please keep the device and accessories out of the reach of small children. Children may accidentally swallow small parts and cause the device to fail.
- Do not drop the product or subject it to strong impact to avoid damaging it, which may cause the device to fail.

1.2 Precautions for batteries

- Overheating of the battery may cause an explosion.
- If the battery is damaged, it may leak or catch fire. If the battery is damaged, please stop using it immediately and contact the manufacturer for medical treatment.
- If a battery shows discoloration, deformation, abnormal heating or other abnormalities during use, charging or storage, please stop using it.
- Please do not throw the battery into fire or water, and do not throw it in the household waste.

2 Technical Details

Bluetooth version: 5.2

BLE range: approx. 10 meters

Battery type: 3.0V 400mAh Li-MnO2 Ultra Thin Soft Flat Lithium Battery CF104848

Maximum operating time: approx. 2 years

Works with Apple Find My

No additional app required

Acoustic signal to protect against unauthorized tracking of people

Frequency range of wireless connection: 2.4 GHz

Transmission power: 4 dBm

Volume: 60 dB

3 Getting Started

The 4smarts SkyTag Slim is an innovative wallet finder in credit card style to protect you from losing your Wallet or other belongings. For example, if you put the SkyTag in your wallet, you can always see the location of your wallet.

Add SkyTag to Apple Find My:

Update your device to the latest version of iOS or iPadOS.
Turn on the Bluetooth function of your phone and remove the protective film from the SkyTag.
Open the "Find My" app on your phone and tap "Add Item".
Select "Add another item" and search for SkyTag.
Follow the on-screen instructions to add the SkyTag.

Pair with another Apple ID:

Reset the SkyTag from Find My by tapping on the "Items" tab, tapping the name of the SkyTag item, scrolling down to the bottom of the detail card and then tapping "Remove Item".

4 Function Notes

Find items at close range – Play sound function

For the paired SkyTag, within the short range of the owner to play sound to indicate the SkyTag location. If it's hiding nearby, such as under a cupboard or in the next room, you can easily follow the sound to find it.

SkyTag is away from the owner

The owner can see the location of the lost SkyTag on Apple device, navigate by the map to find SkyTag and items.

Lost Mode – Find things easier

SkyTag can be set as "Lost Mode". Open the Find My app, select an added SkyTag, click on the "Lost Mode", follow the instructions of the app, enter phone number, then setting is successful. In Lost Mode you automatically get a notification when it's detected by other devices. When you find the lost item, you can click on "End Lost Mode" to deactivate. You can also extract you by following the learn more instructions in Find My app. People nearby also can identify to the owner, help the owner find lost items.

Find items with help of hundreds of millions of Friends

Find My network will help you find your belongings when they are left behind. SkyTag will send out a secure Bluetooth signal that can be detected by nearby iOS devices in Find My network. These devices send the location of your SkyTag device to Cloud, then you can go to the Find My app and see it on the map. The whole process is anonymous and encrypted to protect your privacy. And it's efficient, so there is no need to worry about the battery life and data usage.

Prevent unwanted tracking

To prevent unwanted tracking, your iOS device will detect a third-party SkyTag that is near you when you are in a crowded place. When you are in a crowded place, you can see the location while it will play an alert sound to warn you. However, you will not receive any notification when a SkyTag is near its owner.

Please Protection:

Only you can see the location of your SkyTag. No location data or location history is physically stored in the SkyTag itself. Communication with the Find My network is encrypted throughout, so only you have access to location data. Neither Apple nor anyone else can know the identity or location of the device involved in finding your SkyTag.

5 Care and Maintenance

Do not use the device with harsh chemicals, cleaning agents or this like for cleaning.
Use a clean, dry cloth for wiping.

6 Warranty

4smarts GmbH assumes no liability or warranty for damages resulting from improper installation, assembly and improper use of the product or failure to comply with the operating instructions and/ or safety instructions.

7 Disposal Notification



Electrical and electronic devices as well as batteries must not be disposed of with household waste. The consumer is legally obliged to return electrical and electronic equipment as well as batteries at the end of their service life to the public collection points set up for this purpose or to the point of sale.

8 Service and Support

In case of defective products or problems during installation, please contact your dealer or the 4smarts product support at: <http://www.4smarts.com/contact>.

Monday - Friday: 9 - 17h

+49(0)821 20708444
Email: customer-service@4smarts.com

9 Attention of Conformity

Hereby, 4smarts GmbH declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity according to the RED directive can be found at www.4smarts.com.

1 Sicherheitshinweise

Bitte lies dies Bedienungsanleitung und die Sicherheitshinweise vor der ersten Inbetriebnahme sorgfältig durch, für Schäden, die durch Nichtbeachtung dieser Anleitung und der Sicherheitshinweise entstehen, übernimmt wir keine Haftung.

1.1 Allgemeine Sicherheitshinweise

- Vermeide starke Vibrationen, Stöße oder Extrusion, schütze das Gerät vor Sonne und Regen während des Transports.
- Das Gerät sollte in einem sauberen, kühlen und trockenen Raum gelagert werden, um einen Beschädigung des Produkts zu vermeiden.
- Lass Kinder oder Haustiere nicht in das Gerät oder das Zubehör fallen, da dies zu Schäden oder einem Ausfall des Geräts führen kann.
- Das Gerät enthält Kleinteile. Bitte bringe das Gerät nicht in die Reichweite von Kleinkindern, Kinder können unbeabsichtigt Kleinteile verschlucken und daran erstickt werden.
- Lass das Produkt nicht fallen und setze es keinen starken Stößen aus, um es nicht zu beschädigen, was zu einem Ausfall des Geräts führen kann.

1.2 Vorsichtsmaßnahmen für Batterien

- Eine Überhitzung der Batterie kann eine Explosion verursachen.
- Falls die Batterie ausfällt, vermeide den Kontakt von Haut und Augen mit der auslaufenden Flüssigkeit. Bei direktem Kontakt spüle bitte sofort mit klarem Wasser und begib dich zur ärztlichen Behandlung in ein Krankenhaus.
- Wenn eine Batterie während des Gebrauchs oder der Aufbewahrung verformt, verformt sie bitte nicht mehr.
- Entsorge die Batterie stets nach den regionalen Entsorgungsvorschriften und wirf sie nicht in den Hausmüll.

2 Technische Daten

Bluetooth-Version: 5.2

BLE Reichweite: ca. 10 Meter

Batterietyp: 3.0V 400mAh Li-MnO₂ Ultra Thin Sort Flat Lithium Batterie CP104848

Maximale Betriebsdauer: ca. 2 Jahre

Kompatibel mit Apple Wo ist?

Keine zusätzliche App erforderlich

Auslastisches Signal zum Schutz vor unerlaubtem Tracking von Personen

Frequenzbereich der kabellosen Verbindung: 2,4 GHz

Übertragungsleistung: < 1 dBm

Laustärke: 80 dB

3 Erste Schritte

Der 4smarts Sky Tag Walker ist ein innovativer Geldtruhe/schlüssel in Kreditkartenformat, der dich vor dem Verlust deiner Geldtruhe oder anderer Gegenstände schützt. Wenn du den Sky Tag Walker in deine Brieftasche steckst, kannst du jederzeit den Standort deiner Brieftasche sehen.

Hinzuordnen des Sky Tag zu Apple Wo ist?

Aktualisiere dein Gerät auf die neueste Version von iOS oder iPadOS.
Öffne die Apple Wo ist? App und tippe auf das -Symbol.
Wähle "Weiteres Objekt hinzufügen" und suche nach dem Sky Tag hinzuzufügen.
Folge den Anweisungen auf dem Bildschirm, um den Sky Tag hinzuzufügen.
Wenn du den Sky Tag mit einer anderen Apple Gerät koppeln möchtest, entferne ihn zuerst aus deiner Wo ist? App. Gehe dazu zur Registerkarte "Elemente", tippe auf den Namen des Sky Tag-Elements, scrolle zum Ende der Detailkarte und wähle "Element entfernen". Anschließend kannst du den Sky Tag mit einer anderen ID koppeln, indem du die oben genannten Anweisungen befolgst.

4 Hinweise zur Bedienung:

Gegenstände im Halbkreislich finden - Tonalarm abspielen:

Wenn der Sky Tag mit deinem Apple-Gerät gekoppelt ist, kannst du in der Wo ist? App den Tonalarm abspielen ->Button erücken oder "Hey Siri, finde meine Brieftasche" sagen, um einen Ton zu hören, der dich zum Standort deines Gegenstands führt. Wenn du dich in der Nähe verabschiedest, 2,8" unter einem Möbelschub oder im nächsten Raum, kannst du dann Ton einfach folgen, um ihn zu finden.

Gegenstände außerhalb der Reichweite des Benutzers:

Der Benutzer kann den Standort des jeweiligen Sky Tags auf seinem Apple-Gerät sehen und die Brieftasche bewegen, um den Sky Tag und die damit verbundenen Gegenstände zu finden.

Vorfürer-Modus - Gegenstände leichter finden:

Du kannst den Sky Tag in den "Vorfürer-Modus" versetzen. Öffne die Wo ist? App, wähle den Gegenstand, den du finden möchtest, tippe auf "Vorfürer-Modus". Der Sky Tag wird dann den Vorgang abzuschließen. Gib deine Telefonnummer an und du erhältst automatisch eine Benachrichtigung, wenn du den Gegenstand mit dem Sky Tag irgendwo liegen gelassen hast. Oder wenn andere Personen deinen Sky Tag finden, können sie dich kontaktieren, indem sie den "Vorfürer-Modus" aktivieren. Wenn du den "Vorfürer-Modus" aktivierst, werden alle mit dir verbundenen Gegenstände wiederzufinden.

Finde Gegenstände mit Hilfe von Hunderten von Millionen von Freunden:

Das Wo ist? Netzwerk unterstützt dich dabei, verlorene Besitztümer wiederzufinden. Der Sky Tag sendet ein solches Bluetooth-Signal aus, das von iOS-Geräten im Wo ist? Netzwerk empfangen werden kann. Du kannst die App öffnen und sehen, ob du einen Sky Tag an Bord, sodass du ihn in der Wo ist? App auf einer Karte sehen kannst. Der gesamte Prozess ist anonym und verschlüsselt, um deine Privatsphäre zu schützen. Du musst dir keine Gedanken über die Batterielebenszeit oder den Datenverbrauch machen.

Unerwünschtes Tracking verhindern:

Um unerwünschtes Tracking zu verhindern, erkennt dein iOS-Gerät einen Sky Tag eines Dritten, der sich für längere Zeit in deiner Nähe befindet, und sendet dir eine Warnmeldung. Wenn du die Warnmeldung ignorierst, wird das Tracking fortgesetzt. Du kannst das Tracking jederzeit beenden, indem du die Warnmeldung ignorierst. Du erhältst jedoch keine Benachrichtigung, wenn sich ein Sky Tag in der Nähe seines Besitzers befindet.

Schutz der Privatsphäre:

Apple schützt deine Apple Sky Tags sehr. In Sky Tags selbst werden keine Standortdaten oder Standortbezeichnungen gespeichert. Die Kommunikation mit dem Wo ist?-Netzwerk ist durchgehend verschlüsselt, sodass nur du Zugriff auf die Standortdaten hast. Weiter Apple noch anders können die Identität oder den Standort des Geräts erfahren, das bei der Suche nach deinem Sky Tag beteiligt war.

5 Wartung und Pflege

Öffne das Gerät nicht und las es nur von einem Fachmann reparieren.
Verwende zur Reinigung keine scharfen Chemikalien, Reinigungsmittel oder ähnliches.
Verwende zum Abwischen ein sauberes, trockenes Stofftuch.

6 Gewährleistung

Die 4smarts GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nachbesserung der Bedienungsanleitung und/oder der Bedienungsanweisung resultieren.

7 Hinweise zum Umweltschutz

Elektronische und elektrische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Bitte trenne sie von anderen Abfällen ab und bringe sie zu einer für elektronische Geräte sowie Batterien am Ende ihrer Lebensdauer an dem dafür eingerichteten, öffentlichen Sammelstellen oder an die Verkaufsstelle zurückzugeben.

8 Service und Support

Bei defekten Produkten oder Problemen während der Installation wende dich bitte an deinen Händler oder an die 4smarts Produktberatung auf <http://www.4smarts.com/contact>

Service Hotline

Montag – Freitag: 9 – 17h

Freitag: 9 – 17h

E-Mail: customer-service@4smarts.com

9 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass sich dieses Produkt in Übereinstimmung mit dem CE-Markierung befindet. Das Produkt ist in Übereinstimmung mit dem RED Richtlinie (2014/53/EU) befindet. Die Konformitätsklärung nach der RED Richtlinie findest du unter www.4smarts.com.

* Um diesen Gegenstand mit der App "Apple Find My" zu finden, wird die neueste Version von iOS, iPadOS oder macOS empfohlen. Die App "Gegenstände suchen" auf der Apple Store ist für iOS 11 oder höher erforderlich. Die App "Gegenstände suchen" auf der Apple Store ist für iOS 11 oder höher erforderlich. Die Verwendung des Abzeichens "Works with Apple" bedeutet, dass ein Produkt speziell für die Verwendung mit der in dem Abzeichen angegebenen Technologie entwickelt wurde und von Produkthersteller für die Erfüllung der Produktspezifikationen und Anforderungen von Apple entwickelt wurde. Apple ist nicht verantwortlich für die Verwendung des Produkts oder die Verwendung des Produkts oder die Verwendung dieses Produkts oder dessen Übereinstimmung mit Sicherheits- und Regulierungsstandards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS und watchOS sind Marken von Apple Inc. iOS ist eine Marke oder eingetragene Marke von Cisco in den USA und anderen Ländern und wird unter Lizenz verwendet.

* To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find My app on Apple Watch requires the latest version of watchOS. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple's requirements for interoperability. Apple is not responsible for the use of the product or its operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCI Warning statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that it may receive. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Check the equipment manual for help.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCI RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

4smarts

Thanks for buying our product! We at 4smarts are so glad that you chose our product for your needs. For news, customer support and to win great prizes, see you there!



@4smarts_official



facebook.com/4smarts



linkedin.com/company/4smarts



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.