

使用说明书

OWS 蓝牙耳机

将耳机取出悬挂在耳朵上，悬浮挂耳式佩带，悬浮空气感轻盈贴合不入耳，全天候轻盈舒适久戴不累耳。

功能键	操作	指示灯	提示音
功能名	M14		
开机	耳机在充电状态下，短按耳机自动开机/耳机充电状态下，长按耳机自动开机	红灯交替闪烁5s	Power on/开机
关机	耳机长按5s关机/耳机充电/耳机开机状态下长按5s关机/耳机关机	红灯长亮3s后熄灭	Power off/关机
左右耳耳机的切换	左右耳耳机自动进入配对模式	左右耳耳灯同时亮，主机耳灯在灯交替闪烁，副耳耳灯常亮	Connect/配对成功/配对中
切换中英文语言	未连接状态下按下，进入任意左/右耳机长按5s，即可切换。		English/中文
智能设备连接	当耳机与智能设备，自动进入设备连接状态，长按智能设备上的蓝牙配对按钮，长按5s，主机“M14”进行连接，耳机与智能设备连接成功后，有提示音，且耳耳耳灯闪烁灭	左右耳耳灯常亮	Connected/连接成功/连接中
切换音乐/游戏模式	连接设备状态下长按耳耳耳灯4s，进入切换模式，以“M14”显示。		Music/游戏模式 MUSIC GAME MODE
播放/暂停	单击耳耳耳灯5s后，双击任意左/右耳耳耳灯5s	/	/
上一曲	单击耳耳耳灯5s后，连击左耳耳耳灯键三次	/	/
下一曲	单击耳耳耳灯5s后，连击右耳耳耳灯键三次	/	/
增加音量	单击耳耳耳灯5s后，单击右耳耳耳灯键	/	最大音量提示(蜂鸣)
减小音量	单击耳耳耳灯5s后，单击左耳耳耳灯键	/	/
接听来电	连接状态下，长按左耳耳耳耳灯5s/长按，长按右侧语音助手	/	叮咚
语音助手	长按5s后，双击任意左耳耳耳耳灯键	/	语音助手/语音中
拒接来电	未连接状态下，长按任意左/右耳耳耳灯键2s	/	/
挂断电话	未连接状态下，双击任意左/右耳耳耳灯键	/	/

1. 产品名称: M114	10. 喇叭额定功率: 5mW
2. 蓝牙版本: Bluetooth 5.49	11. 耳机电池容量: 3.7V/40mAh (聚合物电池)
3. 支持模式: AAC/SBC	12. 充电仓电池容量: 3.7V/200mAh (聚合物电池)
4. 蓝牙传输距离: 10m	13. 充电接口: USB Type-C
5. 载波频率: 2.402GHz~2.480GHz	14. 耳机使用时间: $\approx$ 4~5小时
6. 频响范围: 20Hz~20KHz	15. 耳机单次充电时间: $\approx$ 1.5小时
7. 喇叭尺寸: ϕ 13mm	16. 充电仓充电时间: $\approx$ 1.5小时
8. 喇叭灵敏度: 100db $\pm$ 3db	17. 充电仓给耳机充电次数: 约 3~4次
9. 喇叭阻抗: 32 Ω $\pm$ 15%	18. 关机待机电时: $\approx$ 3000h/8

1. 初次使用本产品前，请充分充电再使用。
2. 产品不是玩具，12岁以下儿童应在成年人监护下使用。
3. 请勿通过使用过长时间“安全认证”的5V1A充电器，避免支持高功率的快充充电器对产品造成损坏。
4. 请勿在潮湿的环境下充电，在充电时请勿移动，电量充满后请尽快将充电线拔出，避免长时间充电导致造成短路，充电的充电方式为Type-C接口。
5. 本产品为可拆卸的锂离子电池充电器，重复对手机进行充电时充电器将会随时间逐渐老化，导致性能下降，这对所有可以重复充电电池设备均属于正常现象。
6. 本产品带有温度保护，如长时间未使用，请至少一个月充电一次。
7. 因个体差异原因，如佩戴时感到皮肤不适，请停止佩戴并咨询医生。
8. 蓝牙耳机使用本产品时，请将耳机音量调至合适音量大小，以延长耳机在最大音量状态下使用寿命造成损伤。
9. 如果在日常需要集中注意力的活动时使用本产品，应注意自身和他人的安全，例如在驾车时行驶中，在商场、施工场所、铁路上等公共出行场所，应尽量不要佩戴本产品以确保可以听到周围的警示。
10. 请遵守所在地区或国家的相关法规，并严格按照要求使用本产品。
11. 本产品含有磁性材料，使用或存放产品时，请勿离具有强磁场或强电流的场所，如微波炉、电冰箱等。

1. 请仔细阅读本说明书的内容以正确使用，避免产品因错误操作受损。

2. 本产品请远离儿童、火源、热源、冷冻品、热源及化学药品。

3. 请勿长时间使用本产品以作加热，以免引起火灾造成不良后果。

4. 如将本产品放入附赠托盘中任意液体或热水中清洗，可能导致火灾或触电危险。

5. 请勿将本产品置放在太阳直射处或温度较高的地方。高温会缩短电子部件的使用寿命。损坏电源。使某些塑料部件变形。

6. 请勿将本产品放在尘土多、温度和湿度高低变化的地方保存。

7. 请勿将银质卡（如银联卡、金卡等）长期放在本产品卡槽，否则可能导致银卡被磁场损坏。

8. 请勿在本产品上施加较大的压力、或拆卸、摔打、震动本产品，以防产品损坏。

9. 请勿在潮湿或液体环境下使用，如浴室、厨房、游泳池、热水浴缸等会产生蒸汽的场所。

10. 请勿在本产品上放置重物，如钱包、钥匙、硬币、戒指、打火机、烟等。

11. 请勿在雨天天气下使用设备，避免雨水可能导致设备发生短路、火灾等危险。

12. 请避免本产品及其配件受潮或浸水，且长时间运动或出汗较多时使用本产品，防止液体渗透到产品的内部损坏产品。

13. 产品属于内置聚合锂电池产品，不可更换，请勿丢弃或置入火中，以免爆炸、起火等危险发生。

14. 如消费者违反上述警示提示给使用者造成的人身及财产损失概由自行承担一切后果本公司将不承担任何法律责任。



OWS Bluetooth earphones

Headphones x2pcs
Charging case x1pcs
Type-C charging cable x1pc
Instruction manual x1pcs

Function	operate	Light	Tone
Pair	M134		
Boot	Headphones in the case of charging bit taps the headphones automatically boot/headphones off state, (long touch key 3 seconds to boot)	Red and blue lights flash alternately	Power on/开机
Shutdown	Tap the earphone into the charging bit and shut down automatically the touch button for 5 seconds to shut down the earphone	The red light stays on for 3 seconds before turning off	Power off/关机
Pair the left and right earphones	The left and right earphones will automatically enter pairing mode after powering on	After successful pairing of the left and right earphones, the red and blue lights of the main headphones blink simultaneously, and the height of the speaker air gun can be adjusted	Connect/配对成功
Toggle the Chinese and English prompts tones	Without connecting the smart device, double-click any left/right ear touch key 4 times, the language switch Factory default English		English/中文
Smart device connectivity	When the ear are successfully paired, it will enter the pairing time for 30 seconds, at this time, please take the earphones to search and click "Pair" to connect, after the search is successful, the earphones will be a prompt tone, and the headset volume will go up	The lights in the left and right ears are turned off	Connected /连接成功
Toggle Music/Genre mode	Connect the device to the state of the left earphone touch button 3 seconds to switch, the factory default music mode		音乐/游戏模式 MUSIC/GAME MODE
Play/Pause	After the music player starts, double-click any left/right headphone touch button	/	/
Previous song	After the music player starts, click the left earphone touch button three times	/	/
Next song	After the music player starts, click the right earphone touch button three times	/	/
Increase the volume	After the music player starts, click the touch button on the right headset	/	Maximum volume indicator (knock)
Reduce the volume	After the music player starts, click the touch button on the left headset	/	/
Voice assistant	Press the left earphone touch button 2 seconds to open the voice wake word, more resistant	/	Ding Dong
Answer an incoming call	When the call is incoming, double-click any left or right earphone function key		Ringtone of your phone

Product name: M114	10. Horn rated power: 5mW
Bluetooth version: Bluetooth 5.49	11. Headphone battery capacity: 3.7V/40mAh (polymer battery)
Support mode: AAC/SBC	12. Charging bin battery capacity: 3.7V/200mAh (polymer battery)
Bluetooth transmission distance: 10m	13. Charging interface: USB Type-C
Carrier frequency: 2.402GHz-2.480GHz	14. Headset use time: 3-4.5 hours
Frequency response range: 20Hz-20KHz	15. Earphone single charging time: 1.5 hours
Horn size: Φ13mm	16. Charging time: 1.5 hours
Horn sensitivity: 100dB ± 3dB	17. Charge the headset: About 3-4 times
Horn impedance: 32Ω15%	18. Shutdown standby time: 13000 hours

1. Before using this product for the first time, please fully charge it before using it.
2. This product is not a toy, and children under the age of 12 must be used under the supervision of an adult.
3. Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer.
4. Please do not use the product in a high-voltage environment, such as a power substation.
5. Please charge in a safe environment, when charging the charging case, please pull out the charging cable and connect it to the power source.
6. Please charge by long-term charging. The charging method of the charging case is the Type-C interface.
7. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery performance over time, which is normal for rechargeable built-in batteries.
8. Please use the product in a healthy battery, if it has not been used for a long time, please charge it at least once a month.
9. Please use the product with caution when wearing it due to individual differences, please stop wearing it and consult a doctor.
10. When using this product with Bluetooth connection, please adjust the sound of the earphone to a comfortable level to avoid hearing damage caused by long-term loud volume.
11. If you use this product while engaging in activities that require concentration, you should pay attention to your surroundings, such as driving, walking, or riding a bicycle, to avoid accidents on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warnings.

Please follow the content of this manual to avoid damage to the product due to incorrect operation.

1. Do not use the product away from children, fire, heat, refrigeration, water and chemicals.
2. Do not listen at a loud volume for a long time to avoid adverse effects on hearing.
3. Do not immerse the product and accessories in any liquid or rinse the product with water. The product will be damaged.
4. Do not place the product in the sun or in a place with high temperature. High temperatures will shorten the life of electronic components, damage batteries, and deform certain plastic parts.
5. Do not place the product in a place with a lot of dust, too high or too low temperature and humidity.
6. Do not contact the magnetic stripe card (such as bank card, bus card, etc.) with this product. The magnetic stripe card will be damaged and the information on it will be lost. Do not place a magnetic stripe card near the product.
7. Do not place the product under greater pressure to this product or over it, or shake this product to prevent damage to the product.
8. Do not use this product near heat sources, such as radiators, hot air regulators, stoves, or other instruments that generate heat.
9. Do not block the openings of this product, such as charging ports, indicator lights, etc.
10. Do not use the device in rainstormy weather; thunderstorms may cause the device to malfunction and increase the risk of electric shock.
11. Do not disassemble this product and its accessories are exposed to rain or moisture, and when you experience vigorous or sweat a lot, to prevent liquid from entering the product.
12. The product belongs to the built-in polymer battery, which cannot be replaced, please do not discard or put it in the fire to avoid explosion, fire and other dangers.
13. The product is not a toy. It is not suitable for children. The personal and property damage will be borne by the user, and the company will not incur any legal liability.



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.