


Model No.: G-225-D

G-225-D

Multimode Wireless Mouse

User Manual



1

Quick Start

1. Turn the power switch to ON.

2. Press the pairing button briefly to choose Bluetooth mode.

3. For Bluetooth mode, hold the pairing button for 3 seconds, then pair with Bluetooth device name WM-225GD.

4. Press any mouse button to wake the mouse from sleep

Package Contents

Wireless mouse

USB-C charging cable

User manual

Compatibility

Bluetooth (5.3v) mode: Windows 10 or later, macOS 10.10 or later, iOS 13 or later, and devices with Bluetooth 5.0 or above

Using Bluetooth 5.3v Mode

Turn the mouse ON.

Press the pairing button briefly until the blue indicator flashes.

Press and hold the pairing button for 3 seconds to enter Bluetooth pairing mode.

On your device, open the Bluetooth settings and search for WM-225GD.

Select WM-225GD and complete pairing.

On Windows, you can pair from the Bluetooth menu or from Control Panel > Devices and Printers > Add Device.

On iPhone or iPad, enable AssistiveTouch first: Settings > Accessibility > Touch > AssistiveTouch.

2

Switching Modes

Press and hold the pairing button for 3 seconds to force Bluetooth pairing mode.

Charging

Use the included USB-C cable to charge the mouse from a computer, a standard USB charger, or another USB power source.

Charging time is approximately 2-3 hours. When the battery is low, the yellow LED blinks; while charging, the red LED stays on; when fully charged, the red LED turns off.

If the red LED at the bottom does not light up when first used, the battery may be in protection mode. Charge it for 2-3 hours and try again.

Buttons and DPI

Press the DPI button to switch pointer speed: 800 / 1200 / 1600 DPI (default).

The side buttons support forward and back navigation in supported applications.

Auto-Sleep Function

After 30 minutes of inactivity, the mouse enters sleep mode automatically to save power.

Press any button to wake it up.

Safety Notes

Use this product indoors in a dry environment only. Keep it away from water, excessive humidity, and direct heat sources.

Charge the mouse only with a standard 5 V USB power source and an undamaged cable.

Do not disassemble, crush, puncture, or expose the product to fire. The mouse contains a rechargeable battery.

Stop using the product immediately if it becomes unusually hot, emits an odor, shows swelling, or appears damaged.

Keep the mouse, receiver, and cable out of reach of small children. Small parts may present a choking hazard.

Dispose of electronic products and rechargeable batteries in accordance with local regulations. Do not dispose of them in fire or household waste where prohibited.

3

Troubleshooting

Mouse not working: charge the mouse.

Slow or unstable response: keep the mouse away from sources of wireless interference and avoid metal surfaces between the mouse and receiver.

Bluetooth pairing issue: delete the previous pairing record on your device, then pair again using WM-225GD.

Product Parameters

Battery voltage	3.7 V
Charging voltage	4.2 V
Battery capacity	500 mAh
Charging duration	2-3 hours
Battery life	Approx. 45-55 days under normal use

Warranty Card

After-sales Email: memzuoix@163.com

4

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.