


ULTREAN AI Nutriscale Volt  Ultrean Support: Support@ultrean.com Model No.: JKS18	TABLE OF CONTENTS IMPORTANT SAFEGUARDS3 GETTING TO KNOW YOUR DIGITAL KITCHEN SCALE 5 OPERATING INSTRUCTIONS 7 TROUBLESHOOTING 9 FCC STATEMENT10 WARRANTY INFORMATION 11 CUSTOMER SERVICE11	IMPORTANT SAFEGUARDS Warning: Please read and comply with all of the instructions and warnings provided in this manual before using the product. Important Safety Information Please read and comply with all of the instructions and warnings provided in this manual before using the product. 1. Always place the scale on a hard, dry, and flat surface before measurement to ensure accuracy. 2. DO NOT immerse the scale in water or corrosive liquids. If a liquid is spilled on the scale platform, immediately wipe the scale and clean with a soft cloth to avoid potential damage to the scale. 3. DO NOT exceed 33 lb weight capacity. An overload indicator will appear on the LCD if the limit is exceeded. 4. When replacing batteries, ensure that they are inserted with the correct polarity as indicated inside the battery compartment. 5. DO NOT mix new and used batteries to power the device. 6. This scale is not intended for commercial or heavy-duty use. 3	7. When the scale is not in use, it should be stored in a cool and dry environment. 8. To clean the scale, simply use a soft cloth dampened with water to wipe the surface of the platform. 9. If the scale fails to turn on, please make sure to check if the device is out of power. Replace the batteries or recharge the food scale with a USB cable if necessary. 10. If the scale is not in use for an extended period, take out the batteries to extend the scale service lifetime. 11. Replace the batteries or charge them with the USB cable if the low-battery indicator "Lo" is displayed to ensure the highest accuracy. 4	GETTING TO KNOW YOUR DIGITAL KITCHEN SCALE 1.Product Diagram  1. LCD Display 2. Power/Auto-Tare Button 3. Unit Selection 4. Battery Compartment 5. USB Type-C Charging Port 6. Anti-Skid Padding 5																															
2. Package Inclusion 1x Digital Kitchen Scale 1x USB-A to USB-C Cable 1x User Manual 2x 1.5V AAA Batteries (Pre-installed) Note: The provided 2 x 1.5V AAA Batteries are non-rechargeable batteries and should not be recharged. 3. Specifications <table><tr><td>Model No.:</td><td>JKS18</td></tr><tr><td>Weight Capacity:</td><td>15000g / 15kg / 529oz / 33lb / 527.9 floz (water) / 512.6floz (milk) / 15,000ml / 14,565ml (milk)</td></tr><tr><td>Units:</td><td>g / kg / oz / lb:oz / floz (water) / floz (milk) / ml / ml (milk)</td></tr><tr><td>Measurement Increments:</td><td>0.1 oz / 1 g / 1 ml</td></tr><tr><td>Auto-Off:</td><td>120 seconds</td></tr><tr><td>Two Power Supply Options:</td><td>1. Battery powered: 2 x 1.5V AAA batteries (Pre-installed) 2. USB charging: Built-in 250mAh recharge eable battery and comes with a USB-C charging cable</td></tr><tr><td>Product Dimensions:</td><td>6.1*8.3*0.6 inch/15.5*21*1.5cm</td></tr><tr><td>Product Weight:</td><td>0.6 lb / 274 g</td></tr></table> 6	Model No.:	JKS18	Weight Capacity:	15000g / 15kg / 529oz / 33lb / 527.9 floz (water) / 512.6floz (milk) / 15,000ml / 14,565ml (milk)	Units:	g / kg / oz / lb:oz / floz (water) / floz (milk) / ml / ml (milk)	Measurement Increments:	0.1 oz / 1 g / 1 ml	Auto-Off:	120 seconds	Two Power Supply Options:	1. Battery powered: 2 x 1.5V AAA batteries (Pre-installed) 2. USB charging: Built-in 250mAh recharge eable battery and comes with a USB-C charging cable	Product Dimensions:	6.1*8.3*0.6 inch/15.5*21*1.5cm	Product Weight:	0.6 lb / 274 g	OPERATING INSTRUCTIONS General Operation 1. Place the scale on a flat and level hard surface for measurement. 2. Press the "POWER" button to turn on the scale. Wait until the screen displays zero before measuring. 3. Place the object of measurement on the center of the weighing platform. 4. Allow the scale to adjust to the weight of the object for a few seconds before it displays the final measured reading on the LCD screen. Tare Function 1. The tare function allows you to measure objects in a container without having to include the container's weight in the final measurement. 2. Turn on the scale and wait for the screen to display zero. If the screen does not display zero automatically, press the "POWER" button to auto-adjust to zero. 3. Place the desired object which is to be excluded, on the center of the measuring platform. 4. Press the "POWER" button to tare the current weight of the object. The screen should now display zero. 5. Place the desired item(s) to be weighed on the center of the measuring platform or within the tared container to calculate the net weight of the 7	desired item(s). USB Type-C Charge The scale's display will show "Lo" when the battery power is low. Follow the steps to recharge. 1. Insert the USB charging cable into the USB charging socket. 2. Plug the USB charging cable into a DC 5V adapter and plug it into an outlet. You can also plug the cable into a powered USB outlet. 3. When charging, the charging indicator will turn red. Once the battery is fully charged, the charging indicator will turn off. Reminder: While the built-in battery is charging, please ensure you remove the AAA batteries from the scale. This will prevent any potential issues or conflicts when using the USB-C cable for charging. Battery Replacement 1. Open the battery compartment cover located on the backside of the scale. 2. Take out the used batteries and dispose of them properly. 3. Install new AAA batteries, taking note of the correct polarity displayed in the battery compartment. 4. Reseal the battery compartment. Note: When you use it for the first time, you need to tear off the insulation film of the battery. 8	Automatic Power Off For battery power conservation, the scale will automatically power off after 120 seconds of inactivity. Manual Power Off Press and hold the "Power" button for 3 seconds to manually turn off the digital scale at any time. TROUBLESHOOTING <table><tr><th>ERROR MESSAGE</th><th>REASON</th><th>SOLUTION</th></tr><tr><td>"Err"</td><td>Scale overload. Maximum weight capacity: 33lb(15kg)</td><td>Remove the object from the scale to avoid damage.</td></tr><tr><td>"_ _"</td><td>Indicates a negative weight. When an object is weighed and cleared, and then the object is removed, it will display a negative weight.</td><td>Press the "Power" button to adjust to zero.</td></tr><tr><td>"LO"</td><td>Battery power is low. Shutting down soon.</td><td>Install new batteries/ USB Type-C charging.</td></tr><tr><td>The LCD light is very dim.</td><td>Battery power is low.</td><td>Install new batteries/ USB Type-C charging.</td></tr></table> If your problem is not listed, please contact Customer Support at support@ultrean.com. 9	ERROR MESSAGE	REASON	SOLUTION	"Err"	Scale overload. Maximum weight capacity: 33lb(15kg)	Remove the object from the scale to avoid damage.	"_ _"	Indicates a negative weight. When an object is weighed and cleared, and then the object is removed, it will display a negative weight.	Press the "Power" button to adjust to zero.	"LO"	Battery power is low. Shutting down soon.	Install new batteries/ USB Type-C charging.	The LCD light is very dim.	Battery power is low.	Install new batteries/ USB Type-C charging.	FCC STATEMENT NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 10
Model No.:	JKS18																																		
Weight Capacity:	15000g / 15kg / 529oz / 33lb / 527.9 floz (water) / 512.6floz (milk) / 15,000ml / 14,565ml (milk)																																		
Units:	g / kg / oz / lb:oz / floz (water) / floz (milk) / ml / ml (milk)																																		
Measurement Increments:	0.1 oz / 1 g / 1 ml																																		
Auto-Off:	120 seconds																																		
Two Power Supply Options:	1. Battery powered: 2 x 1.5V AAA batteries (Pre-installed) 2. USB charging: Built-in 250mAh recharge eable battery and comes with a USB-C charging cable																																		
Product Dimensions:	6.1*8.3*0.6 inch/15.5*21*1.5cm																																		
Product Weight:	0.6 lb / 274 g																																		
ERROR MESSAGE	REASON	SOLUTION																																	
"Err"	Scale overload. Maximum weight capacity: 33lb(15kg)	Remove the object from the scale to avoid damage.																																	
"_ _"	Indicates a negative weight. When an object is weighed and cleared, and then the object is removed, it will display a negative weight.	Press the "Power" button to adjust to zero.																																	
"LO"	Battery power is low. Shutting down soon.	Install new batteries/ USB Type-C charging.																																	
The LCD light is very dim.	Battery power is low.	Install new batteries/ USB Type-C charging.																																	

WARRANTY INFORMATION We grant a 1-year warranty on the product commencing on the date of purchase. Within the guarantee period, we will eliminate any defects in the appliance resulting from faults in materials or workmanship. Please contact us at: support@ultrean.com to launch a warranty claim. This guarantee does not cover damage due to improper use, normal wear or use as well as defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorized persons and if original product parts are not used.
CUSTOMER SERVICE 1. If you have any product questions or concerns, please prepare your order details and contact us directly at support@Ultrean.com or visit our website at: www.ultrean.com. 2. We have a professional customer service team to provide satisfactory solutions to any issue you might have.