


Model: T19

Sound Effects Machine User Manual



Get ready to create surprise and joy
with sound!

This product complies with all applicable CPSIA and ASTM F963 safety requirements.

v26.6

FCC Warning Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

IC Warning:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment; To maintain compliance with IC's RF Exposure guidelines, this device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.


Déclaration de l'ISED Canada: Cet appareil contient des émetteur(s) / récepteur(s) sans licence / conformes à l'innovation RSS exemptes de licence de Sciences et Développement économique Canada. L'opération est sous réserve des deux conditions suivantes:

- 1) cet appareil ne peut pas causer d'interférences et
- 2) ce dispositif doit accepter toute interférence, y compris peut provoquer le fonctionnement indésirable de l'appareil.

Exposition aux rayonnements: Cet équipement est conforme aux radiations du Canada limites d'exposition pour un environnement incontrôlé noncé d'exposition RF Pour maintenir le respect des guides d'exposition RF d'IC, Cet appareil et ses antennes ne doivent pas être co-localisé ou en opération en conjonction avec toute autre antenne ou émetteur.

For the safety of you and your children, please strictly read and observe the following warnings:

- ◆ **Hearing Protection:** Do not place the main unit's speaker directly against the ear for extended periods, especially in High Volume mode, to avoid hearing damage.
- ◆ **Choking Hazard:** This product contains small detachable parts and is not suitable for children aged 3 and under. Please use under adult supervision and keep it in a safe place.
- ◆ **Battery Safety:** Both the main unit and the remote control have built-in lithium batteries. Do not disassemble, puncture, or dispose of them in fire.
- ◆ **Charging Safety:** Please ensure you use the included Type-C charging cable and a charger compliant with DC 5V-1A specifications. Do not cover the main unit while charging, and avoid leaving it charging unattended for long periods.
- ◆ **Water Warning:** This is an electronic product and is not waterproof. Keep away from water sources, moisture, and any liquids to prevent short circuits and damage.
- ◆ **Usage Norms:** Do not disassemble, throw, or violently impact this product to avoid damaging internal electronic components.



How to Use

Before first use, it is recommended to fully charge both the host and the remote control.

Safety Precautions

For the safety of you and your children, please strictly read and observe the following warnings:

- ◆ **Hearing Protection:** Do not place the main unit's speaker directly against the ear for extended periods, especially in High Volume mode, to avoid hearing damage.
- ◆ **Choking Hazard:** This product contains small detachable parts and is not suitable for children aged 3 and under. Please use under adult supervision and keep it in a safe place.
- ◆ **Battery Safety:** Both the main unit and the remote control have built-in lithium batteries. Do not disassemble, puncture, or dispose of them in fire.
- ◆ **Charging Safety:** Please ensure you use the included Type-C charging cable and a charger compliant with DC 5V-1A specifications. Do not cover the main unit while charging, and avoid leaving it charging unattended for long periods.
- ◆ **Water Warning:** This is an electronic product and is not waterproof. Keep away from water sources, moisture, and any liquids to prevent short circuits and damage.
- ◆ **Usage Norms:** Do not disassemble, throw, or violently impact this product to avoid damaging internal electronic components.

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

- **Solid Light:** Charging.
- **Light Off:** Fully Charged.

Blue Light (Host Only):

- **Solid Light:** Connected successfully, ready for use.
- **Light Off:** Low battery, please fully charge before use.

Troubleshooting

Problem: No sound comes from the host when pressing buttons on the remote control?

- ① **Check 1:** Check if the host has automatically shut down due to prolonged inactivity. Try toggling the power switch to wake it up.
- ② **Check 2:** Check the indicator light status on the host. If the blue light is off while the device is switched on, the battery is depleted. Please charge it first.
- ③ **Check 3:** Check if the connection has dropped. If you need to re-pair, ensure the device is powered on and long-press the pairing reset button on the remote. Once you hear three consecutive beeps from the host, the pairing is successful.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

◆ **Resetting & Re-pairing:** If the host does not respond when you operate the remote control normally, try re-pairing them. Ensure the host is powered on, then press and hold the button with the star symbol "★" (the 2nd button from the left in the 3rd row on the front of the remote) for about 6 seconds. When you hear the host emit three consecutive beeps ("beep, beep, beep"), the re-pairing is successful, and the device is ready for normal use.

- 6 -

English

Charging & Power Management

Charging Specifications:

Both the host and the remote control use a Type-C interface. Please use a 5V-1A charger for charging.

Smart Sleep Mode:

If the host does not receive any signal from the remote control for an extended period, it will automatically shut down to save power. To wake it up, slide the host's switch back to the "OFF" position and then slide it open again.

Indicator Light Status

You can easily understand the operational status of the device through the indicator light on the host:

Red Light:

