

展开尺寸: 600*140mm

Prohibition

WARNING

May cause electric shock or fire hazard.

INSTALLING

1. Do not use unsafe plug or power.
2. Do not install the device at the place where children can touch.
3. Do not install the device in the place where can not bear strength and prone result in falling and collapsing.
4. Do not tilt the device.
5. Keep the device away from fire and heat source, prohibit to store flammable and explosive materials around the device.
6. Except for the atomizer, the housing material is not resistant to corrosion.
7. Do not use device in high temperature or wet environment.
8. Do not use inflammable, explosive, corrosive and other hazardous solvents work with the device.

Note

May cause personal injury or property damage

NECESSARY INSTALLING

- 1.Ensure the firmness of installation area.
- 2.install the device in a ventilative and adequate space.
- 3.Do not block the sprayer by hand or other obstructions when the device is working.
- 4.Do not spill water or conductive, corrosive liquid on the device surface or fall inside of the device.
- 5.Cut off the power in extreme weather environment.

ATTENTION	This diffuser is unique for using fragrance oil without mixing water. For a better performance of the perfume in the environment, we recommend only using pure essences.
-----------	--

Voltage: 6V
Power: 2.5W
Capacity: 500ml
Weight: 0.56kg
Coverage: 500-800m²
Size: 245*167*44mm

The diagram shows the internal layout of the refrigerator. On the left is the freezer compartment with three drawers. To the right is the main refrigerator compartment. At the top right, there is a control panel with a digital display and four buttons labeled '10', '20', '30', and '40'. Below the control panel is a large evaporator fan motor assembly. The main compartment has a vertical scale on the right side with markings at 100, 200, 300, and 400. The bottom of the main compartment is divided into two sections, labeled '100' and '200'.

01. Choose one favorite oil
02. Use key to open the door
03. Insert the battery and take out oil bottle
04. Pour the oil into the bottle

- 05.** insert the diffuser head on machine
- 06.** Set the work time manually
- 07.** Or Set the work time on App
- 08.** Enjoy the fragrance

Figure 1 shows the front panel of the digital clock. The display is a 7-segment LCD showing the day of the week (MON), the time (8:00), and the month (8). The buttons include SCENT, WORK, PAUSE, EVENT, ON/OFF, and a numeric keypad.

4. Battery power display:

- ★ one cell power: battery power remaining 20%;
- ★ two cells power: battery power remaining 40%;
- ★ three cells power: battery power remaining 60%;
- ★ four cells power: battery power remaining 80%;
- ★ five cells power: battery power remaining 100%;
- ★ when the battery power is lower than 5%, the device stops working.

5. Work time and Scent intensity setting

- (1) Press the **MODE** button for the first time to enter the first program working time setting (**Event on 1**). Press the **SET** button to start the hour setting, press the **↑** button to select the hour, press the **SET** button to confirm. Enter the minute setting, press the **↑** button to select the minute, and press the **SET** button to confirm. Enter the day setting, press the **↑** button to select the work day, the **↑** button to cancel the work day setting. Automatically save and finish the first program working time setting.
- (2) Press the **MODE** button for the second time to enter the first program pause time setting (**Event Off 1**). Press the **SET** button to start the hour setting, press the **↑** button to select the hour, press **SET** to confirm, enter the minute setting, press **↑** to select the minute. Automatically save and finish the first program working time setting.
- (3) Press the **MODE** button for the third time to enter the first program scent intensity adjustment (**Scent Work**). Press the **↑** button to adjust the working seconds, the working seconds range is 5 to 30 seconds. Press **↑** once to increase 1 second, press **↓** once to decrease 1 second, the working seconds Setup is complete.
- (4) Press the **MODE** button for the fourth time to enter the first program scent pause adjustment (**Scent Pause**). The pause seconds range is 90 to 900 seconds. Press the **↑** button to increase or decrease the pause frequency. Within 90-300 seconds. Press **↑** button once to adjust for 30 seconds; Within 300-500 seconds, press **↑** button once to adjust for 50 seconds; and within 500-900 seconds, press **↑** button once to adjust for 90 seconds.

Press and hold the **"MODE + SET"** button for **5 seconds** to restore the device to the factory settings. The first program factory setting is **8.00am to 22.00pm**, the scent frequency is **10-120 seconds**, and the remaining four program setting are **00.00-00.00**, and the scent frequency is **10-120 seconds**.


the power-off prompt is the **[OFF]** icon flashing 3 times continuously. The screen

1. **Download Aroma-Link**



To start configuring the diffuser on phone, please scan QR code to download "Aroma Link" App.

First step, turn on the bluetooth function on your phone,
Second step, run our Aroma-Link app and choose bluetooth mode.
Then Click My Devices ,you will find the device name SmartAO (Mobile should nearby to machine).
Third Step, Click this device and put the password 1234(default setting is 1234),the machine will be connected successfully.
Reference the pictures (Figure 1 to Figure 4)



Figure

Figure

Device List (0)

- NI-200 A3
ID: 67C3B48A-C85D-1A4F-0...
- SmartAoma A5 A3
ID: A758F125-70ED-7627-43...
- A6.A5.WIFI
ID: B257965A-605A-2CE4-4...
- SmartAoma A3
ID: C810A474-505A-4C7E-4...
- OG-S.A5.WIFI
ID: D109B389-B24D-47C3-8...

Figure 3

Figure

On the APP, you can check working time and pause time of the device, change the settings and turn on/off the device.

Click "Set up" on the main interface to set working period, support to set five working periods in each day. After setting, please click "Save" to finish the setting. (Refer to Figure 5 and Figure 6).

Figure

Figure 6

5. Click "Set up" on the main interface to set the working frequency (Refer to Figures 7 and 8).





Figure 7



Figure 8

In order to manage multiple devices, the Bluetooth name of each device can be modified. For example, we can modify the device which put in the meeting room: Meeting Room 01".

Modify method: Press the device name "Smart.A1" in the app (Refer to Figure9), then enter the name modification interface, after you rename the device, click "OK" to confirm the setting. (Refer to Figure 10).



Figure




Figure 10

No scents	1. Check whether the device's battery is powered on or not. 2. Check whether the pump is working or not and whether the nozzle is blocked or not. 3. Check whether the essential oil in the bottle is ran out or not and whether the pipe falls off or not.
Scents weak	1. Oil leakage inside the machine: Check whether the essential oil bottles is tightened or not. 2. Oil leakage from the mist outlet: Check whether there are obstacle in the mist outlet hole.
Unusual noise	1. Check pump whether fall out, and re-install the air pump. 2. Check whether the mist outlet is blocked by obstacle. 3. Check the pump whether is low airflow and low pressure.

(1) Provide free technical solutions and installation process guidance
(2) Provide free online FAQ consultation and scent-marketing suggestion

(1) All devices enjoy 12 months free maintenance (from the day of purchase),
(2) Please provide the warranty card, invoice or other proof which can prove it ordered from our company to enjoy the free maintenance
(3) The human error or other wrong operation cause the fault; not belong to the scope of warranty, and will not be accepted to provide free maintenance.

1. Please clean the equipment periodically, suggest 2-3 months in 1 circle, so that it can work under best condition.

2. Please cut off the power when cleaning, also do not use wet hand to operate it directly, in case of electric shock and injury.

- (1) Please turn off and cut off the power then roll up the power cord,
- (2) Clean the filter components,
- (3) Place the deodorant package which contains activated carbon in the device or package, to prevent residual substances in the equipment produce odor.
- (4) Please equip the machine with the dust cover, placed in the shade, ventilative place.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning: This equipment may be used without restrictions regarding RF exposure provided that the following conditions are met:

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
- These limits are designed to provide reasonable protection against interference in a residential installation.
- This equipment generates, uses, and can radiate radio frequency energy, and it is not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, you may avoid this interference by reorienting or separating the equipment from the interfering item.
- If you are unable to eliminate the interference through the above measures, you are encouraged to notify your local government or the FCC.

Interference can be caused by radio frequency signals that can be determined by turning the equipment off and on; you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.