


70mm

正面

120mm

User Manual



Function introduction

1. Battery power indicator
2. Type C input
Type C output
3. Wireless output

Operating instructions:

1. Press the power button to display the remaining power
2. Power input and output: Use the power cable to connect the power adapter to charge the power bank, connect the power bank to charge the device to be charged through the power cable, or use the wireless charger to charge the mobile phone (the device needs to support wireless input function).

Technical parameters:

Battery Type: Polymer Battery
Capacity: 2500mAh
Type-C Input : 5V/3A;9V/2A
Type-C Output: 5V/3A;9V/3A;12V/2.5A
Wireless Output Power: 15W (Max)
Size: 97*61.5*23mm
Weight: 156.5 ± 5g

How to charge for power bank

1. Use a Type-C charging cable to charge the power bank.
2. It is recommended to use a power adapter to charge the power bank.
3. It can be connected to the USB port of a computer to charge the power bank.
4. After pressing the power button, the LED power indicator on the power bank will turn white.
5. During the charging process, the white LED power indicator on the power bank will continuously blink, and the green LED light will turn on when in fast charging mode.
6. When fully charged, the LED power indicator on the power bank is stable and white.
7. The four LED power indicators correspond to 25%, 50%, 75%, and 100% of the remaining battery capacity of the power bank, respectively.

Charge mobile devices

1. Use a power bank to charge your phone.
2. Connect the power bank to your phone using a charging cable, and the phone will automatically charge through the power bank.
3. Place a smartphone with wireless capabilities on the wireless charging area of the power bank, then press the power button and wait for about 8 seconds, and the power bank will automatically charge your phone.
4. When charging the phone, the LED power indicator will light up white.
5. When the phone is fully charged, the power bank will automatically turn off within 30 seconds after disconnecting.

Note:

1. The charging time for this power bank is approximately 3-4 hours, depending on the actual situation.
2. If the power bank cannot charge or your phone cannot be charged through the power bank, please check if the connection cable is normal and secure, and if the charging port accessories are suitable. It is recommended to use a power adapter from a reputable brand to charge the power bank.
3. There is a conversion rate issue with power banks, so the capacity of the power bank does not equal the rechargeable capacity.
4. If the power bank cannot turn on for short-circuit protection due to improper operation, please charge the power bank to activate it.

Safety Information:

Warning: Failure to follow these safety instructions may result in fire, electric shock, damage or other injury.

1. Please try to keep the storage temperature of the product between 10-35°C.
 2. Do not fall, do not disassemble or puncture, repair the power bank by yourself.
 3. Do not expose the power bank in fire, high temperature or water.
 4. Stop using the power bank if you find any abnormal phenomena such as expansion or expansion of the charged device.
 5. This device is not suitable for using by persons with immature physical, perceptual and mental abilities (including children), nor by persons lacking relevant experience and knowledge, unless supervised and guided by someone who is professionally responsible for their personal safety. Please control children to ensure that they do not use this device as a toy.
 6. Do not leave the product in the car for a long time, especially when parked in the sun.
 7. Do not put foreign bodies into the product interface.
 8. Please charge your power bank at least every three months.
- The above information is for reference only and is subject to change without prior notice.

List of parts:

1. Power bank *1
2. Type C charging cable *1
3. User manual *1



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.