




English2

WARNING


English



(15"-60" OR 40-140CM FROM THE GROUND)


1. Place the Motion X at a suitable height.

Position it between 15"–60" (40–140 cm) from the ground.




2. Put Motion X close to the edge.

This allows the camera to capture as much of the play area as possible.




3. Do not block the camera.

Keep the camera lens clean and unobstructed.




4. Connect Motion X to the TV via HDMI .

Select the corresponding input source on your TV.



5. Connect Motion X to Power Supply.


Use the original power cable provided.



6. Follow the on-screen setup guide:


Let's get started.

Tips




1. Clear your play area before you start.

Make sure there' s nothing in the way so you can move around safely and have fun!



2. Wear clothes that stand out from your background.


The camera may have trouble recognizing your movements.



AVOID BACKLIGHTING


3. Keep your play area well-lit and avoid backlighting.

Avoid lighting that is too dim or too harsh, as it may affect camera recognition.



4. Try to keep just one player in front of the camera at a time.

Too many people in the view might confuse Motion X when it's trying to follow your moves.



5. Turn on Game Mode on your TV (if available).

This helps make your gameplay smoother and more responsive. If your TV doesn't have this option, no worries—you can still have a great time!

Model	Motion X	RAM	4GB LPDDR5
CPU	RK3576S	ROM	128GB UFS
GPU	ARMMali G52 MC3	Bluetooth	BT 5.0+
DC Power	DC 5V- 2A	Language	Multi-Language
WiFi	WIFI6	Operating system	Android 14

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

If you want to know more about retro games or other content, please scan the QR
code below :

