


USER MANUAL


使用手册

产品简述及外观

本产品是针对成人伴侣所研发的一款震动阳件套,可用遥控器进行操控。产品采用液态硅胶制造,柔软舒适,贴近人体肌肤的表面触感。仿真外形,一体成型;小兔子内置一个强力震动子弹,强震撩拨蜜豆。丰富爱爱情趣,轻易获取性高潮。



使用方法



使用前,请先顺时针转开遥控器后盖,如上图所示取出绝缘片,再将纽扣电池扣到位,合上后盖,逆时针转紧,即可使用。



使用方法1: 阳件套

- 1、长按子弹 ① 键1.5秒进入待机状态
- 2、点按 ② 键开启震动模式, 10种频率循环切换
- 3、长按子弹 ① 键1.5秒关机


使用方法2: 遥控器+阳件套

- 1、长按阳件套子弹 ① 键1.5秒进入待机状态
- 2、点按遥控器 ② 键开启震动模式
- 3、点按遥控器 ③ 键可切换震动频率, 10种频率循环切换
- 4、点按遥控器 ② 键可使子弹回到待机状态
- 5、长按阳件套子弹 ① 键1.5秒关机

充电

阳件套子弹充电

- 1、充电前请确保充电口和充电线插针处未沾水或润滑液
- 2、将USB充电线连接充电口并接电源充电, 充电时灯光闪烁, 充满后灯光长亮
- 3、请勿在充电状态下使用本产品
- 4、请注意充电时间不要超过24小时
- 5、请使用原装充电配件



遥控器更换电池

遥控器使用一粒CR2032 3V纽扣电池, 旋开后盖更换。更换完成, 旋转合上。



产品信息

材 质	液态硅胶+ABS
电 池	子弹内置可充电聚合物锂电池 遥控器使用一粒CR2032 3V纽扣电池
充电电压	5V
充电时间	约1小时
使用时间	充满电后可使用约1小时
工作模式	10频震动

清洁与储存

- 1、每次使用前后都请对本产品进行清洁。
- 2、清洁前, 请先取出内置于小兔子的子弹。
- 3、使用沐浴露、香皂或情趣用品专用消毒液清洁阳件套表面与内部, 然后用温水冲洗干净。
- 4、洗净后请用干爽柔软的毛巾轻轻拍干或待其自然风干。待阳件套内部完全干后, 再将子弹塞回小兔子内部。
- 5、收藏时请将产品装入包装盒内, 按原位置分别放置好以备下次使用。产品请于干爽无尘处保存。

安全

- 1、注意个人卫生健康, 请勿与他人共用此私密用品。
- 2、请选择水溶性润滑液与本产品配合使用。请勿使用含有硅油成分的润滑液或以按摩油、护手霜或身体乳作为润滑液。
- 3、如果您出现任何不适, 请立即停止使用。
- 4、如果产品出现任何损坏, 请立即停止使用。请勿尝试拆开或拆解产品。
- 5、如果USB充电线出现损坏, 请勿继续用此线充电。
- 6、请将本产品放在儿童和宠物接触不到的地方。


法律声明

本产品仅作为玩具使用。不适用于医疗用途或对身体有不利影响的任何用途。本产品皆适合一般健康正常的成年伴侣使用。如果您对自己身体状况有所怀疑, 请先咨询专业医师, 取得专业意见。使用产品前, 请确实清楚正确的使用方法, 再依个人的适应力谨慎使用。使用者需自行承担使用本产品的风险。因使用本产品所造成的任何伤害, 本公司将不承担任何责任。


USER MANUAL

PRODUCT OVERVIEW

This product is a vibrating penis sleeve developed for adult partners, which can be controlled by a remote. The product is made of liquid silicone, which is soft and close to human skin feel. Not only with integrated molding and realistic appearance, but also the rabbit part has an inserted powerful vibrating bullet which can provide intense clitoral stimulation. It can help you release your lustful desires and achieve orgasm easily.



USAGE



Before use, please turn the back cap of the remote clockwise first, and remove the tab as shown above. Then put the button cell battery in place, close the cap and turn it counterclockwise to lock. Now it's ready to use.



Usage 1: Penis Sleeve Only

1. Press and hold ① Button on bullet for 1.5 seconds to turn on, activating standby mode.
2. Press ② Button once to cycle through 10 vibration modes.
3. Press and hold ① Button on bullet for 1.5 seconds to turn off.


Usage 2: Penis Sleeve with Remote

1. Press and hold ① Button on bullet for 1.5 seconds to turn on, activating standby mode.
2. Press ② Button on remote once to turn on the vibration mode.
3. Press ③ Button on remote once to cycle through 10 vibrating modes.
4. Press ② Button on remote once can get back to standby mode.
5. Press and hold ① Button on bullet for 1.5 seconds to turn off.

CHARGING

Bullet Charging

1. Before charging, please completely dry the charging port and charging pin.
2. Plug charging pin into charging port and connect USB to power source. Light will flash while charging. Once fully charged, it will turn to solid light.
3. Please don't use the toy when charging.
4. Please don't charge over 24 hours.
5. Use the original charger provided for charging the toy.



Replacing Remote Battery

The remote requires one CR2032 3V button cell battery. Turn the back cap on, change the battery, and then close the cap and turn it locked.



SPECIFICATIONS

Material	Liquid silicone+ABS
Battery	Bullet: Built-in rechargeable polymer lithium battery Remote: Requires one CR2032 3V button cell battery
Charging Voltage	5V
Charging Time	Approx. 1 hour
Run Time	Approx. 1 hour after fully charged
Working Mode	10 vibration modes

CLEANING AND STORAGE

1. Always clean the toy before and after each use.
2. Before cleaning, please take out the bullet inserted in the rabbit.
3. Use body wash, mild soap or cleaner specialized for cleaning sex toys to clean the surface and inside of the penis sleeve. Then rinse with warm water.
4. After cleaning, please pat dry with dry and soft towel or allow to air dry. After the inside of the penis sleeve is completely dry, insert the bullet back into the rabbit.
5. When not in use, please put the toy into the packaging box and keep it in dry and dust-free place.

SAFETY

1. For personal health, do not share the toy with others.
2. Always use water-based lubricant with the toy. Do not use silicone-based lubricant, or use massaging oil, hand cream or body lotion as lubricant.
3. If you feel any discomfort, stop using immediately.
4. If any part of the toy is damaged, stop using immediately. Do not attempt to take apart or disassemble the toy.
5. Do not charge if the USB cord appears damaged.
6. Keep out of reach of children and pets.

LEGAL DISCLAIMER

This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse affect on any function of the body. In general, the toy is suitable for healthy adult partners to use. If you have doubts about your physical conditions, please consult your doctor or other health professionals first. Users should clearly know the right way to use and discreetly use it based on their own adaptability. Users use this product at their own risk. Our company assumes no responsibility for any adverse affect caused by this product.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.