







F Baggerfunktionen / Excavating Functions / Fonctions d'excavation / Funciones de la escavadora / Graaffuncties



G Licht / Lights / Lumière / Lucas / Verlichting





H Eigenen Modellnamen vergeben / Assign your own model name / Attribuer des noms de modèles propres / Asignar un nombre de modelo propio / Eigen modelnaam geven



I Maschinensound / Machine sound / Son de la machine / Ruido de motor / Motorgeluid






J Ketten nachspannen / Retension chains / Retendre les chaînes / Tensar las cadena / Kettingen spannen





SIKUCONTROL
#6740 / #6741 Bedienungsanleitung
Operating Instructions / Mode d'emploi
Instrucciones de uso / Gebruikshandleiding


A Batterien einlegen / Inserting the batteries / Placer les piles / Colocación de las pilas / Baterijen plaatsen





B Systemstart / System start / Démarrage du système / Inicio del sistema / Systeem starten

1 Download SIKU**CONTROL**APP:
Available on the Google play App Store

1.  **2.** 


2 

3  

4  

B Systemstart / System start / Démarrage du système / Inicio del sistema / Systeem starten

1 

2 

3  


4  

C Fahrfunktionen / Driving Functions / Fonctions de déplacement / Funciones de manejo / Rijfuncties

1   


2   

3   


4   

oder / or / ou / o / of

1.  **2.** 

3.   

D Oberwagen drehen / turn upper carriage / Tourner la partie supérieure / Girar la estructura superior / Bovenwagen draaien



E Oberwagen in Fahrtrichtung drehen / turn upper carriage into driving direction / Tourner la partie supérieure dans le sens de conduite / Colocar la estructura superior en el sentido de marcha / Bovenwagen in rijrichting draaien



CAUTION: Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with the RF exposure guidelines, place the product at least 20 cm from nearby persons.