

黑白印刷

装订翻页 (按照页码排版)

封面: 0.2MM (157G双铜)

内页: 0.07MM (105G双铜)

88.00 mm

130.00 mm

CREATE A
BETTER PRIVATE
CINEMA FOR YOU



Opening Remarks

Thank you very much for your support!
You can learn to use and operate on this projector by reading this manual.
This projector has powerfully features like compact, convenient etc. It is specifically designed for home, entertainment, business and other occasions.
The projector let you enjoy the fun of the big screen really anytime and anywhere, and you are also welcome to share your fun and opinions with us.
If you have any questions about this product, please contact our after-sales department. We are happy to service for you.

CATALOGUE

Cautions And Warnings	01-02
List Of Items	03-04
The Remote Control	05-06
Product Details	07-08
Installation And Debugging	09-11
Install The Equipment	12-14
The Software Settings	15-16
Media Player	17-18
Same screen	19-20
Clean And Maintain	21-22
Warranty Card	23-24

CAUTIONS AND WARNINGS

- Do not install the machine where directly blow by the air conditioner. The water combined or high temperature may cause machine failure.
- Make sure that there is no dust venting and the ventilation is not blocked. Do not place the projector in the air duct.
- Prevent glass or paper falling into the machine, and do not put any other objects into the machine.
- Do not touch the lens of the projector. Do not touch any part of the machine.
- When connecting the projector, please use soft padding to protect the projector during transportation. Please avoid the lens protection cover, do not touch with your hand.
- During or after the projector, any nearby fire or smoke will become serious damage to you.

NOTICE

Do not open the case. Please refer qualified professional maintenance personnel for repair and maintenance.

This mark warns there is an anticipated voltage in this unit. While this device electric shock can be fatal. Therefore, it is extremely dangerous to touch any parts inside the machine.


NOTICE

To prevent fire or electric shock, do not expose this machine to rain or moisture.


01

INTELLIGENT PROJECTOR

MADE IN CHINA




Do not install in poorly ventilated places. Do not install in hot or humid places.



Do not block the ventilation holes. Do not install in dusty or smoky places.

LIST OF ITEMS




Projector Remote Controller

Thank you very much for purchasing our products. Please check whether the physical products received are complete. If the products and accessories you receive are not complete, please contact the sales personnel in a timely manner. (For specific items, please refer to the actual package.)

02

INTELLIGENT PROJECTOR


MADE IN CHINA



User Manual Power Cord

Please use the original power adapter. Using a non-original adapter may result in overheating, fire, or damage to the product.

THE REMOTE CONTROL



04


INTELLIGENT PROJECTOR

MADE IN CHINA

Remote Control Description

- Power: To turn on/off the unit.
- Mute: To mute or unmute the projector speaker.
- Menu: To open the menu of applications or files.
- Volume: To increase/decrease the volume.
- Enter: Choose Click.
- Directional Keys: Use the up or down buttons to select OSD items, use the left and right buttons to make adjustments.
- Return: Back to previous menu or close the active window.
- Home Back to Homepage.
- Signal source switching: Switching signals or opening removable disks.
- Before focal length: Adjust the lens focus forward.
- After focal length: Adjust the lens focus backward.
- Tool: Open product settings function.


PRODUCT DETAILS



06

INTELLIGENT PROJECTOR


MADE IN CHINA



*Do not place objects within 20cm of the heat dissipation hole.

08

INSTALLATION AND DEBUGGING



Place it on the table. Place it on the floor.


Install on the ceiling.

09

INTELLIGENT PROJECTOR


MADE IN CHINA

Focus: When the projection image is blurry (as shown in the right figure), adjust the focus adjustment button on the remote control to move forward or backward to achieve satisfactory imaging results. If satisfactory clarity cannot be achieved through adjustment, please move the machine back and forth appropriately.



Adjustable Height Adjustable Angle

INSTALLATION AND DEBUGGING




Projection Size (inch)	Projection Distance (M)
32"	1.5 M
42"	2.0 M
52"	2.5 M
62"	3.0 M
72"	3.5 M

How To Power Off

- Press the ON/OFF button on the remote control or the power switch on the unit.
- Put the lens cap on and store the unit in a dry and cool place.


10

INSTALL THE EQUIPMENT



Signal direction USB drive

THE SOFTWARE SETTINGS




Notes: With the update of system version, there will be differences from the actual interface. Please refer to the displayed interfaces as final.

12

INTELLIGENT PROJECTOR


MADE IN CHINA



14

MEDIA PLAYER

You can play videos, music, or pictures from a storage device in the following ways.



USB disk insertion detected. Open file manager to view.

Click to skip automatic playback. Press to stop playback. Press to play. Press to pause. Press to full screen. Press to exit full screen. Press to return to previous menu. Press to return to home page.


(1) After the projector is turned on, insert a USB flash drive, and the system will detect the external device to detect, and a pop-up prompt will pop up. Select the type of the file you want to play, and press the "OK" button on the remote control panel to enter.

(2) Press the signal input button on the remote control and select USB device to turn it on.

15

SAME SCREEN

Connect the projector and phone to the same network, then open the HAPPYCast application and follow the prompts.



16

CLEAN AND MAINTAIN

Before cleaning, you must make sure that you have unplugged the power plug.

Do not use insecticides or other volatile chemicals on the projector or lens. Do not use rubber or vinyl products to touch the projector. This can damage or cause coating peeling off.

Within 12 months upon purchasing, faults that not caused by improper use of human factors shall be inspected by after-sales service center. free maintenance service shall be provided for you with valid purchase proof if it is determined as defect that caused by product quality itself.

Remember: for compliance could need the user's authority to operate the equipment. (Example: use only shielded interface cables when connecting to computer or peripheral devices.)

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

1. Clean the Projector. Wipe with a soft dry cotton cloth. Use a soft cloth dipped in a diluted neutral detergent to wipe it, then with a dry cloth. If you use chemical fiber cloth, please follow the precautions.

2. Dust cleaning of lens. Use the same method to clean the camera lens, use the professional hair dryer for the camera on the cleaning paper for the glass's lens. Be careful not to scratch the lens.

3. Dust cleaning at suction and outlet. The dust in the air inlet and outlet prevents ventilation, which will increase the internal temperature and cause malfunctions. Cleaning guidelines: at least clean once use every 10,000 hours.

Turn off the projector, disconnect the power. Clean the exterior with an electric vacuum cleaner and install a brush head adapter on the vacuum cleaner. Please be careful not to use a vacuum cleaner without an adapter or brush head.

17

Product Warranty Description

The after-sales service of projector is strictly based on the "Consumer Rights Protection Law of the People's Republic of China" and "Product Quality Law of the People's Republic of China".

Within 12 months upon purchasing, faults that not caused by improper use of human factors shall be inspected by after-sales service center. free maintenance service shall be provided for you with valid purchase proof if it is determined as defect that caused by product quality itself.

Remember: for compliance could need the user's authority to operate the equipment. (Example: use only shielded interface cables when connecting to computer or peripheral devices.)

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

1. Accessories such as Remote Controller, User manual, Power cord are not warranted.

2. Damage caused by self-disassembly or unauthorized maintenance, modification etc.

3. Damage that caused by artificial damage.

4. Period of warranty validity has expired.

After-Sale Service Card

Customer Name: _____

Customer ID: _____

Customer Tel: _____

Customer Email: _____

Fault Description (Please describe in detail for quick maintenance): _____

18

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.

2. Increase the separation between the equipment and receiver.

3. Use a different power outlet or circuit on a different line to which the receiver is connected.

4. Consult the equipment dealer or an experienced radio/TV technician for help.

Remember: for compliance could need the user's authority to operate the equipment. (Example: use only shielded interface cables when connecting to computer or peripheral devices.)

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

1. Accessories such as Remote Controller, User manual, Power cord are not warranted.

2. Damage caused by self-disassembly or unauthorized maintenance, modification etc.

3. Damage that caused by artificial damage.

4. Period of warranty validity has expired.

INTELLIGENT PROJECTOR

19