

Manual



Model Name:
FM16

FAQ:

1. How to confirm if the device is turned on?

Double click the device button. If the device emits sound, it indicates that the device is in working condition; If the device does not respond, it will be in a shutdown state. Press and hold the button for 5 seconds to turn it on.

1. How to replace the battery of the device?

1. Use a screwdriver to unscrew the device screws counterclockwise and pry open the housing from the gap.
2. Remove the old battery and insert the new button battery, ensuring that the positive pole is facing upwards.
3. Cover the back cover of the device, tighten the screws, and press and hold the power button for 5 seconds to complete the startup.

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users. Google, Android, Find Hub, and Fast Pair are trademarks of Google LLC.

WARNING

INGESTION HAZARD: This product contains a button cell or coin battery.
DEATH or serious injury can occur if ingested.
A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
KEEP new and used batteries **OUT OF REACH OF CHILDREN**.
Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



KEEP BATTERIES OUT OF REACH OF CHILDREN
Keep in original package until ready to use
Call a local poison control center for treatment information.
Australia: 13 11 26 Canada: 1-800-268-9017(Ontario), 1-800-567-8911(BC), 1800-463-5060 (Quebec) US: 800-498-8666. Verify suitable, emergency call numbers for your country.
Do not use if the compartment is not secure.
Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.

European Union-Disposal Information
The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities.
The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.


- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) Battery type: CR2032.
- e) Nominal battery voltage :3 V.
- f) Non-rechargeable batteries are not to be recharged.
- g) Do not force discharge, recharge, disassemble, heat above60 °C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- h) Ensure the batteries are installed correctly according to polarity (+ and -).
- i) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- j) Always completely secure the battery compartment.
- k) If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Risk of fire and burns. Do not recharge, disassemble, heat (-20°C +170 °C)or incinerate.

Operation Instructions

- 1.**Power on** : Long press the button for 5 seconds;
- 2.**Device status confirmation**: Double click the device button , the device beeps, it is on. If it does not beep, it is off.
3. **Pairing mode timeout, device enters pairing mode again**: when the device is on, if it is not paired within 10 minutes, the device will exit pairing mode, please click the device button once, the device beeps, then you can pair it with the Find My or Find Hub app.
4. **How to query serial number**: Press the button 6 times in a row within 2 seconds, the device beeps.
5. **Factory reset**: Press the device button 4 times quickly, the device will sound. Long press the device button, and the device will beep, do not release it, continue pressing until the second piece of music is played.
- 6.**Power off**: Press the device button 5 times in a row within 2 seconds, the device beeps, it is off.
- 7.After unbinding the device with your phone, please perform a factory

Note:

- If the device is powered on but, Find Hub cannot detect it, restore the device to factory settings. If it still cannot be found, restart your phone to locate the device.
- The device cannot be paired with iOS and Android™ at the same time.
- If you dismiss the Fast Pair™ pop up twice or frequently pair and unpair a tag, you might trigger the banning logic, which prevents unnecessary Fast Pair pop ups. To resolve this, you can either wait for five minutes for the Fast Pair pop up to be re-enabled or reboot your phone.
- Some of these steps are applicable only on devices running Android 12 and above.




FCC Caution. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules . These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Article 12
Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.
Article 14
The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

Product Overview



Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Regulatory Safety Information



WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN

Do NOT dispose of batteries in household trash. hours or death, due to chemical burns and Swallowing may lead to serious injury in as little as potential perforation of the oesophagus.
If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.
Rated voltage 3V
Rated current ~15mA
Immediately dispose of used batteries and keep away from children.


Even used batteries may cause severe injury or death.
Call a local poison control center for treatment information.

Safety Statement

ASTMU



Introduction



1 Open "Find My" App
2 Tap "Add Item"
3 Tap "Other Supported Item"
4 This Item is Linked To Your Apple ID
5 Finish

Mode D'emploi




1 Ouvrir "Localiser"
2 Cliquez sur "Ajouter un objet" dans Objets
3 Sélectionnez "Autre objet pris en charge"
4 Après avoir rempli les informations associez votre Apple ID
5 Appareil couplé avec succès

使用说明




1 打开 "查找"
2 物品中轻点 "添加物品"
3 选择 "其他支持的物品"
4 填写好信息后绑定Apple ID
5 完成绑定

Anweisungen



1 Klinken Sie "Wo ist?"
2 Klinken Sie "Objekt hinzufügen"
3 Klinken Sie "Anderes unterstütztes Objekt"
4 Das Objekt ist mit deiner Apple-ID verknüpft
5 Akzeptieren

Instrucciones de Uso



1 Abierto "Buscar"
2 Haga el "Añadir objeto" en Objetos
3 Seleccione "Otros objeto compatible"
4 Vincular Apple ID después de completar la información
5 El enlace del dispositivo es exitos

Istruzioni per l'uso



1 Aprire "Dov'è"
2 Clicca sull'articolo "Aggiungi oggetto"
3 Scegli "Aggiungi un altro oggetto"
4 Compila le informazioni e associa l'ID Apple
5 Completa il legame

Introduction



1 Open "Find Hub" App
2 "Connect"
3 Select "Agree and Continue"
4 Select "Open app"
5 Finish

Mode D'emploi



1 Ouvrir "Find Hub" App
2 "Connecter"
3 Select "Accepter et continuer"
4 Sélectionnez "Ouvrir l'appli"
5 Finition

使用说明



1 打开 "查找中心"
2 点击 "连接"
3 选择 "接受并继续"
4 选择 "打开应用"
5 完成绑定

Anweisungen



1 Öffnen App „Find Hub“
2 "Verbinden"
3 Wählen Sie „Ich stimme zu - weiter“
4 Wählen Sie „App öffnen“
5 Fertigstellen

Instrucciones de Uso



1 Abrir Aplicación "Find Hub"
2 Conectar
3 Seleccione "Aceptar y continuar"
4 Seleccione "Abrir app"
5 Acabado

Istruzioni per l'uso



1 Aprire App "Trova hub"
2 Connessione
3 Selezionare "Accetta e continua"
4 Selezionare "Apri app"
5 Finitura