



120mm

65mm



DH602D Ultra

DECT Wireless Headset





Diagram illustrating the controls and functions of the handset:

- Sunlight**: Power ON / In Call: Solid Red
- Touch Screen**
- Charge Headset**
- LED Bar**
- Function Button**: Press to open contacts
- Speaker Button: Answer / End (Speaker Mode)**
- Mute Button**
- Headset Button: Answer / End (Headset Mode)**
- Volume Button**
- Lift to answer, replace to end (Handset Mode)**




1. In the Box



2. Set Up the Base

Step 1: Connect the handset and the base.
Step 2: Plug in the power adapter.
Step 3: Adjust the stand angle back of the base.




3. Power ON/OFF



5. Use the Headset Without the DECT Base



6. Charge



7. Ear Cushions Replacement



Please scan the QR code to see the User Manual

Fanli Technology Co., Ltd
All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Fanli Technology Co., Ltd
Tel: +86-755-2640-2199 Email: sales@fanli.com Web: www.fanli.com
Fanli Technology Co., Ltd

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

For Base

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device must operate with a minimum distance of 20 cm between the radiator and user body.

For Headset

SAR tests are conducted using standard operating positions according standards with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

This model product has been tested and meets the RF exposure guidelines with the test distance 0mm for head. The highest SAR_{1g} value is 0.211 W/Kg for head. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with RF exposure requirements, and should be avoided