


Cordly for Echo Instructions

FRONT

Cordly
For Echo




Overview




Step 1

Stuff wall cord into storage cavity on bottom




Step 2

Plug in Echo speaker



Step 3

Place phone on wireless charging pad.



Use USB-C ports to charge accessories

80mm

BACK

Usage

Cordly shares available power from the Echo wall adapter between the Echo device, wireless charging pad, and USB-C accessory ports.

Charging may slow down when the Echo is playing loudly or when multiple devices are connected.

Your Echo device remains powered during normal use and charging output may adjust when multiple devices are connected at the sametime.

- Use USB-C ports for small accessories.
- Not intended for laptops or high-power devices.

Thanks for getting Cordly!

We built Cordly to make your everyday charging setup a little cleaner, smarter, and less tangled.

A special thank you offer:
Visit GoCordly.com and receive 15% off of any order for any product. Just enter HELLO15 during check out. Cheers!

Questions, ideas, or feedback? We'd love to hear from you. hello@gocordly.com

Cordly products are designed and serviced in the USA by Intuitive Concepts Inc.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.