

## 运动蓝牙音箱

### 使用说明书

感谢您选用迷你音箱，为了让您轻松体验产品，我们配备了内容详尽的使用说明，您从中可以获得有关产品的介绍，使用方法等方面的知识，在您使用本机前请先仔细阅读说明书，如果有印刷错误或翻译失误望广大用户谅解。

#### 一、注意事项

为了使用者正确使用播放器，确保播放器性能良好，请认真阅读并遵守：

- 1.切勿严重撞击主机。
- 2.切勿接触苯、稀释剂等化学药品。
- 3.请不要靠近强磁场、电场。
- 4.请避开直射光线或发热器具。
- 5.切勿自行拆卸、修理、改造。
- 6.骑车、驾驶汽车及摩托车时，请勿使用播放器及耳机，以免造成危险。
- 7.切勿以较大音量收听，以免对听力造成不良影响。
- 8.废弃包装、电池、旧电子产品，请分类妥善处理。

#### 二、功能特点

[蓝牙音频] Bluetooth 5.0，最大接收距离10 米。

[蓝牙通话] 语音清晰、无回声。

[MP3 播放] 直接播放TF 卡内存及U盘放的MP3 文件。

[FM 收音机] FM 数字立体声收音机，电台记忆播放。

[音频输入] 立体声音频输入接口，轻松连接电脑、数码音乐播放器、手机等音源设备。

[断点记忆] 自动记忆上次退出时的曲目，音量大小。

[内置电池] 内置可充电锂电池，环保，节能，实用。

[AUX声卡] 连接电脑，播放电脑音频文件，可控制电脑音量大小。

三、播放音乐操作 本机开机时自动检测识别外接设备，开机后进入 蓝牙模式，插入TF 卡、U盘或音频线自动识别播放，后者优先原则，也可自行切换播放模式；

#### 四、产品的按键、插孔功能定义(以实物为准)

- 1.[  ]：电源开关；关机状态下，长按开。开机状态下，长按关。开机状态下，短按模式切换。
- 2.[]：播放/暂停/接听电话/挂断电话/全自动搜台。 短按：TF、U盘和蓝牙模式为播放/暂停,FM模式下消音；来电时短按接电话，通话时短按挂机。 长按：开机状态下，TWS模式。FM 模式为全自动搜台。
- 3.[<]：音量调节小/上一曲/上一个电台。短按：音量调小；长按：上一曲。
- 4.[>]：音量调节大/下一曲/下一个电台。 短按：音量增大； 长按：下一曲。
- 5.[MICRO-USB]：充电接口/FM 天线。 电源充电插孔，可使用本机配送的专用USB 电源线，接驳电脑的USB 接口或DC 5V充电器进行充电。 FM 收音模式，可使用本机配送的专用USB 电源线做外置天线，收台灵敏度更佳。

五、指示灯介绍 红色指示灯：充电指示灯，充电中红灯亮，充满电红灯灭。 蓝色指示灯：TF，AUX、蓝牙、FM 播放模式指示灯；低电关机指示灯。

#### 六、蓝牙连接方法（可选机型，以实物为准）：

- 1、开机或按模式键切换进入蓝牙模式，LED 指示灯快闪。
- 2、打开移动设备（手机、电脑等）的蓝牙功能，搜索蓝牙设备。
- 3、手动点击，设备自动配对、连接，（一般情况下不用输入密码，特殊机型提示输出密码，输入 “0000”即可）
- 4、已配对成功的设备，下次开机会自动连接。 备注：进入蓝牙模式10秒钟内，蓝牙会自动寻找设备并配对连接，10 秒后要通过手动连接。

#### 七、收音机功能使用方法：

- 1、短按[]键切换模式，进入FM 模式。
- 2、搜台：短按[]键开始自动搜台，搜台时指示灯闪烁，搜台完毕后自动记忆保存电台。
- 3、记忆选台：自动搜台完毕后，长按[<]或[>]键可选择上一个电台或下一个电台；
- 4、音量调节：短按[<]键减小音量，短按[>]键增大音量。 备注：使用本机配送的专用USB 电源线做外置天线，收台灵敏度佳。

八、充电使用方法：将电源线一端插入本机的[MICRO-USB]插口，另一端USB 插入电脑的USB 接口，或连接标准5V 500mA的充电接口中，充电中“红色灯”亮，充满后“红色灯”灭。 本机内置过充电保护电路，可长时间连接电脑或充电器使用，约4 小时可充满电池；电池每次的续航时间会因使用时间音量大小而不同。

九、电池低电 当电量出现低电时，系统会自动关机，此时请及时充电；如果长时间不使用本机，至少每月充电一次，可以保护电池延长电池寿命。

#### 十、疑难解答

- 1、Q：开机就自动关机？ A：电池电量不足，请及时充电，建议充电两小时后使用。
- 2、Q：播放蓝灯一直在快闪后自动关机或重启？ A：电池电量不足，请及时充电，建议充电两小时后使用。
- 3、Q：无法充电？ A：请使用本机配送的充电线，并确定被接入的USB 接口电压正常。
- 4、Q：充电红灯不亮或红灯很暗？ A：正常。如果电池已充满或电压块满时，充电红灯会不亮或很暗，总之电池电量越低，充电时红灯越亮。
- 5、Q：喇叭无声音？ A：确定在TF/蓝牙/FM/AUX 模式下，在播放状态，并调整至适当的音量。
- 6、Q：AUX 无声音？ A：1、请使用本机配送音频线，并选择正确的音频输出接口。
- 7、Q：蓝牙不会自动连接？ A：1、只有配对过的设备，才会自动连接。 2、部分手机如果音箱进入蓝牙10 秒以后才打开蓝牙设备，音箱不会自动连接。 3、音箱关机后重启。
- 8、Q：蓝牙无声音？ A：1、请确认蓝牙是否已连接成功。 2、蓝牙设备的音量是否已打开。 3、音箱关机后重启。
- 9、Q：按键无功能或功能错？ A：关机后再开机。

#### 十二、技术规格

输出功率： 5W\*2                      工作电压： 3.7V                      频率响应： 100Hz-18KHz  
信噪比： ≥80dBA                      失真度： < 1%                      音频： 蓝牙MP3、蓝牙通话、TF卡MP3、U盘MP3、AUX、FM支持MP3：比特率，32Kbps-320Kbps    扬声器单元：52mm\*2，4Ω                      输入电源： DC 5V  
调节/控制方式： 按键                      输入灵敏度：450±50mV                      重量： 约433g  
尺寸： 180x81x75mm

十三、包装附件 音箱1台 充电线1条

## Sport Bluetooth speakers

### Instruction Manual

Thank you for choosing mini speaker. In order to let you experience the product easily, we are equipped with detailed instructions. You can get the knowledge of product introduction, usage method and so on. Please read the instructions carefully before you use this machine.

#### Notes

\* For users to use the player correctly, please read carefully and follow:

1. do not seriously impact the mainframe.
2. Do not contact benzene, diluents or other chemicals.
- 3.Please don't approach the strong magnetic field, electric field.
- 4.Please avoid direct light or heating apparatus.
5. do not disassemble, repair or modify yourself.
6. Do not use players and headphones when cycling, driving cars and motorcycles to avoid danger.
7. do not listen at a higher volume to avoid adverse effects on listening.
- 8.Waste packaging, batteries, old electronic products, please sort properly.

#### \*Functional characteristics

[Bluetooth Audio] Bluetooth 5.0, maximum receiving distance of 10 m.

[Bluetooth call] Clear voice, no echo.

[MP3 play] directly plays TF card memory and MP3 files placed on the disk.

[FM radio] FM digital stereo radio, radio memory play.

[AUX ] stereo audio input interface, easy to connect computer, digital music player, mobile phone and other audio source equipment.

[Breakpoint Memory] Automatically remembers the track at the last exit, volume.

[Built-in ] rechargeable lithium battery, environmental protection, energy saving, practical.

[AUX sound card] connect computer, play computer audiofile, can control computer volume.

Play music operation when the machine automatically detect and identify the external device, after boot into Bluetooth mode, insert TF card, U disk or audio line automatic recognition play, the latter priority principle, can also switch play mode;

Product key,jack function definition (subject to physical)

[  ]: power switch; shutdown, long press on. On the boot state, long press off. In boot state, switch by mode.

[  ]: play / pause / answer / hang up / full automatic search. Short press: TF、U disk and Bluetooth mode for play / pause, mute in FM mode; call short press to answer the phone, call short press hang up. Long press: boot state,TWS mode. FM mode is automatic search platform.

[<]: volume adjustment is low / last / last station. Short press: volume down; long press: last song.

[>]: volume adjustment / next song / next station. Short press: volume increase; long press: next song.

[MICRO-USB]: charging interface/ FM antenna. Power charging Jack, can use the special USB power cord distributed by this machine, connect the USB interface of the computer or charge DC 5V charger. FM radio mode, the special USB power cord can be used as external antenna, and the sensitivity of receiving station is better.

The indicator light introduces the red indicator light: charging indicator light, charging red light, full red light out. blue indicator: TF,AUX、 bluetooth, FM play mode indicator; low power shutdown indicator.

Bluetooth connection method (optional model, subject to physical object):

Boot or press mode key to switch into Bluetooth mode, LED indicator flash.

Turn on the Bluetooth function of mobile devices (mobile phones, computers, etc.) and search for Bluetooth devices.

Manual click, the device automatically paired, connected,(generally do not need to enter password, special model prompt output password, input "0000" can)

Paired successful devices, the next opportunity to automatically connect. Note: within 10 seconds of entering Bluetooth mode, Bluetooth will automatically find the device and pair the connection. After 10 seconds, it will be connected manually.

How to use radio function:

Short press [  ] key to switch mode and enter FM mode.

Search: press the [  ] button to start the automatic search, the indicator lights flicker, after the search automatically memory save station.

Memory station: after automatic search, press [<] or [>] to select the previous station or the next station;

Volume adjustment: Short press [<] key to reduce the volume, short press [>] key to increase the volume. Note: use the special USB power cord distributed by this machine to make external antenna, the sensitivity of receiving station is good.

Use method of charging: one end of the power cord is inserted into the [MICRO-USB] socket of the machine, the other end USB inserted into the USB interface of the computer, or connected to the charging interface of standard 5 V 500mA. The "red light" in the charging is on and the "red light" is extinguished after filling. This machine has built-in overcharge protection circuit, can be connected to the computer or charger for a long time, about 4 hours can be filled with batteries; the battery life will vary according to the volume of service time.

When the power of the battery is low, the system will automatically shutdown, please charge in time at this time; if you do not use the machine for a long time, charge at least once a month, can protect the battery to prolong the battery life. 's

X . Trou bleshooting

1、Q： turns off on ?A： battery power is insufficient , please charge in time , it is recommended to use after two hours .

The 2、Q： light automatically turns off or re starts after the flash - up ?A： battery power is insufficient , please charge in time , it is recommended to use after two hours .

The 3、Q： cannot charge ?A： Please use the delivered charging line and determine that the voltage of USB interface is normal .

4、Q： charging red light or red light is dark ?The A： is normal .If the battery is full or the voltage block is full , the charging red light is not bright or very dark , in short , the lower the battery power , the brighter the red light when charging .

5、Q： horn without sound ?A： determinesin TF/ Bluetooth / FM/AUX mode and adjusts to the appropriate volume .

6、Q： AUX No sound ?A： 1、 Please distribute the native audio line and select the correct audio output interface .

The 7、Q： Bluetooth will not connect automatically ?The A： 1、 connects automatically only with paired devices . 2、 phones if the speakers enter the Bluetooth 10 seconds after the Bluetooth device , the speakers will not automatically connect .Rest art after 3、 speakers is off .

8、Q： Bluetooth No free ?A： 1、 Please confirm that the Bluetooth is successfully connected .Is the volume of the 2、 Bluetooth device turned on .Rest art after 3、 speakers is off .

9、Q： key is functional or wrong ?The A： turns on after the shutdown .

#### XII. Technical specifications

Output power :5 W\*2                      operating voltage :3.7 V                      frequency response :100 Hz-18KHz  
Signal-to-noise ratio (SNR):≥80 dBA    distortion :<1%                      audio: Bluetooth MP3、 Bluetooth calls, TF card MP3、U disk                      support MP3： bitrate, 32Kbps-32 0 Kbps                      speaker unit :52 mm\*2, 4Ω                      Input Power: DC 5V  
Type of adjustment/control: Key Input Sensitivity :450±50 mV                      Weight: about 433 g  
Size :180 x81x75mm  
Packing accessories speaker 1                      charging line 1

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment RF warning for Mobile device:  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.  
FCC-ID: 2BD4X-G06