



User operation manual

USER OPERATION MANUAL

Table of contents

1. Product feature introduction	2
2. Notes to users	3
3. Main interface	5
4. navigation	7
5. Bluetooth	8
6. Set up	12
7. Carplay connection	15
9. Multimedia	16
10. System upgrade	18

Product feature introduction

- ◎Support analog HD reversing/360
- ◎High-fidelity low-noise DSP with 32-segment EQ, surround sound
- ◎Built-in GPS/WIFI/Bluetooth/audio and video processing
- ◎Support original car system
- ◎Support CarPlay/mobile phone interconnection
- ◎GPS/Beidou/GLONASS dual-mode navigation
- ◎Support Bluetooth 4.0 and WIFI 802.11b/g/n connection, support 5G WIFI
- ◎Support 1080P multimedia video playback, lossless music playback

Notes to users

Thank you for choosing to use our car audio-visual navigation system, so that you can fully enjoy the various new features of this machine.

1.1. This machine is used in cars with a negative grounding battery system with a 12V voltage. Please do not install this machine directly on a truck or bus with a 24V battery.

2. Please do not install this machine in a place that hinders the driver's vision or affects the driving operation. In order to avoid traffic accidents caused by distracting the driver's attention, the driver should not operate this machine or watch the playback screen while driving. If you do need to operate, please park your car in a safe place.

3. Do not put this machine in an overly humid environment or in water, otherwise it will cause electrical short circuits and cause fire or other damage.

4. Please do not replace the fuse device on the power connector attached to this machine without authorization. Replacing it with a mismatched fuse will lose the protection of the overcurrent of the machine, and may burn the machine or even cause a fire. If there is no sound, there is no image. There is water or small objects leaking into the machine, or smoke appears. When there is an odor, please stop using this machine immediately and send it to the purchase office or after-sales service center for processing. If you continue to use it, there may be a fire or other accidents.

5. The driver should adjust the volume to the appropriate level to prevent excessive noise from interfering with the driver's ability to listen to messages outside the car.

6. When using this machine, you should follow the instructions. Damage caused by illegal operation is not covered by the warranty.

Note: The company's products have been continuously improved and updated, and are subject to change without notice.

Main interface

The main interface can be clicked to enter common functions such as navigation, settings, etc.

Click on the function item of the main interface to enter the corresponding function interface.




Click the icon “” to return to the main interface.

Navigation

This system supports a variety of navigation software, customers can click Settings → General Settings → Navigation application settings → select navigation application

In the navigation interface, you can slide down at the top to bring up the status bar, through the status bar you can exit the navigation and return to the main interface.



Bluetooth

Bluetooth is a radio technology that supports short-range communication. In addition to the function of a Bluetooth headset, it also has the feature of automatic connection. Automatic connection refers to the built-in Bluetooth and the mobile phone will automatically connect to the mobile phone and be in standby state after the system is turned on.

● Enter/exit

Click the Bluetooth icon on the main interface to enter the Bluetooth interface.

Click  return to the main interface.

Click  Exit Bluetooth.



Click  to enter the Bluetooth settings, and you can set the Bluetooth name, pairing password, automatic answering, etc. on the Bluetooth settings page.

● Dial number

Click  enter the dial-up interface.

You can make a call directly from your mobile phone, make a call through the number button on the screen, press the number button on the screen to enter the number, and the number field displays the entered number. If you enter it incorrectly, you can click “” to delete it. After entering the number, click  to make a call.

Click the  icon to hang up the phone.




● Call interface

When an external call enters, except in the reversing state, the system will automatically switch to the Bluetooth function interface in any other mode to realize the hands-free function, which can directly answer the call. Touch the  icon under the answer interface to hang up directly.

Bluetooth

● Call history

Click  to enter the call log interface and display all Bluetooth call logs.



● Bluetooth music

Click  to enter Bluetooth music, through this function you can control and listen to the music played in the phone.

● Phone book

Click  to enter the phone book, click  to download, and click  to search for designated contacts.




Set up

Click the settings icon on the homepage to enter the settings interface.

You can set: wireless settings, equipment settings, general settings, factory settings, and system settings.

● Vehicle settings

Click  on the application interface to set the original car screen parameter type, reversing mode, etc.



● About this machine

Click “About this machine” in the settings interface to enter the version interface and view the version information.





● Language and input method

In the settings interface, click  → Language and input method → language, and click Add language, where you can add the corresponding language selection.


● Date and time

In the settings interface, click  to enter the interface → Date and time → Automatically determine the date and time → When you click close, manually set the time and date.



Carplay connection

Wireless connection: First connect to Bluetooth, click Car link to enter the Carplay interface, Car link will automatically connect, and the connection will successfully enter the Carplay interface.





Multimedia

● Music

Click “Music” in the main menu to enter the music interface, you can select the up and down songs in the music and pause playback and other functions.


● Video

Click “Video” on the main interface to enter the video playback interface, you can select the up and down songs in the video and pause playback and other functions.




AUX

Click “AUX” on the main interface to enter the external audio input interface.



- **System upgrade**

Copy the upgrade software to an empty U disk, and the system will automatically upgrade; after the upgrade is complete, the system prompts: The upgrade has been completed, please remove the device.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.