Warning:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

ENGLISH / FRANCAIS / DEUTSCH/ ESPANOL / ITALIANO

Ashdown

THE ELIZABETH LINE

ELIZA

WWW.ASHDOWNMUSIC.COM

USER MANUAL

THANK YOU

Thank you for purchasing your Ashdown Engineering amplifier and welcome to the family! We really think you've made the right choice and know that the amplifier will give you years of great tone and service.
If you have any questions about your amplifier please don't hesitate to get in touch with our friendly and helpful customer service team. We can't promise we'll help you get the most out of your new amplifier, but we'll certainly try our best!
Happiest and very famous customers

REGISTER ONLINE

Please register the product online so we can make sure we give you years of customer support through our friendly in-house service centre.
Head online and register to get the most out of your product:
http://www.ashdownmusic.com/pages/register-your-product

ASHDOWN ENGINEERING – ELIZA

USER GUIDE

INTRODUCTION

Thank you for choosing a unique amp that sits with some of the biggest and most famous brands of our time. At the home of the Ashdown Bass Amp, our factory has received multiple 'Rock 'n Roll' Fitness Stamping Machines since 1977. Ashdown Engineering was founded in 2004 and has since grown to be one of the UK's largest independent brands and a true success story.

The Ashdown story started in 1977 when Mark Ashdown built his very first amp in the company founder Mark Ashdown's family previously home to engravings. Mark has always been a bass player, and after a few years playing in bands, he found that he was obviously somewhat of a bass amp pioneer. His world was that the power in the amp was the most important thing, and he was determined to make sure that in terms of bass tone he helped to establish Ashdown as the world's leading bass amplifier manufacturer.

Now, massive fan base stretches to headstock and coffee that of Ashdown based products, covering a far broader spectrum of frequencies, tones but always delivering the ultimate in bass tone.

The Ashdown Elizabeth Line encompasses all of what we have learnt about sound, from working with some of the worlds most admirable musicians and bands, to the way we have developed our own factory and our own products.

Fastening our backboard, it's better still stands to reassess the output of the audio taking a beautiful logo the device. Enjoy high quality audio from the comfort of your home, studio or on the road. Please read this manual carefully, LIGHT through the Incorporated ADS chip all sound or Sound.

ASHDOWN ENGINEERING – ELIZA

USER GUIDE

POWER CORD CONNECTION

Make sure the power switch on the back panel of the amplifier is in the off position.
Before connecting the power cord to a power outlet, verify that the unit is configured for the voltage in your area and that the power switch is in the off position. Connect the power cord to the unit first, then plug the power cord into the outlet.
To disconnect power to the unit, switch off the power switch, then unplug the power cord from the outlet.

POWERING ON/OFF

Before turning the unit on, make sure that the master switch on the back panel of the amplifier is in the ON position.
Press the front panel power button and the front panel of the speaker should illuminate. If it does not, it is possible that on/off button of the chosen unit has failed completely. Please contact your local dealer or Ashdown Engineering for further assistance.

SELECT AUDIO SOURCE

Select the audio source you wish to connect or send to, or connect to the speaker.
AUX - Stereo mini 3.5mm
OPTICAL - High-bandwidth optical interface

ASHDOWN ENGINEERING – ELIZA

USER GUIDE

All rights reserved. Ashdown Engineering Ltd.

CONNECTING TO A PHONE, TABLET OR COMPUTER

1. Check your phone, tablet or computer is fully switched on and that all of its audio settings are correct.
2. Connect the 3.5mm cable to the AUX input on the back panel of the amplifier.
3. Connect the other end of the 3.5mm cable to the headphone socket on your phone, tablet or computer.
4. Set the volume on your phone, tablet or computer to around 50%.
5. Turn on the amplifier and set the volume to around 50%.
6. Start playing some audio on your phone, tablet or computer.
7. Adjust the volume on your phone, tablet or computer and the amplifier to your desired level.

CONNECTING TO A TURNTABLE

1. Check your turntable is fully switched on and that all of its settings are correct.
2. Connect the turntable's phono output to the phono input on the back panel of the amplifier.
3. Connect the turntable's earth wire to the earth terminal on the back panel of the amplifier.
4. Set the volume on your turntable to around 50%.
5. Turn on the amplifier and set the volume to around 50%.
6. Start playing some audio on your turntable.
7. Adjust the volume on your turntable and amplifier to your desired level.

CONNECTING TO A CD PLAYER

1. Check your CD player is fully switched on and that all of its settings are correct.
2. Connect the 3.5mm cable to the AUX input on the back panel of the amplifier.
3. Connect the other end of the 3.5mm cable to the headphone socket on your CD player.
4. Set the volume on your CD player to around 50%.
5. Turn on the amplifier and set the volume to around 50%.
6. Start playing some audio on your CD player.
7. Adjust the volume on your CD player and amplifier to your desired level.

CONNECTING TO A TV (OPTICAL)

1. Check your TV is fully switched on and that all of its settings are correct.
2. Connect the optical cable to the optical output on the back panel of the amplifier.
3. Connect the other end of the optical cable to the optical input on your TV.
4. Set the volume on your TV to around 50%.
5. Turn on the amplifier and set the volume to around 50%.
6. Start playing some audio on your TV.
7. Adjust the volume on your TV and amplifier to your desired level.

CONNECTING TO A TV (HDMI ARC)

1. Check your TV is fully switched on and that all of its settings are correct.
2. Connect the HDMI cable to the HDMI ARC output on the back panel of the amplifier.
3. Connect the other end of the HDMI cable to the HDMI ARC input on your TV.
4. Set the volume on your TV to around 50%.
5. Turn on the amplifier and set the volume to around 50%.
6. Start playing some audio on your TV.
7. Adjust the volume on your TV and amplifier to your desired level.

SETTING UP BLUETOOTH

1. Make sure the amplifier is switched on.
2. Press the Bluetooth button on the front panel of the amplifier or the remote control.
3. The Bluetooth LED will flash blue and red.
4. Search for Bluetooth devices on your phone, tablet or computer.
5. Select "ELIZA" from the list of available devices.
6. Once connected, the Bluetooth LED will stay solid blue.
7. Play some audio on your phone, tablet or computer.
8. Adjust the volume on your phone, tablet or computer and the amplifier to your desired level.

TO DISCONNECT A BLUETOOTH DEVICE

1. Press the Bluetooth button on the front panel of the amplifier or the remote control.
2. The Bluetooth LED will flash blue and red.
3. Disconnect the device from the amplifier on your phone, tablet or computer.
4. The Bluetooth LED will stop flashing and turn off.

TO CONNECT A NEW BLUETOOTH DEVICE

1. Press and hold the Bluetooth button on the front panel of the amplifier or the remote control for 5 seconds.
2. The Bluetooth LED will flash blue and red rapidly.
3. Search for Bluetooth devices on your phone, tablet or computer.
4. Select "ELIZA" from the list of available devices.
5. Once connected, the Bluetooth LED will stay solid blue.

TO CLEAR ALL BLUETOOTH PAIRINGS

1. Press and hold the Bluetooth button on the front panel of the amplifier or the remote control for 10 seconds.
2. The Bluetooth LED will flash blue and red rapidly.
3. All Bluetooth pairings have been cleared.

SETTING UP WI-FI

1. Make sure the amplifier is switched on.
2. Press the Wi-Fi button on the front panel of the amplifier or the remote control.
3. The Wi-Fi LED will flash blue and red.
4. Search for Wi-Fi networks on your phone, tablet or computer.
5. Select "ELIZA" from the list of available networks.
6. Once connected, the Wi-Fi LED will stay solid blue.

TO CLEAR ALL WI-FI PAIRINGS

1. Press and hold the Wi-Fi button on the front panel of the amplifier or the remote control for 10 seconds.
2. The Wi-Fi LED will flash blue and red rapidly.
3. All Wi-Fi pairings have been cleared.

SETTING UP AIRPLAY

1. Make sure the amplifier is switched on.
2. Press the AirPlay button on the front panel of the amplifier or the remote control.
3. The AirPlay LED will flash blue and red.
4. Search for AirPlay devices on your phone, tablet or computer.
5. Select "ELIZA" from the list of available devices.
6. Once connected, the AirPlay LED will stay solid blue.

SETTING UP SPOTIFY CONNECT

1. Make sure the amplifier is switched on.
2. Press the Spotify Connect button on the front panel of the amplifier or the remote control.
3. The Spotify Connect LED will flash blue and red.
4. Search for Spotify Connect devices on your phone, tablet or computer.
5. Select "ELIZA" from the list of available devices.
6. Once connected, the Spotify Connect LED will stay solid blue.

SETTING UP DAB

1. Make sure the amplifier is switched on.
2. Press the DAB button on the front panel of the amplifier or the remote control.
3. The DAB LED will flash blue and red.
4. Search for DAB stations on your phone, tablet or computer.
5. Select "ELIZA" from the list of available stations.
6. Once connected, the DAB LED will stay solid blue.

SETTING UP FM

1. Make sure the amplifier is switched on.
2. Press the FM button on the front panel of the amplifier or the remote control.
3. The FM LED will flash blue and red.
4. Search for FM stations on your phone, tablet or computer.
5. Select "ELIZA" from the list of available stations.
6. Once connected, the FM LED will stay solid blue.

SETTING UP USB

1. Make sure the amplifier is switched on.
2. Press the USB button on the front panel of the amplifier or the remote control.
3. The USB LED will flash blue and red.
4. Search for USB devices on your phone, tablet or computer.
5. Select "ELIZA" from the list of available devices.
6. Once connected, the USB LED will stay solid blue.

SETTING UP BLUETOOTH

1. Make sure the amplifier is switched on.
2. Press the Bluetooth button on the front panel of the amplifier or the remote control.
3. The Bluetooth LED will flash blue and red.
4. Search for Bluetooth devices on your phone, tablet or computer.
5. Select "ELIZA" from the list of available devices.
6