



SELFIE STICK

USER MANUAL

At A Glance



FUNCTION KEYS



Quick Steps for Remote


Step 1: On the mobile phone, click Settings> Bluetooth, And turn on the Bluetooth of the phone.
 Step 2: Press and hold the remote control switch for 2 seconds to start the machine
 Step 3: When the mobile phone searches for "SELFIE" Bluetooth device, click and select Pair.
 Step 4: Open the camera and short video APP, and press The remote control function key can be used on the mobile phone Operation of.
 Step 5: Long press the key of the remote control for 2 seconds.

Remote Battery

Push the back cover in the direction of the arrow as shown in the figure to change Install the back cover after the battery.



Fill light (optional)



Press and hold for 3 seconds to start the machine
 Battery model of fill light: 402030 (200 mA)

Troubleshooting:

1. Bluetooth remote control cannot be switched on Replace the battery.
2. Bluetooth cannot be connected or works normally Remove the Bluetooth pairing on the phone and restart the Bluetooth remote control Re pair and connect after the device.

Attention

1. Do not store the product in a low temperature and humid environment.
2. Do not place the product in the high temperature ring such as sun exposure and fire baking Environment.
3. Do not use the device in places where its use is restricted. Avoid violating public order.
4. When replacing the battery, place the positive pole of the battery outward It is prohibited to connect the positive and negative electrodes in reverse.
5. This product contains batteries, please put it in infants and children Keep out of reach to prevent children from swallowing by mistake.

Made in China



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.