


WEPHONE

GK-210



1. Multi-functional touch keys

2. Earphone indicator

3. USB charging port

4. Main voice hole

5. Charging pin

6. Microphone

Attention

To protect the battery life of the charging case and headphones, please charge the battery case and headphones before first use.

TWS pair

First pairing method:

1. Open the lid and take out the earphones. The left and right earphones will pair.
2. Open the Bluetooth of the mobile phone, refresh the list of Bluetooth devices of the mobile phone, click "GK-210" to fill in the name of the model, and then the name will show that the connection has been completed.

* If the connection fails, please repeat the above steps and try again. If the headphones have been removed and do not start automatically, please put them back into the charging case and remove them from the compartment before trying again, or try again after charging.

Note: After the first successful pairing, you only need to open the Bluetooth of your phone and take out the headset to automatically reconnect (supporting both ears or one ear).

Switch the device pairing method:

1. Turn off the Bluetooth of the A phone, and the headset automatically disconnects into pairing mode.
2. Refresh the list of Bluetooth devices on B phone, click to pair the model of this phone, and complete the pairing.

* Does not support connecting two phones at the same time. The next time you boot up, it will return to the phone paired last time by default.

Restore factory Settings:(This method is used in any abnormal situation during use, including but not limited to failure to connect normally, single ear connection, etc.)

1. If you have connected a mobile phone, find the model of your phone in the list of Bluetooth devices on your phone, click to enter the Settings, and select ignore or cancel pairing.
2. Repeat the first pairing method connection.

Introduction to Product Function Operation

1. Power on: Open the charging case, take it out of the compartment, and it will automatically turn on.
2. Shut down: Put the headphones into the charging box.
3. Connect to mobile phone: After turning on the headset, open the Bluetooth of the mobile phone and search for the corresponding device name: GK-210.
4. Pause/Play: Click the Touch button on any headset.
5. Previous track: When music , click L/R three times.
6. Next track: When music , click L/R two times.
7. Answer: When incoming call , Tap the Touch button on any headset to answer a call.
8. Hang up: When phone talking , Double-click the Touch button on any headset to hang up the call.
9. Reject call: When incoming call , Long press any headset Touch button for 2 seconds to reject incoming calls.
10. SIRI(Voice Assistant): Long press any headset Touch button for 2 seconds.

Product parameters

Model name: GK-210

Bluetooth version: BT6.0

Charging time: About 1-2 hour

Communication distance: 10 meters (in barrier-free environment)

Battery type: polymer lithium ion battery

Earphone battery capacity: 3.7V 30mAh

Charging case battery capacity: 3.7V 250mAh

Charging input: 5V-300mA

Supported protocols: HFP HSP A2DP AVRCP

Play duration: 4.5 hours

Bluetooth working frequency: 2.402GHz-2.480GHz

Maximum transmission power: 8dBm

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
- FCC ID:2BD7C-GK-210