

Pop-Up Pneumatic Outlet User Manual

Chapter 5

Relevant information			
User name		Common telephone	
Mailing address			
Product model		Product number	
Purchase shop		Purchase date	
Service location		Invoice number	
Service record			
Service date		Fault detail	
Processing details			
Service unit name			
Service personnel telephone number			
Service personnel signature			

NOTE: If there are any issues with the use or quality of the product, please contact us in a timely manner. We guarantee to solve the problem for you as soon as possible.

Pop-Up Pneumatic Outlet User Manual

Chapter 6

 Remind

In order to ensure safe use and avoid injury and property loss to you and others, please observe the following safety precautions. Misuse without safety warning may lead to accidents.

 heed

This product does not consider the following situations :
Trial use of appliances by unattended children and disabled people.
Children playing with instruments.



Do not soak in liquid Need professionals

FCC Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

Pop-Up Pneumatic Outlet User Manual

BE400Series



Product features : 4 AC outlets 1 USB-A wireless charging. 1 USB-C



Thanks for choosing Pop-Up Pneumatic Outlet. Please read manual before use and keep for future reference

Pop-Up Pneumatic Outlet User Manual

Chapter 1: Introduction to Pop-Up Pneumatic Outlet


- Simple installation, just pop it open and it's good to go.
- Wireless charging kicks in automatically when powered on, no need to start it up, and it charges fast at 15W.(Excluding BE700A)
- The device features an easy-to-clean acrylic panel and brushed aluminum shell, so keeping it tidy is a breeze.
- Its waterproof design ensures that splashes won't cause any damage, whether it's open or closed.
- The device supports USB-C 20W fast charging, so you can quickly juice up your device and get back to your day.

Important: Do not immerse in water or use outside.

1.1、Productcontent



Instructions* 1



Install fasteners*1




Pop-Up Pneumatic Outlet * 1


Pop-Up Pneumatic Outlet User Manual

1.2、 Installation and use of products

Installation




A, Drill 3.9-inch (100mm) diameter holes into the table top using a drill.



B, Unscrew the installation fasteners, put the Pop-Up Pneumatic Outlet into the hole, and tighten the fasteners.

Pop-Up Pneumatic Outlet User Manual



C, Insert the power cord into the terminal connector at the bottom of the Pop-Up Pneumatic Outlet to power it on, and press down on the socket to activate the pop-up mechanism.

Chapter 2

- 1、 Wireless charging: mobile phones and smart devices with wireless charging capability can be placed on the charging pad. (BE400A)
- 2、 This product has overload protection switch

Pop-Up Pneumatic Outlet User Manual

Chapter 3

series	BE400electrifiingseries			
ItemNo	BE400A	BE400B	BE400C	BE400D
Productconfiguration	4 sockets+USB-A-C+15W wireless charging	4 sockets+15W wireless charging	4 sockets USB(A+C fast charging)	4 sockets
Shellmaterial	plastics			
SelectiveColor	Black/white			
Surface technology	plastics			
Wirelesscharging	15W fast wireless charging			
USB charging port	2*USB-A+C20WQC3.0/PC1.0	/	2*USB-A+C20WQC3.0/PC1.0	/
export	USB-C:DC 5V/3A/9V/2.22A/20V/1.67A USB-A:DC 5V/3A/9V/2A/12V/1.5A/USB-C USB-A+C 5V 3.4A			
Powerinput/power	Ac100-250V/50Hz-60Hz/10A_2500W			
IP protection grade	IP54			
parts	One 1.5m power cord/one mounting fastener			
Opening size	98-100mm			
Installation method	Embedded installation			

Chapter 4

Product qualification certificate

Examination conclusion : Qualified
Inspector number : Inspector 001
doe : See production batch number

For the production date, see the first 6 digits of the production batch number (year/month/day)

statement :

All contents in this material have been carefully checked.If there are any typographical errors or misunderstandings,you can consult our company. If there is any technical improvement,it will be incorporated into the new version of the manual without prior notice. If the appearance and color of the product are changed, the actual product shall prevail.