


黑武士蓝牙音响

DZ-023



产品使用说明书

感谢您选择我们的产品 希望您尽情享受音乐之旅

• 安全指导

- 在使用前请仔细阅读此说明书，并保存好以供之后参考。
1. 远离热源，太阳曝晒和尖锐物体。
 2. 远离明火。
 3. 不要插入任何金属物体，避免短路。
 4. 不要自行修理产品而应联系授权维修厂家。
 5. 避免产品淋雨，喷雾。
 6. 如果产品过热，损坏或坠入液体中，请停止使用。
 7. 根据标准和规定使用产品。

• 包装配件


01. DZ-023音响*1
02. TYPE-C充电线*1
03. 产品说明书*1

• 内置电池

01. 内置可充电电池，初次使用需2-3小时完成充电，放电周期。
02. 不要把充满电的电池继续充电，过度充电会缩短电池寿命。
03. 如果放置不用，满电的电量可能会有些许流失。
04. 产品置于过热或者过冷的地方，都会缩短产品寿命。

• 充电功能

01. 插入TYPE-C充电线，另一头连接充电器。
02. 产品的LED充电指示灯常亮红灯，即需正常充电。
03. 当产品充满电时，LED指示灯红灯熄灭。



• 操作功能

- ① 开 / 关机
- ② 上一曲 / 声音加
- ③ 下一曲 / 声音减
- ④ FM 收音机模式
- ⑤ 氛围灯
- ⑦ TYPE-C 充电端口

- 1、开关机键，长按开关机按键，提示“Bluetooth mode”即开机完成进入蓝牙模式，打开手机蓝牙设置-打开蓝牙-进行搜索并找到音响蓝牙名称进行连接。
- 2、短按进入上一曲，长按音量增大。
- 3、短按进入下一曲，长按音量减小。
- 4、M键：单击，收音机功能，收音机频段87.5Hz--108Hz，使用操作说明：(1)将配线Type-c头插在音响Type-c充电端口上，线的另一端“不能”插在充电器上(TYPE-c线作为增益天线)。(2)短按FM按键进入收音机模式，然后需要短按开/关机⊗形按键进行收音机搜台，若需退出收音机模式则再次短按FM按键。(3)收到电台后，再次短按开/关机⊗形按键锁定已搜到的电台，再按音量上/下键短按进行切换电台。
- 5、M键：连续双击，灯光切换模式；连续双击按两次M键进行灯效切换，总共六种灯效模式，灯效二、灯效三模式会根据音乐节奏快速闪烁。
- 6、音响互联功能。（注：对歌前需断开音响蓝牙与手机的连接）取两台音响同时开机，然后取一台音响连续短按两次开关机按键进行两台音响互联连接，若需断开则再次连续短按两次开关机键，听到提示音则对连成功。然后在用手机搜索蓝牙进行连接。
- 7、可透过 TYPE-C 充电线给音箱充电。
- 8、LED 充电指示灯，判断充电状态，充电亮红灯，充满后红灯灭。

• 故障排查

故障现象	可能原因	解决方案
无法搜索蓝牙	电池没有电关机了	给音响充电
无法配对蓝牙	音响已经配对了另外的设备且没有进入配对模式	关闭其他配对设备重新搜索并进行配对

• 技术规格


产品型号	DZ-023
蓝牙名称	BT-023
蓝牙接收距离	直线无障碍10米
喇叭功率	5W
电池容量	500mAh
充电接口	TYPE-C接口
充电时长	2H
工作时长	音量最大时≥3H，音量最小时≥6H (注意：手机的品牌和实际音量不同，对时间会有所不同)

感谢您的支持！

PE CE RoHS

Black Warrior Speaker

DZ-023



Product Instruction Manual

Thank you for choosing our products and I hope you enjoy your musical journey

• SAFETY INSTRUCTION

- PLEASE READ THE MANUAL CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE
- 01.Keep away from heat, sun exposure and sharp objects.
 - 02.Stay away from the open fire.
 - 03.Don't insert any metal objects. Avoid short circuit.
 - 04.Don't repair the product by yourself, but contact the authorized repairer.
 - 05.Avoid products from getting caught in the rain.Spray.
 - 06.If the product is overheated.Damaged or fell into liquid. Please stop using.
 - 07.Use products according to standards and regulations.

• PACKAGING ACCESSORIES


- 01.DZ-023 Audio*1
- 02.TYPE-C charging cable*1
- 03.Product description*1

• INTERNAL BATTERY

- 01.Built-in rechargeable battery takes 2-3 hours to complete the charging and discharge cycle.
- 02.Don't continue charging a fully charged battery. Overcharging will shorten the battery life.
- 03.If the full load is placed, it may be a little lost.
- 04.Placing the product in a place that is overheated or too cold will shorten the product life.

• CHARGING FUNCTION

- 01.Plug in the TYPE-C charging cable and connect the charger at the other end.
- 02.The product's LED charging indicator light is always on in red, that is, the sound is charging normally.
- 03.When the product is fully charged, the LED red light is off.



• OPERATION FUNCTION

- ① Power on /Power off
- ② Previous Song/Sound Plus
- ③ Next song/Sound reduction
- ④ FM mode
- ⑤ Ambient Light
- ⑦ LED charge lamp

- 1、Open/off button, long press the switch button, prompted "Bluetooth mode" that is, power on the completion of the entry into the Bluetooth mode, open the cell phone Bluetooth settings - open Bluetooth - search and find the audio Bluetooth name for connect.
- 2、Short press to enter the previous song, long press to increase the volume.
- 3、Short press to enter the next song, long press to reduce the volume.
- 4、M key: click, radio function, radio band 87.5Hz - 108Hz, use the operating instructions.
(1)Insert the Type-c head of the cable into the Type-c charging port of the stereo, and the other end of the cable "can not" be inserted into the charger (TYPE-C), and the other end of the cable "cannot" be plugged into the charger (Type-c cable is used as gain antenna).
(2)Short press the FM button to enter the radio mode, then you need to short press the On/Off button to search for radio stations, if you need to exit the radio mode, you need to press the button to search for radio stations, station, if you need to exit the radio mode then short press the FM button again.
(3)After receiving the radio station, press the On/Off button again to lock the ⊗ buttons, then press the Volume Up/Down button to switch the radio station.button to switch between stations.

- 5, M key: continuous double-click, light switching mode: continuous double-click and press the M key twice for light effect switching, a total of six light effect modes, light effect switching mode, light effect switching mode, light effect switching mode. A total of six light effect modes, light effect two, light effect three modes will flash quickly according to the music rhythm.
- 6, audio interconnection function: (Note: the need to disconnect the audio Bluetooth connection with the phone before coupling) Take two stereo at the same time, and then take a stereo on two consecutive short press the button on / off for two stereo mutual connection, if you need to disconnect, then again short pre
- 7, through the TYPE-C charging cable to the speaker charging.
- 8, LED charging indicator to determine the charging status, charging red light, full red light off.

• TROUBLESHOOTING

Failure phenomenon	Possible reasons	Solution
Unable to search Bluetooth	The battery is not powered off	Charge the audio
Unable to pair Bluetooth	The audio has been paired with another device and has not entered pairing mode	Turn off other paired devices. Search again and pair

• TECHNICAL SPECIFICATIONS

Product Model	DZ-023
Bluetooth Name	BT-023
Bluetooth receiving distance	Straight line obstacle free 10m
Speaker Power	5W
Battery capacity	500mAh
Charging Interface	TYPE-C Interface
Charging duration	2H
Working hours	Maximum volume ≥ 3H, minimum volume ≥ 5H (Note: The time will vary depending on the type of mobile phone and the actual situation)

Thank you for your support!

PE CE RoHS

60*70mm

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.