


八爪鱼感应蓝牙音响

DZ-032



产品使用说明

感谢您选择我们的产品 希望您尽情享受音乐之旅

• 安全指导

在使用前请仔细阅读此说明书，并保存好以供之后参考。

01. 远离热源，太阳暴晒和尖锐物体。
02. 远离明火。
03. 不要插入任何金属物体，避免短路。
04. 不要自行修理产品而应联系授权维修厂家。
05. 避免产品淋雨，喷雾。
06. 如果产品过热，损坏或坠入液体中，请停止使用。
07. 根据标准和规定使用产品。

• 包装配件


01. DZ-032音响*1
02. TYPE-C充电线*1
03. 产品说明书*1

• 内置电池

01. 内置可充电电池，初次使用需2~3小时完成充电，放电周期。
02. 不要把充满电的电池继续充电，过度充电会缩短电池寿命。
03. 如果放置不用，满载的电量可能会有些许流失。
04. 产品置于过热或者过冷的地方，都会缩短产品寿命。

• 充电功能

01. 插入TYPE-C充电线，另一头连接充电器。
02. 产品的LED充电指示灯常亮红灯，即音响正常充电。
03. 当产品充满电时，LED指示灯红灯熄灭。



• 操作功能

- ① 开 / 关机
- ② 音量加 / 上一曲
- ③ 音量减 / 下一曲
- ④ 模式切换键
- ⑤ TYPE-C 充电端口
- ⑥ U盘功能


1、开\关机键-感应模式：长按开关机键提示 “Proximity Sensing Mode” 即开机自动进入感应模式。单次按压为暂停/播放功能。对联功能：在蓝牙模式状态下，连续双击开关机键为音响对联功能。

2、M键：

(1) 蓝牙模式：在感应模式状态下，短按一次M键提示 “Bluetoothmode” 则切换至蓝牙模式，打开手机蓝牙设置-打开蓝牙-进行搜索并找到音响蓝牙名称进行连接，再次短按M键则切换回感应模式。

(2) 收音机模式，收音机频段87.5Hz-108HZ，步骤一：将配线Type-c头插在音响Type-c充电端口上，线的另一端 “不能” 插在充电器上(TYPE-c线作为增益天线)。步骤二：双击M按键进入收音机模式，然后需要短按开/关机按键进行收音机搜台，若需退出收音机模式则再次单击M按键。步骤三：收到电台后，音量上/下键短按进行切换电台。

3、音量 “+” 键：短按切换音乐列表上一曲，长按音量增大。



• OPERATION FUNCTION

- ① Power on / Power off
- ② VolumeUp/PreviousTrack
- ③ VolumeDown/NextTrack
- ④ FM mode
- ⑤ TYPE-C charging port
- ⑥ USB drive functionality

1. Power Button: - Proximity Sensing Mode: Long press the power button to hear “Proximity Sensing Mode” and automatically enter proximity sensing mode upon startup. A single press controls play/pause. - Pairing Function: In Bluetooth mode, double-click the power button to activate speaker pairing.

2. M Button:

(1) Bluetooth Mode: In proximity sensing mode, a single short press of the M button prompts “Bluetooth mode” and switches to Bluetooth mode. Open your phone’s Bluetooth settings, enable Bluetooth, search for and connect to the speaker’s Bluetooth name. Press the M button again to switch back to proximity sensing mode.

(2) Radio Mode: Radio frequency range 87.5Hz-108Hz. Step 1: Plug the Type-C end of the cable into the speaker’s Type-C charging port. The other end of the cable must not be plugged into a charger (the Type-C cable functions as a gain antenna). Step 2: Double-click the M button to enter radio mode. Then briefly press the power button to scan radio stations. To exit radio mode, press the M button again. Step 2: Double-click the M button to enter Radio Mode. Then briefly press the Power button to scan for radio stations. To exit Radio Mode, single-click the M button again. Step 3: After finding a station, use the VolumeUp/Down buttons to switch stations

4. 音量 “-” 键：短按切换音乐列表下一曲，长按音量减小。
5. 可通过 TYPE-C口充电线给音箱充电，LED充电指示灯:判断充电状态，充电亮红灯、充满红灯灭。
6. U盘功能:在关机状态下插入U盘再开机，则开机后自动优先播放U盘内音乐 (注:支持最大内存为:32GB，音频文件格式仅支持:MP3、WAV格式)。

备注：感应功能仅适用于右声道的手机，左声道手机无法使用。

• 故障排查

故障现象	可能原因	解决方案
无法搜索蓝牙	电池没有电关机了	给音响充电
无法配对蓝牙	音响已经配对了另外的设备 且没有进入配对模式	关闭其他配对设备 重新搜索并进行配对

• 技术规格


产品型号	DZ-032
蓝牙名称	BT-0 32
蓝牙接收距离	直线无障碍10米
喇叭功率	5W
电池容量	1200mAh
充电接口	TYPE-C接口
充电时长	2H
工作时长	音量最大时≥3H，音量最小时≥4H (注：手机的实际使用场景及不同，使用时间会有所不同)

感谢您的支持！

FC CE RoHS

Octopus Induction Speaker

DZ-032



Product Instruction Manual

Thank you for choosing our products and I hope you enjoy your musical journey

• SAFETY INSTRUCTION

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE

- 01.Keep away from heat, sun exposure and sharp objects.
- 02.Stay away from the open fire.
- 03.Don't insert any metal objects. Avoid short circuit.
- 04.Don't repair the product by yourself, but contact the authorized repairer .
- 05.Avoid products from getting caught in the rain,Spray.
- 06.If the product is overheated. Damaged or fell into liquid. Please stop using.
- 07.Use products according to standards and regulations.

• PACKAGING ACCESSORIES

- 01.DZ-032 Audio*1
- 02.TYPE-C charging cable*1
- 03.Product description*1

• INTERNAL BATTERY

- 01.Built-in rechargeable battery takes 2-3 hours to complete the charging and discharge cycle.
- 02.Don't continue charging a fully charged battery. Overcharging will shorten the battery life.
- 03.If the full load is placed, it may be a little lost.
- 04.Placing the product in a place that is overheated or too cold will shorten the product life.

• CHARGING FUNCTION

- 01.Plug in the TYPE-C charging cable and connect the charger at the other end.
- 02.The product's LED charging indicator light is always on in red, that is, the sound is charging normally.
- 03.When the product is fully charged, the LED red light is off.

3. Volume “+” button: Short press skips to the previous track in the music list; long press increases volume.
4. Volume “-” button: Short press skips to the next track in the music list; long press decreases volume.
5. Charge the speaker via the TYPE-C port charging cable. LED charging indicator: Red light indicates charging; red light turns off when fully charged. Translated with DeepL.com (free version)
6. USB Drive Function: When a USB drive is inserted while the device is powered off and then powered on, it will automatically prioritize playing music from the USB drive upon startup. (Note: Supports a maximum storage capacity of 32GB. Audio file formats supported are limited to MP3 and WAV formats only.)

Note: The sensing function is only compatible with right-channel phones; left-channel phones cannot be used.

• TROUBLESHOOTING

Failure phenomenon	Possible reasons	Solution
Unable to search Bluetooth	The battery is not powered off	Charge the audio
Unable to pair Bluetooth	The audio has been paired with another device and has not entered pairing mode	Turn off other paired devices Search again and pair

• TECHNICAL SPECIFICATIONS

Product Model	DZ-032
Bluetooth Name	BT-032
Bluetooth receiving distance	Straight line obstacle free 10m
Speaker Power	5W
Battery capacity	1200mAh
Charging Interface	TYPE-C Interface
Charging duration	2H
Working hours	Maximum volume ≥ 3H, minimum volume ≤ 4H (Note: The time will vary depending on the type of mobile phone and the actual situation)

Thank you for your support!

FC CE RoHS

80×274mm

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.