



CHIPS PRO WIRELESS HELMET AUDIO




Thanks for taking a few minutes to get to know your new CHIPS PRO. They're built to drop into almost any audio-ready helmet and let you take life's soundtrack wherever you go with just the push of a button. Read this manual before you head out to learn the setup, controls, features, and safety basics.

Go Forth and Play!



WARNING: Designed only for off-highway activities. Follow all laws, regulations, and restrictions regarding headset use during sports or activities requiring attention to safety. Slow down at your own risk. Excessive volume may cause permanent hearing damage. Contains magnets: Keep away from pacemakers and implanted medical devices.

ANATOMY



A. Left ear button
B. Right ear button
C. Charge port USB-C
D. LED light
E. Microphone


FUNCTIONS

FUNCTION	ACTION	VOICE PROMPT
POWER ON	LONG PRESS 4 SECONDS	"POWER ON"
PLAY	PRESS ONCE	
PAUSE	PRESS ONCE	
SKIP FORWARD	PRESS TWICE	
SKIP BACKWARD	PRESS THREE TIMES	
ANSWER CALL	PRESS ONCE	"ANSWER"
END CALL	PRESS ONCE	"CALL TERMINATED"
REJECT CALL	LONG PRESS 2 SECONDS	"REJECT"
SIRI/ VOICE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"
CLEAR MEMORY	LONG PRESS 6 SECONDS	

FUNCTIONS

FUNCTION	ACTION	VOICE PROMPT
POWER OFF	LONG PRESS 4 SECONDS	"POWER OFF"
VOLUME UP	PRESS TWICE	"MAX VOLUME"
VOLUME DOWN	PRESS ONCE	
MIC MUTE	PRESS THREE TIMES	
SIRI/ VOICE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"

POWER UP



For best results, fully charge your CHIPS PRO using the supplied USB-C to USB-C charging cable before use.

The indicator light located on the right earpiece will flash red to indicate a low battery.

Once the Chips PRO are plugged into a power source, the indicator light will turn red. It will turn off once the CHIPS are completely charged.

NOTE: It only takes 45 minutes to give your CHIPS PRO a full charge.

PAIRING



Choose: "ODT Chips PRO" in your phone's Bluetooth settings.
VOICE PROMPT: "connected"
(If prompted by your device to connect, select "Yes". If prompted by your device enter password or use pairing code: 0000.)

TALK

The following are tips for using your chips when making calls.

Answer a call..... Press right ear button
End a call..... Press right ear button
Reject a call..... Press and hold the right ear button for two seconds
Make a call Use voice assistant to prompt a call or dial as usual, listen and talk through the Chips
Volume up..... Double press the left ear button
Volume down..... Press left ear button
Voice Assistant Press and hold both left and right ear buttons simultaneously. Release and speak when you hear the voice prompt: "Beep".

APP

Level up your sound game! Just head to the App Store if you're on iOS or the Google Play for Android devices and download the TruTone APP.

Getting connected is a breeze! Turn on Bluetooth, pair with your device, fire up the APP, and follow the easy steps.


Sound Modes

-Default: The go-to, no-frills sound.
-Popular: Perfect for jamming to today's hits.
-Bass: Crank up those deep, thumping beats.
-Rock & Roll: Built for that raw, energetic rock vibe.
-Gentle: Smooth, laid-back tunes.
-Classical: Brings out the elegance of classical music.
-Custom: Tweak treble, mid, and bass, give it a cool name, and save it for later!

Keep an eye on your battery level. And if your Chips ever go MIA, use the integrated "Find My" map feature to track 'em down.

Keep your APP and phone system updated. If you run into any snags, hit us up! Have a blast!

PUT THE CHIPS IN YOUR HELMET



SPECS

Battery life..... 15 hours of play time
*Battery life varies subject to different playing circumstances, such as music type and volume.
Bluetooth version..... V5.3
Bluetooth profiles..... HFP1.8, HSP1.2, A2DP1.3, AVRCP1.6
Operating distance... 33 feet, 10 meters
Charging input..... DC 5.0V, 1A
Dimensions..... 2" diameter, 0.6" thick
Weight..... 0.12 lbs (54.4g)
Battery capacity..... 250mAh

FAQ

Why is the red LED off when charging?
A. Make sure the connection between the charging cable and the CHIPS PRO is tight.
B. If the CHIPS PRO haven't been used in a while, the light may not come on immediately. Charge the battery for at least 30 minutes.
Why can't I pair my CHIPS PRO?
A. Your Bluetooth device and the CHIPS PRO must both be in pairing mode.
B. Your CHIPS PRO should not be paired to any other devices.
Why do I have Bluetooth signal loss/dropout/unclear conversations?
A. Move your device closer to your CHIPS PRO.
B. Make sure your CHIPS PRO are charged up.
C. Turn off your CHIPS PRO and device, then power up and reconnect.
Why can't the other person hear my voice during a call?
A. Make sure the CHIPS PRO are on.
B. Make sure the volume is not too low or muted.
C. Make sure the CHIPS PRO are properly connected with your device.
D. Make sure the CHIPS PRO are within range of your device.

CARE & MAINTENANCE

- Avoid excessive moisture. Wipe dry after exposure to snow. Do not submerge.
- Store in a cool, dry place away from direct sunlight and high heat to help prevent battery and electronics damage.
- Do not drop, crush, puncture, or subject to hard impacts.
- Do not disassemble or attempt to repair.
- Clean only with a soft, dry cloth. Do not use harsh chemicals or abrasives.
WARNING
Cancer and Reproductive Harm
www.P65Warnings.ca.gov
Battery Recycling / Disposal
This product contains a lithium-ion battery. Do not dispose of this product with household waste. Take it to an appropriate WEEE or battery collection point for proper recycling. Do not attempt to remove the battery. Scan the QR code for additional battery, recycling, and disposal information.


FOR BATTERY INFO

FCC Warning

FCC Compliance Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
CAUTION: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
RF Exposure Statement:
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Manual de usuario en Español.

Manuel d'utilisation en Français.
Benutzerhandbuch auf Deutsch.
Manuale d'uso in Italiano.
日本語のユーザーマニュアル。



K, later gator.

By Outdoor Tech

Facebook.com/outdoortechology
X & Instagram: @outdoortech

Questions, comments, complaints, or just want to say hi?
Email us at support@outdoortech.com

K bye.

www.outdoortech.com

DON'T BE SO ANTISOCIAL



Facebook.com/outdoortechology
X & Instagram: @outdoortech

Questions, comments, complaints, or just want to say hi?
Email us at support@outdoortech.com

K bye.

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com

www.outdoortech.com