

感谢您购买及使用本产品！
为了给您带来更好的使用体验，在使用产品前请仔细阅读本用户手册，
并妥善保管，以便日后参考。谢谢。

①	电源开关 (关闭状态)	⑥	光线感应装置
②	暂停键、自动暂停、时间调节	⑦	数据结果显示
③	灯光键、亮度调节键	⑧	液晶片
④	播放键、快进键	⑨	控制、可写为手机支架
⑤	播放开关 (打开状态)	⑩	LOGO区域
“+”键: 音量+ / 上一曲/快进		⑪	USB接口
“-”键: 音量- / 上一曲/快进		⑫	接口
⑬	背光源	⑭	底部微孔

[illegible]

散热器与身体之间的最小距离为20厘米：仅使用随附的

保修范围

在正常使用状态下出现的质量问题,并非外力破坏造成的损坏,产品保修期间,我们将免费对产品出现的故障或损坏,本公司将承担任何责任,原则上产品属于保修期内的用户不支付任何费用,但属于力损坏则需要收取检测或零配件费用,产品超出保修期时一律收费。

以下情况不能享受保修

由于人为损坏如使用不当,错误造成损坏,外观不正常磨损、摔碰、电路损坏、跌落入水、异物吸入、受潮、产品本身的缺陷而造成或改装的,以及其他任何可预见或不可见的,其他原因引起产品自身原因造成损坏或自行拆装的,使用不当、操作不当造成水灾或为雷电击所造成的损坏,因不可抗力造成的损坏,如地震、火灾、台风或战争等。

Multi functional speaker



MANUAL

Thank you for buying and using this product!
In order to bring you a better user experience, please read this user manual carefully before using the product.
Please keep it safe for future reference. Thank you.

Product Features

This product is a retro multifunctional audio system that integrates aromatherapy, wireless charging, clock, ambient color, ambient lighting, phone holder, and other functions, simplifying complexity and making the product more practical.
Retro and modern are like two rivers of time, intertwined and converging in our product design, forming a unique melody.
Retro is an ancient poem softly recited by time, flowing with the depth and weight of history. It is like a yellowed scroll, gently unfolded, revealing the charm of the past, enchanting people.
Modernization is a new chapter in the era's singing, playing with the passion and vitality of innovation. It is like a dazzling neon light, dazzling and leading the direction of the trend, making people yearn for it.
Every detail design contains both classical charm and modern inspiration. It events that ancient and modern people are interacting at this moment, telling the story of time together. Welcome to my world, let's explore this wonderful time together!

Product Specifications


Product Name: Fragrance Diffuser/Stereo Audio speaker
Product Model: A55-KC
Product Material: ABS+PC
Product size: 216mm*172mm*88mm
Individual weight/net weight: 650g
Style/Color: Wood grain+Black
Power interface: DC7V 2A
Wireless charging rated voltage: 9V
Wireless charging output power: 15W
Speaker power: 5W
Atmosphere lamp charging voltage: 3.3V
Rated power of night light: 4.0W
Lamp color temperature: 3000-3200K
Lamp beam value: 15-60LM
Color rendering index: 70
TX to RX sensing distance: 6mm
Aromatherapy type: Solid Aromatherapy Tablets

Accessories List:

Host *1, instruction manual *1, aromatherapy sheet *1, adapter *1, cover clip *1.



Product Description



① Audio switch (off and on)	⑤ Wireless charging area
② Power button (power on/off adjustment)	⑥ Digital screen display
③ USB Type-C charging light adjustment	⑦ Aromatherapy sheet
④ Alarm function, alarm adjustment	⑧ Alarm function (alarm on/off adjustment)
⑨ Audio volume (volume on/off)	⑨ Night light
⑩ < > key volume (volume back/forward)	⑩ USB output port
⑪ Aromatherapy cover	⑪ LED indicator
	⑫ Ambient light

Operating Instructions

1. Key definitions:

1. Toggle switch: audio switch
2. Pause button: Music pause, clock adjustment
3. Light button: Atmosphere light adjustment
4. Alarm key: Alarm adjustment
5. < > key: Volume (Previous back/Time)
6. < > key: Volume (Next back/Time)

2. Power indicator light:

1. Digital screen icon display

3. Instructions:

- Connect DC power supply
Clock, alarm clock, date, temperature, ambient light, wireless charging, USB output port start, disconnect power, turn off all functions.
1. Flip the switch: Turn left 30 degrees to turn on the Bluetooth speaker. Bluetooth waits for pairing, and after a successful Bluetooth connection, the time and period will automatically update. Turn right 30 degrees to turn off the speaker.
 2. Pause button: Click on the music play/pause button, press and hold to switch to manual adjustment mode for time and date.
 3. Light button: The default brightness of the light is 20%. Click once to switch the light brightness to 50%. Click again to switch the light brightness to 100%. Click again to turn off the light.
 4. Alarm button: Click to enter Alarm 1 adjustment mode, long press to enter Alarm 2 adjustment mode.
 5. < > key: Click/Long press on previous track/Volume-Manual clock adjustment mode/Time-Time Alarm mode/Time-Alarm adjustment, Alarm switch adjustment.
 6. < > key: clicking long press next track/volume down in manual clock adjustment mode/time up, date up in alarm mode/time down in alarm adjustment alarm switch adjustment.
 7. Screen display: week, time, date, temperature, Bluetooth connection status icon, aromatherapy machine status icon, ambient light status icon, and wireless charging status icon.
 8. Glasses: can hold a phone as a stand for use.
 9. USB output port: The output current is 5A, which can supply power to external devices.

FCC Caution

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance between 20cm the radiator your body. Use only the supplied antenna.

warranty card

Please keep this card properly. The company will take this card as the warranty certificate. Thank you for your warranty this product. The warranty period of this product is 12 months from the date of purchase. Please keep it properly and fill in detailed correct information for warranty use.

Product model: _____ Date of purchase: _____
Customer name: _____ Contact number: _____
User name: _____
Address: _____

Explain the reason: ☐ Return goods ☐ Exchange goods ☐ Suggest

Warranty conditions:
When warranty service is required, please show this card and fill in the relevant content in detail.
The company provides users with a 12-month warranty period from the date of purchase.

Warranty scope:
The quality problem that appears under the normal use conditions, is not the damage caused by the external force damage, the product warranty period, because can not use for the improvement or damage caused by the product, the company assumes any responsibility principle. The product belongs to the warranty period users do not have to pay the cost, but in the case of human damage is necessary to charge testing or spare parts costs, products beyond the warranty period of a law charges.

Warranty is not available under the following circumstances:
-- Improper use: Improper use, improper storage, improper handling, abnormal use and use of accessories, wrong damage, circuit destruction, deformation, water or liquid damage, mechanical damage or tearing of labeling labels on products, and any other damage that is not made during the warranty period, and the user's own personal reasons (unauthorized disassembly and modification, unauthorised repair, operation, water damage, etc.) Damage caused by force majeure, such as earthquake, flood, fire, typhoon or war.

MADE IN P.R.C
FC CE RoHS