



User Manual

Hibird Pro



Video Instructions



Smart Bird Camera

support@hibird.com

Catalog


1. What's in the Box	03
2. About the Product	04
3. Installation Steps	05
4. Support	12
5. Hibird Community	12
6. Specifications	13
7. Warning	14
8. Warranty	15
9. Important Safety Advisory	15

Product Overview

The Hibird Pro is an intelligent birdwatching camera designed for families and bird enthusiasts. Equipped with a 4K ultra HD camera, 4× digital zoom, 6× slow-motion recording, and AI recognition, it helps you effortlessly capture every beautiful moment in your backyard.

What's in the Box

Please ensure all accessories are included:




Feeder




Hibird Pro Camera



Mounting Bracket



Mounting Strap




Perch




Hose Clamp



SD Card



Screw Pack




Charging Cable




User Manual

About the Product



- 1** SD Card Slot
- 2** Power Button & Indicator Light
- 3** Type-C Port



- 4** Roof
- 5** Bracket
- 6** Feeder Body
- 7** Perch
- 8** Camera

Installation Steps

Step 1: Set Up the Camera


1. Take everything out of the box. You will find:

- The camera
- The feeder
- Charging cable and other accessories

2. Charge


- Charge the camera for 2-4 hours using the included USB-C cable before first use. (5V/2A)
- Unplug before continuing

Status Light	Status	Meaning
Yellow	Solid	Charging
Green	Solid	Fully Charged
Green	Flashing	Wi-Fi Pairing
Red	Flashing	Low-Battery



3. Download and log in to the Hibird App

- Search for “ Hibird ” in the App Store or Google Play
- Download the app
- Open it and sign up for an account




4. Place the camera close to the router to pair

- Place the camera within 6 feet (about 2 meters) of your home Wi-Fi router. This helps the connection work smoothly.



5. Connect to Wi-Fi

- Turn on the camera
- Open the app and ensure Bluetooth is enabled on your phone.
- The app will automatically find nearby devices that can be connected. Tap to connect your camera to Wi-Fi.
- If no pairable device is detected, you can restart the camera, or tap icon in the app to begin.



- Follow the step-by-step guide to connect your camera to Wi-Fi
- Scan the QR code below if you want to watch a short video guide




IMPORTANT:

- Make sure Bluetooth and location permissions are enabled on your **phone**.
- Make sure your phone is also connected to Wi-Fi.
- Keep the camera within 6 feet (about 2 meters) of your home Wi-Fi **router**.
- If something doesn't work, contact us at **support@hibird.com**

Step 2: Install the Feeder


1. Place the Camera into the Feeder

- Open the waterproof silicone cover located on the back of the **feeder**.
- **After successfully pairing the camera with Wi-Fi and completing the firmware update**, insert the camera from the front.
- **Secure it with the included nut until it feels firmly attached.**




2. Connect the solar panel cable

- Plug the solar panel's USB-C cable into the camera's charging port.
- Solar Panel's cable is located behind the silicone cover.




3. Close the waterproof cover tightly

- Ensure it's tightly sealed with no gaps for full water protection.




4. Perch Installation & Mounting

- Slide the perch securely into the slot on the feeder and tighten with the screw. Ensure the slots line up correctly for the correct installation.




- Use the provided bracket, strap, or screws to attach the feeder to a tree, wall, or any spot birds love. Then place the feeder on the bracket.


Tree-Mounted:




Pole-Mounted:




Wall-Mounted:





5. Fill Your Feeder

- Fill your feeder with seed.
- You can choose the type of seeds based on the birds you want to attract.



6. Feeding Time

- Be patient — it may take a few days for birds to visit and feel comfortable.

Friendly Tips:

- **Choose a quiet, shady spot to attract more birds.**
- Test the livestream before final mounting for the best view.
- If unsure, ask a family member to help with mounting.
- If something doesn't work, contact us at **support@hibird.com**.

Support

We are dedicated to providing top-notch products and services to our customers.

If you encounter any issues with your Hibird, please don't hesitate to reach out to us — we're here to help!

Email: support@hibird.com.

Our support team responds within 24 hours.

Hibird Community

Scan the QR code to join our vibrant FaceBook Community and connect with fellow bird enthusiasts! Discover endless potentials on bird-watching and techniques, exchange your best shots, and witness extraordinary birds from all around the globe!



FaceBook Group

Follow us on our Socials!



Specifications

Hibird Pro

Item	Specification
Dimension	9.8"× 9.9"× 12.2"
Net Weight	35 oz
Field of View	130°
Image Quality	Photo: 3M/8M/16M/32M Video: 720P/1080P/2K/4K
Live Streaming	Supported in APP, 480P/720P/1080P
Battery	5000mAh
Input	5V/2A, 6V/2A, 12V/1A
Memory	Built-in 32G
Connction	2.4GHZ / 5GHZ
Working Temperature	-4°F~131°F
Working Humidity	5%~90%
Waterproof	IP66

Solar Panel

Item	Specification
Output	5V/1A
Max Output Power	5W (±5%)
Dimensions	164mm x 88mm x 2mm x 2pcs

Function	Color	Status	Description
Charging & Battery	Green	Solid On	Fully charged
	Yellow	Solid On	Charging
	Red	Fast Flashing	Low battery
Camera Status	Green	Solid On→Off	Press power button once; light stays on briefly then off → camera in standby mode(operating)
		Fast Flashing	Camera is in Wi-Fi configuration mode
		Slow Flashing→Off	Camera is shutting down
	Yellow	Fast Flashing	Camera is performing a Reset
		Slow Flashing	USB connected / SD card error / No SD card inserted
	Red	Solid On	Hardware malfunction
		Slow Flashing	Communication error with server

Warning

FCC regulation

Federal Communications Commission - Part 15



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communications Commission rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement To comply with FCC RF exposure compliance requirements, this grant is applicable to The antennas used for this transmitter must be installed to or operating in conjunction with any other antenna or transmitter. only mobile configurations. provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Warranty

Hibird Pro includes a free 12-month warranty and lifetime technical support.

Our dedicated support team responds to all inquiries within 24 hours.

To activate the free 12-month warranty, please ensure that your Hibird Pro was purchased through our official Amazon store or the Hibird official website.

Thank you for choosing Hibird!

We're here to help you capture every feathered moment.

Email: support@hibird.com

Official Site: [Hibird.com](https://hibird.com)



Important Safety Advisory

The device contains batteries. Keep away from fire.

Be aware that the device may detach or fall due to various unforeseen factors, including but not limited to improper bundling or being struck by heavy objects. To ensure your personal safety, do not stay or linger in the area directly beneath this product.

