













展开尺寸：700X105mm，风琴九折，折后成品：70X105mm，材质128G双铜+彩色印

Projector  ✕ UserManual ✕	Attention Please read this manual carefully before use and keep it for future reference. - The projector is non dustproof or waterproof. - In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog. - Please use the original power adapter. The projector should work under specified rated power supply. - When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults. - Do not cover the vents of projector. Heating will reduce the life of projector and cause danger. - Regularly clean projector vents, or dust may cause cooling malfunction. - Do not use the projector in greasy, damp, dirty or smoky environment. Oil or chemicals will cause malfunction. - Please handle with care during daily use. - If the projector is not used for a long time, please cut off the power. - Non professionals are prohibited from dismantling, testing, and repairing the projector of this equipment on their own.	Multi point TOF focusing omnidirectional trapezoid function 1.Pay attention to the autofocus and automatic trapezoid function. Please adjust the machine angle to a 15° before triggering. 2.After each focusing action is completed, if you are not satisfied with the trapezoid effect, you can follow the prompts in the following picture when a pop-up window appears. Press the OK button on the remote control to fine tune the four corners of the trapezoidal screen. Fine tune the clarity by pressing (F+/-). 	3. It is recommended to control the horizontal left/right/pitch angle within 20° for optimal results. After exceeding the range, there will be a dynamic image pop-up prompt. When the pop-up appears, press the "OK" key and enter manual trapezoid correction mode. 	4.In manual trapezoid mode, press the directional keys to adjust the screen angle, and press the "OK" key to confirm the next corner position. 	Structure Description The following equipment picture and functional descriptions are for reference only, and the actual product shall prevail if any. Modifications are subject to change without prior notice, and our company reserves the right to final interpretation.  ①:Voice outlet ②: Air outlet ③: power socket ④: HD-interface ⑤: Headset jack ⑥: USB ⑦: IR ⑧: ON/OFF ⑨: Atmosphere light switch ⑩: return ⑪: Volume+ ⑫: Volume- ⑬: USB ⑭: IR	Remote Control Function Description  Power UP Mute Left OK Right Down Menu Back Volume- Mouse Volume+ signal source HOME Focus- Focus+	Power ON/OFF Power On: Long press Power button on projector for 3 seconds. Power Off: When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off. Focus Adjustment When turning on the projector, moving the machine or adjusting the angle will trigger the automatic trapezoid and focus functions. You can also use the focus button on the remote control to adjust the lens position to a clear state on the projector screen. 	Bluetooth remote control paired steps: - hold down the left and right keys do not let go, indicator lights start flashing, Bluetooth radio opens - Bluetooth options will automatically search to "XBL" click on the connection, the connection will be successful after the prompt. Bluetooth connect 	Launcher UI Note: Enter the setting of two displays, please refer to the actual display. 
OSD Language Setting - System Settings > OSD Lang > To choose your language. Note: The language display interface may be one of the following, please refer to the actual display 	Home Background Select the desired main background in the upper right corner of the interface  Projector Mode Setting - System Settings > PIP > To select different modes according to your application scenario. Four modes are available: < Front Table, Front Ceiling, Back Table, Back Ceiling >. Auto focus and trapezoid function can be optionally turned on or off 	Media Player Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.  HDMI Signal Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out. 	On-screen image IOS system - Connect the projection device and the mobile phone to the same network. - Open the screen mirroring interface on your phone and click on the word "XZ" "X" "X". - Select the device name to complete the screen projection. Note: There are two projection interfaces, please refer to the actual display, and follow the prompts 	Android screen projection 1.Connect the projection device and the mobile phone to the same network. 2.Open the screen mirroring interface on your phone and click on the word "XZ" "X" "X". 3.Select the device name to complete the screen projection. Note: There are two projection interfaces, please refer to the actual display, and follow the prompts 	【Safety instructions】 - Please pay attention to important information related to the operation and interference of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector. - Please consult the qualified personnel for installation and repair services, and do not use damaged vents, accessories and other peripherals. - Projector should be kept away from flammable materials, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc. - Do not cover projector vents. - Please use the original power adapter. - Keep adequate ventilation and make sure vents are not covered to avoid projector overheating. - When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. - Do not bend or drag the power cord. - Do not put power cord under projector or any heavy objects. - Do not cover other soft materials on power cord. - Do not heat the power cord. - Avoid touching power adapter with wet hands.	【Disclaimer】 This manual is general instructions. The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice. Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims. This manual has been carefully checked by professional engineer, please understand for any inevitable omissions. Attention: Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.	【Singing karaoke and lighting】 This product supports karaoke function, and the following three methods are feasible: - The machine comes with a karaoke APP for singing. - The karaoke function can be used on the same screen as the phone. - It can be connected to a Bluetooth speaker to use the karaoke function. This product is also equipped with colorful ambient lighting effects and four switchable modes. Formula: Single brown color, breathing light, colorful scrolling light, rhythm following. 	【microphone】 Press and hold the power button for 2 seconds. After turning on the microphone, it turns green. The indicator light will flash. Until the automatic connection with the projector is completed. Connect, the indicator light will remain on green for a long time. Microphone sound mode options: KTV - Magic Sound - Cool Sound - Original Sound When using a microphone, approach the pickup area. 	

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.