




USER GUIDE



Smart Dog Puzzle Toy

- Sound Recording
- Dog IQ Training
- Interactive Puzzle Feeder
- USB Rechargeable

D1

SPECIFICATION




Product Name	Smart Dog Puzzle Toy
Material	ABS + PP
Size	6.4" x 6.4" x 8.7"
Power Source	USB Chargeable (USB A-C)

HOW THE PRODUCT WORKS



Main Unit



- 1 Turn the lid counterclockwise, press the On/Off button till the blue light flashes. Press Reset button, the kibble container will rotate once to confirm normal operation.
- 2 Press the On/Off button again to turn off the main unit.


1-1

1-2

HOW THE PRODUCT WORKS



Remote



Switch

- 1 Flip the switch right, the power light will turn green.
- 2 Press the top remote button, the indicator light will flash blue with a "ring" sound. The main unit dispenses food.
Note: Wait 5 seconds between remote control actions.
- 3 Flip the switch left, the power light goes out, signifying shutdown.
- 4 When the remote beeps "dididi" five times, it signals low battery and requires charging.

1-3

SOUND SWITCHING & RECORDING



- 1 10 sounds: 9 presets + 1 user recording.
 - 2 Switch between sounds: short press the Sound Toggle (it remembers the last choice when turned on again).
 - 3 Recording: press and hold the Sound Toggle and you hear "di" with a blue light to start recording; Release and you hear "didi" to signal the end of recording (recording duration limited to 1-30 seconds).
- Tip:** To achieve a silent sound effect, record in a noise-free environment.

HOW TO SECURE THE REMOTE



- 1 Place on the holding tray. (Recommended for the protection of the remote)
- 2 Attach to smooth surfaces with a suction cup. (Insert suction cup in the slot, slide to lock it in)

1-4

HOW TO PUT IN DOG KIBBLES



- 1 Turn the lid counterclockwise.
- 2 Adjust the Kibble Dispensing Adjustment Panel and scoop in the dog kibble.

HOW TO DISPENSE DOG KIBBLES




- 1 Adjust the Kibble Dispensing Adjustment Panel properly.
- 2 Turn the lid clockwise.

1-5

HOW TO DISPENSE DOG KIBBLES



- 1 Pull out the kibble tray.
- 2 Press the top remote button and the main unit will dispense kibbles.



2-1

HOW TO TRAIN YOUR DOGS



- 1 Grasp dog's paw to press the remote button, then let him eat kibbles auto dispensed to the bottom tray.
- 2 Repeat multiple times till he learns to do it independently.

We recommend you scan the QR code to directly watch videos online to learn how to use this product and train your dog to play with it.




USB CHARGING



- 1 Plug the USB A-C cord into the charging socket and connect it to an adapter.

Tips:

- Charging: Red indicator.
- Fully charged: Light goes out.
- The product cannot be turned on while charging.
- The product charges with QC adapters (USB A-C) and won't charge with PD adapters (USB C-C).
- Included USB cable is recommended.




2-2

MAINTENANCE



- 1 Unlock and take out the kibble container.
- 2 Pull out the kibble tray.
- 3 Rinse and dry the kibble container and tray before putting them back in the main unit.



Notes:

- Clean the kibble container and tray regularly.
- Do not wash the main unit and remote.

2-3

REMOTE REPLACEMENTS




Although we work hard to make the remote for durability, it can inevitably get broken over time as a consumable since dogs need to press it too often and some dogs could be super destructive. You can order more in our Amazon store by scanning the QR code.

100% SATISFACTION



No-Hassle Fast Refund/Replacement

We issue immediate refund or replacement from our end when you request it any time for any reason. You don't need to return the product. You just tell us, we take care of the rest.



24/7

No item return!

No shipping fee!

No extra charges!

The only thing you need to do is just sending refund/replacement request to customer@potaroma.com and our after-sales will put smile back on your face.

2-4

- END -

2-5

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.