

SMART WATCH FT02 User manual	Quikc Start Guide Main Parts  Smart watch	Quikc Start Guide  ①Screen ②Knob (on and off screen, return to ③Button, wake up screen, return, enter menu) ④Heart rate ⑤Charging POGO PIN ⑥Buckle ⑦Strap
---	--	---

· When using the watch for the first time, make sure that the watch is fully charged, if the battery is low and cannot be turned on Please fully charge the watch first, the charging time is about 2 hours. · Make sure the charging pins on the charging cable are properly seated on the back of the smartwatch on the charging pin of the user cable, and then plug the other end of the user cable into the power source · Scan the QR code below to install the APP, and install the "APP" application.	Use any browser to scan the code and download directly 	· Turn on Bluetooth on the smartphone, and then open the "APP" application on the phone · Click "Connect Device" on the APP device interface, and a search interface will appear. Select the corresponding Bluetooth name of the watch to connect. (To unbind, you can directly click Unbind on the device page to unbind) 
---	--	--

Function Dial Press and hold on the watch face interface to choose to change the watch face  Steps The watch will automatically record your daily activities, click on the touch screen to view more detailed data. 	Heart rate/blood oxygen Enter the heart rate/blood oxygen interface, and the watch will automatically test your heart rate/blood oxygen. Swipe to the right to exit.  Sports The sports smartwatch has multiple sports modes, choose one sport to exercise.. After completing the exercise, slide to the right to stop the exercise and save the exercise data. If you have connected your smartwatch to the app through Bluetooth, you can view your exercise data in the app. 	① Walking ② Hiking ③ Badminton ④ Power ⑤ Workout ⑥ Running ⑦ Cycling ⑧ Stair climber ⑨ Shipping ⑩ Yoga ⑪ Treadmill ⑫ Swimming ⑬ Elliptical ⑭ Golf If you want to pause or end the movement, you can swipe the screen left or right to pause or end the current movement.  *Note: If the practice time is short, the data will not be saved.
--	---	---

Sleep monitoring When the watch generates sleep data, it will display the sleep data on the interface at this time. When sleep stops, the watch will display your total sleep, light sleep and deep sleep time on the sleep interface. After syncing with the APP, you can view a more detailed sleep report.  Information After connecting the APP to enable message push, unread messages will be displayed in the message interface, slide up and down to view the message list, and click the message list to enter the message details.	 Alarm clock In the "Alarm Clock" interface, click to add an alarm clock, and click the corresponding alarm clock to enter the alarm edit page, the watch will vibrate when the alarm time is up.  Stopwatch In the "Alarm Clock" interface, click to add an	alarm clock, and click the corresponding alarm clock to enter the alarm edit page, the watch will vibrate when the alarm time is up.  Weather After connecting the "app", turn on the location permission, and the weather will be automatically pushed to the watch. 
--	--	--

Sedentary reminder Turn on or off the sedentary reminders you have set up in the app on this page.  Remote photo The device can be used as a remote control for the camera function on the phone. In the app, tap "Take Photo", your watch will display a camera icon, short press to capture your photo. 	Music control Click the music function icon to enter the music playback interface. In the music interface, you can control the music playback of the mobile phone, you can select the previous/next song or play/pause the song.  Set up In the "Settings" interface, you can perform various settings on the watch, including finding phone numbers, screen brightness, screen on time, language, reset, shutdown, system, etc.	Find phone Dial switch Notification Vibration intensity Brightness Menu style Language Calculator Display off Sleep Mode Reset call System Restart Reset Shutdown Audio setup Find phone Once connected to the app, click the Find Phone feature in the dropdown menu or settings and the phone will ring/vibrate. 
--	--	--

Switch dial Touch "Switch Watch Faces" on the screen to choose another watch face.  Language Select the Multilingual feature on Settings, and then have the option to switch the watch to another language.  Reset Reset to factory default settings.	*Note: All user data will be deleted if factory reset Touching "Power Off" on the screen will turn off the watch.  System On the system page, you can view the Bluetooth name and firmware version information of the watch.  Sleep mode When the sleep mode is turned on, the system Bluetooth will be turned off, and the watch will not receive information	 Audio setup On this page, you can set the audio playback source of the watch 
---	--	--

Warranty policy Thank you for purchasing the our product. When you experience any non-human damage performance failure during the use of the product, you can enjoy the "guaranteed repair, return and replacement" (referred to as "three guarantees") service of Busee. promise. In order to protect your rights and interests, please keep the three-guarantee certificate and the issued invoice properly after purchasing the our product. The validity period of the three guarantees of the product will be calculated from the date you receive the product (hereinafter referred to as "receipt"), and the validity period of the three guarantees of the product is 12 months. Three Guarantees Service Content	1. Within 7 days from the date of receipt, to ensure that the received goods are in good condition, the product packaging and accessories are complete, and there is no performance failure caused by artificial damage, the payment for the goods can be refunded at one time according to the invoice price, or the products of the same model and specification can be replaced. or free maintenance. 2. From the 8th day to the 15th day from the date of receipt, if the product has a performance failure that is not damaged by human beings, the product of the same model and specification can be replaced. Product replacement is the responsibility of the seller. 3. Within the validity period of the Three Guarantees, if the product still cannot be used normally after two product replacements, and confirmed by the noise test, you can choose	to repair or replace the same model and the same specification with the valid replacement record provided by the seller in the Three Guarantees. product. Product replacement is the responsibility of the seller. How to Get Three Guarantees Service In order to ensure your legitimate rights and interests, you need to go to the seller of to enjoy the three-guarantee service. When you request the Three Guarantees service, you need to provide: 1. The original of the purchased product; 2. The original invoice when purchasing the product or the proof of purchase record from the seller; 3. A valid three-guarantee certificate.
---	---	---

Circumstances that are not covered by the warranty service • The product exceeds the validity period of three packs; • There is no Three Guarantees certificate and valid invoice, and it is impossible to prove that the purchased products are within the validity period of the Three Guarantees; • The warranty certificate does not match the product model identification or the warranty certificate has been altered; • Damage caused by not using, maintaining and maintaining according to the requirements of the "Instruction Manual", or using non-original accessories • Unauthorized repair, alteration, misuse, bump, drop, crush, liquid entry, corrosion;	• Tearing, altering or illegible product labels, seals and serial numbers (SN); • Damage caused by force majeure such as flood, fire, lightning strike; • Defects due to normal wear or normal aging of the product; Paid service guarantee If the product does not meet the warranty conditions and needs to be charged, will calculate the appropriate maintenance fee according to the cost of parts and labor, and propose a suitable maintenance quotation to you, after obtaining your consent and paying the fee for your product. Provide maintenance services.	Warranty Card <table><tr><td>Product name and model:</td><td>serial number:</td></tr><tr><td>username:</td><td>purchase date:</td></tr><tr><td>contact number:</td><td>Delivery date:</td></tr><tr><td>Address (including zip code):</td><td>Invoice number:</td></tr><tr><td colspan="2">Sales unit name:</td></tr><tr><td colspan="2">Sales unit address (including zip code):</td></tr><tr><td colspan="2">Sales unit telephone:</td></tr></table> *The above information is filled by the seller	Product name and model:	serial number:	username:	purchase date:	contact number:	Delivery date:	Address (including zip code):	Invoice number:	Sales unit name:		Sales unit address (including zip code):		Sales unit telephone:	
Product name and model:	serial number:															
username:	purchase date:															
contact number:	Delivery date:															
Address (including zip code):	Invoice number:															
Sales unit name:																
Sales unit address (including zip code):																
Sales unit telephone:																

FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to	radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction	SMART WATCH FT02 User manual The pictures are for reference only, please refer to the actual product (including but not limited to color, size, screen display, etc.)
---	--	---