

电动露营车

Electric campervan

说明书

Instructions



深圳市金宝冠科技有限公司
Shenzhen Jinbaoguan Technology Co., Ltd
工厂地址：深圳市龙华区观湖街道新田社区新棉路 66 号环通工业区厂房 D,E 栋 301
Factory address: Shenzhen Longhua District Guanhu Street Xintian Community
Xinzhang Road No. 66 Huantong Industrial Zone plant D, E building 301
联系电话：189 2527 5651 贺先生（微信同号）
Tel: 189 2527 5651 Mr. He (same number as WeChat)
售后电话：180 2533 3413 杨先生（微信：y18025333413）
After-sales Tel: 180 2533 3413 Mr. Yang (WeChat: Y18025333413)

规格型号

JBG2023-EV1pro

目录

directory

一、产品部件	-----	02
Product parts	-----	02
二、技术参数	-----	03
Technical data	-----	03
三、使用方法	-----	04
Application	-----	04
四、注意事项	-----	05
Precautions	-----	05
五、维护及保养	-----	05
Maintenance and maintenance	--	05

保修卡

Warranty card

用户姓名: User Name:	联系电话: Contact Number:	
购买方式: How to buy:	购买日期: Date of purchase:	
产品名称: Product Name:	产品型号: Product Model:	
通信地址:		
送修日期 Drop-in date	维修记录 Maintenance records	备注 remark

售后服务提示：为了更好的规范（JINBAOGUAN 跃科宝冠）品牌售后服务：
保修服务只限于正常使用；（整机、购买之日一年内）（配件、购买之日半年内）
一、必须提供此（保修服务卡）给予售后、
二、不管出于什么问题来回运费都由消费者自己承担、（注：本公司只提供符合
条件免费维修服务、如有未符合条件的均按正常维修收费标准收取）
三、车轮胎、外壳、铝件、踏板、装饰件等易损件（不在质保范围）
四、控制器、驱动、电机等进水或一切人为损坏、如自行改装、私自拆修、
使用不当碰撞、不提供无保修服务卡（都不在质保范围）
After-sales service tips: In order to better standardize (JINBAOGUAN brand after-sales service:
Warranty service is for normal use only. (Within one year from the date of purchase of the whole machine) (within half a year from the date of purchase of accessories)
First, this (warranty service card) must be provided to after-sales.
2. No matter what the problem, the round-trip freight shall be borne by the consumer himself.
3. Optional free maintenance service, if there is no eligibility, it will be charged according to the normal maintenance charging standard.
3. Wearing parts such as tire times, shells, aluminum parts, pedals, decorative parts (not covered by warranty).
4. Water ingress or all remote damage to controllers, drives, motors, etc., such as self-modification, unauthorized dismantling,
Improper use of collisions, no warranty service card provided (not covered by warranty).


四、注意事项（Notes）

1. 请仔细阅读说明书。超载或不正确折叠以及使用非核准附件都可能造成本产品损坏、故障或不安全。
Please read the instruction manual carefully. Overloaded or incorrectly folded and the use of non-approved attachments are acceptableCan cause damage, malfunction or unsafety of this product.
2. 本产品须由成人进行操作使用、小孩须在成人陪同下使用本产品。
This product must be operated by an adult, and children must be accompanied by an adult.
3. 当调整本产品上任何可活动部件时，必须确保肢体保持安全距离。
When adjusting any moving parts on this product, it is important to ensure that the limbs are kept at a safe distance.
4. 为避免指尖夹伤，收合及展开本产品时务必小心。
To avoid pinching your fingertips, be careful when closing and unfolding this product.
5. 使用时请远离火源、高温、水池或电源附近，保持安全范围。过度暴晒易导致本车老化或变形，请尽量避免暴晒，雨淋
When using, please keep away from fire, high temperature, pool or near the power supply, and maintain a safe range, pass
Exposure to the sun can easily lead to aging or deformation of the car, please try to avoid exposure to the sun and rain
6. 放置物件前，确保本产品完全展开。
Make sure the product is fully unfolded before placing the object.
7. 请勿将小孩放置在本车内。
Please do not leave children in this vehicle.
8. 禁止在楼梯上使用本产品。
It is forbidden to use this product on stairs.
9. 不可将本产品放置马路、坡道或危险场所。
Do not place this product on roads, ramps or hazardous locations.
10. 请勿允许婴幼儿将本产品当玩具使用。
Do not allow infants and toddlers to use this product as a toy.
11. 当发现本产品损坏时，应立即停止使用。
When this product is found to be damaged, use should be stopped immediately.

五、维护及保养（Maintenance and maintenance）

1. 请使用（35℃以下）清洗布套，不可用漂白剂及化学剂等。
Please use (below 35℃) to clean the cloth cover, do not use bleach and chemical agents.
2. 定期检查是否有螺丝松动、零件损坏或缝线断裂，如有必要请及时更换。Regularly inspect for loose screws, damaged parts, or broken stitches, if necessary Replace in time.
3. 电池不能长时间充电超过 8 小时，必须在有人监管条件下充电
The battery cannot be charged for more than 8 hours for a long time and must be charged under supervised conditions
4. 电池在不使用时三个月内必须给电池补充电、
The battery must be recharged within three months when not in use
5. 本产品尽量放在干燥的地方贮存
Store this product in a dry place as much as possible

一、产品部件说明（Product part description）



特别申明：本产品如因产品技术升级、外观更改、功能优化等更变、请以实物为准。

Special statement: this product due to product technology upgrades, appearance changes, For changes such as function optimization, please refer to the actual product

二、技术参数（Technical parameters）

产品名称；电动露营车
Product Name ; Electric campervan
工作电压：24v
Working voltage: 24V
电池容量：125wh
充电电压：29.6v
Battery capacity: 125Wh
充电电流：2ah
Charging current: 2ah
电机功率：250w*2
Motor power: 250W*2
续航能力：20km
Cruising range: 20km
爬坡能力：20 度
Climbing ability: 20 degrees
制动方式：电子刹 + 机械脚刹
Braking method: electronic brake + mechanical brake
工作温度：-10~50℃
Working temperature: -10~50℃
储存温度：-15~45℃
Storage temperature: -15~45℃
整机净重：15kg
Net weight: 15kg
包装毛重：17kg
Packing gross weight: 17kg
最大承载：150kg
Maximum load: 150kg
整车尺寸：90cm*50cm*60cm
Vehicle size: 90cm*50cm*60cm
包装尺寸：65cm*65cm*30cm
Packing size: 65cm*65cm*30cm
适用地形：硬化路面/草地/沙滩/石子路面/
Applicable terrain: hardened pavement / grass / beach / gravel pavement /

三、使用方法（How to use）

1. 车子从箱里面取出展开
The car was taken out of the box and unfolded
2. 电池安装
Battery mounting
3. 先按驱动开关、再按把手开关
Press the drive switch first, and then press the handle switch
4. 按档位键确认功能
Press the gear key to confirm the function
5. 握住把手拨动指拨键前后学习
Hold the handle and move the finger keys back and forth to learn
6. 手机打开 APP 小程序连接蓝牙
(一) 进入界面显示电量速度温度
(二) 可以根据自己习惯调整参数
(三) 遥控控制车子前后左右行驶
(四) 安全锁车与解除功能
(五) 系统优化升级补丁漏洞
6. Open the APP applet on the mobile phone and connect it to Bluetooth
(1) Enter the interface to display the battery speed, temperature
(2) You can adjust the parameters according to your own habits
(3) Remote control of the car to drive forward, backward, left and right
(4) Safe locking and discharging functions
(5) System optimization and upgrade patch vulnerabilities