U1

USER GUIDE



Waterless | Heatless | Mold-free

01 Overview

Thank you for choosing our smart scent diffuser.
It works with the Sleekpoint app via Bluetooth connectivity.

Our advanced cold diffusion technology converts essential or fragrance oils into nano-vapor particles (approximately 1-3 microns) without using heat or water. This process preserves the molecular structure of the oil, maintaining its therapeutic properties for easier absorption into the body. It's a cleaner, safer, and more efficient way to diffuse.


It can effectively scent areas up to 1200 sq. ft. | 120 m^2, making it suitable for both residential and commercial use, including homes, offices, hotels, cafes, libraries, and more.

Compatible with most essential and fragrance oils, you have the freedom to choose from a wide range of fragrances to create your desired atmosphere: calming, relaxing, or invigorating. Using sanitizing oils can also help eliminate odors and purify the air.

02 Cautions


- **DO NOT** invert or tilt the device once the oil bottle is installed.
- **DO NOT** use resin or thick oils such as Agarwood, Camphor.
- **DO NOT** mix your oil with water when the device is in use. This will cause failing to atomize (mist not visible).
- **DO NOT** attempt to disassemble the device. If the mist output reduces noticeably, please clean the diffuser according to our instructions.
- For more quiet use, ensure the device is **10 feet away**.
- Keep the device away from children and pets. The thicker the oil, the less diffusing capability.
- Optimal Working Temperature: -5°C / 40°C (23°F / 104°F) Suggested room size: **100 - 1500 sq. ft. | 10 - 150 m^2**
- **DO NOT** use other items as replacement parts for this product.
- **DO NOT** use the unit if the cord has been damaged.
- **DO NOT** operate with power cord coiled or with twist tie in place.
- **DO NOT** handle the power cord or plug with wet hands. Keep the plug and power cord away from liquids.
- **DO NOT** attempt to repair or adjust any electrical or mechanical functions on this device. Doing so will void your warranty.

03 Specifications



Max. Oil Capacity	120 mL | 4 fl. oz.
Input	DC 12 V ⎓ 1 A
Rated Power	6 W
Size	103 x 308 x 103 mm 4.1 x 12.1 x 4.1 in
Net Weight	750 g | 1.65 lb

What's in the Box




Smart Scent Diffuser Set

Power Adaptor


User Guide

04 Installation



05 Setup

Getting ready



1 Lift the nozzle set out.

2 Turn to remove the oil bottle.


3 Fill the bottle with your desired oil.

4 Tighten the oil bottle to the nozzle to prevent leaks, and then insert the nozzle set to the device in right direction.

CLEANING THE DIFFUSER

⚠ Clean the diffuser at least once a month.





1. Empty the bottle and fill in 30 mL of 90% or greater ethanol/ ethyl/ isopropyl alcohol. Ensure the bottle is tightened.
2. Create a "Cleaning" schedule in the Sleekpoint App. Set "Diffuses for" to 35 seconds, and " Pauses for" to 60 seconds.
3. Run the device based on the above schedule for 15 minutes.
4. Empty the bottle and fill in your oil.

Got a problem with your product or experience?

Don't return it yet
- just give us a shout.
We're here to make it right for you.



⚠ **For best results, use Essential or Fragrance Oils only.**

Customer Service
SCAN ME


Video Guide
YOUTUBE

www.airversa.com

support@airversa.com

Add your device to the Sleekpoint app

01 Connect the power adapter to the device. Plug the adapter to a standard AC outlet.
You will hear a beep.



02 Go to Apple App Store or Google Play and search for "Sleekpoint". Download and open the Sleekpoint app.



Sleekpoint


Download on the App Store

GET IT ON Google Play


iOS App

Android App

03 Locate and tap the " ⊕ " button, and then choose "**AIRVERSA U1**".



04 Enter the default activation key "**8888**" (you can change this key later on in "settings"). > Setup completed.




Factory Reset

Press & hold the knob for 5 seconds until you hear a beep. All settings will be cleared.

06 Warning



Place the device on a clean, flat surface.
Improper placement of the diffuser when an oil bottle is installed might cause oil leakage (e. g. when the unit is tilted at an angle larger than 45°).



Auto-off 45° Spill-protection
If the unit is tilted beyond 45°, it will power off automatically. It will only restart after being placed upright for at least 5 seconds.

07 Troubleshooting

Issues	Analysis
Not diffusing/ No mist/ Mist barely visible	• Ensure the device is powered on. • Ensure the bottle is tightened. • Check if the pump has stopped operating, or it is making unusual noise. • Place your finger near the air outlet and feel for airflow. If you can feel it, contact us for a nozzle replacement. • Nozzle might be clogged by residue. • Clean the device following the cleaning instructions. If this issue remains, contact us for a nozzle replacement.
Oil Leaks	• The device might be angled, inverted or tilted. • Ensure it is placed on a clean, flat surface.
Abnormal Motor Noise	• Ensure the oil bottle is fully tightened to the nozzle. • The seal ring within the nozzle might be absent or lost. Contact us for a seal ring replacement. • The pump might be damaged. Contact us immediately.

Read all the instructions before using the product.

1. Use the Product in the environment with the temperature Between-10°C and 50°C.
2. The appliance is only to be used with the recommended vaporizing medium. The use ofother substances may give rise to a toxic or fire risk.
3. This appliance is not intended for use by persons (including children) with reducedphysical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
4. Children should be supervised to ensure that they do not play with the appliance.
5. The appliance can only be used in conjunction with the power supply device withwhich the appliance is e quipped.
6. The appliance s hould only use the safe ultra-low voltage power supply specified bythe appliance to prevent failure.
7. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
8. The appliance can only be powered by the specified voltage of the product, otherwise there is a safety risk
9. Do not tamper with the original operating device and function of the appliance.

08 FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Not applicable

RF Exposure
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

09 ISED Statement

English: This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES-3 (B)/ NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.
l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).
This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.
This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.
Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.
This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.