Outdoor Eaves Light

Plese read this manual carefully before using the product,and keep if for records properly

INSTALLATION STEPS

Installtion Steps

1. Before installing the string downlight, please connect the power supply to the string downlight,correctly,then turn on the power and check whether all equipment is working properly (eitherend of the lamp can be connected to the power supply).

   Note: Connect the lamp to the power supply first, and then power on for testing.



2. Clean the surface of the installation area with a rag or paper towel to ensure that it is dry and free of debris.

   Note: Only for indoor installation.



3. Please use the back adhesive in the accessory bag, peel off the surface layer on the back, and stick it on the back or top of the permanent downlight according to your needs. It is recommended to align the light tightly with the edge of the fixture at right angles to the wall, and then press it firmly to stick it securely. It can also be installed and fixed with screws.



4. After the installation is completed, you can use the wire clip provided in the accessory packageto fix the wire at the tail of the downlight.



PRODUCT PARAMETER

Model	W20
Product Size	42x30mm
Input Voltage	DC 24V
Lamp Power	1W
LED Type	5054RGB+2835LED
LEDs Number	7
Color Temperature	RGB Addressable 2700K–3300K; 5000K–6500K
Waterproof Grade	IP67
Shell Body Material	PC
Beam Angle	≥120°
Lifespan	≥50000h

INSTALL THE "SMART LIFE - SMART LIVING" APP

1. Find and install the "Smart Life - Smart Living" App on Apple Store, Google Play.

2. Agree User Agreement and Privacy Policy.
   Register a "Smart Life - Smart Living" account.



3. Turn on Wi-Fi & Turn on Bluetooth

STEPS

1. Advised to enable Bluetooth, Enable Bluetooth to add some Wi-Fi device easily;

2. Ensure that the device is connected to a power source, and follow the instructions in the product manual to set it to the configuration mode. Under normal circumstances, unconfigured devices will automatically enter this mode upon powering on for the first time.

3. If the automatic setup is unsuccessful, you can manually add the device.

HOW TO CONNECT REMOTE CONTROLLER

Step1: Advised to enable Bluetooth,Enable Bluetooth to add some Wi-Fi device easily;

Step2: Each time the device without distribution network is powered on, confirm the light is breathing or blinking pairing mode;

Step3: Open the "Smart Life-Smart Living" App, In the top corner of the Devices screen, click "+" and select "Add Device" to confirm that the device is paired.
If not, you need long press button 5s confirm the light is blinking.

Step4: Find the device, choose Wi-Fi and enter password,press "Next",Click "Add", and wait patiently. After that, click "Done", and the device is successfully added to the App.

Step5: Other ways to add devices,Open the "Smart Life-Smart Living" App>>In the top corner, click "+">> Choose "Lighting">>Select "Light Source (BLE + Wi-Fi)"

APP FUNCTIONS

When you enter the App, you can see five sections: On/Off, Colour,Scene, Music, Plan. Detailed function description please check below:

1. **On/Off.** Analog key switch, control the switch of the whole set of Eaves lights.



2. **Colour.** After the successful connection, enter this Colour UI page by default. This UI page is with 2 icons and 1 digital display.

- Select all colors / Select single colors
- Clear individual colors
- Number of LED lights

3. **Scene.** It has 44 different scene mode. Supports DIY 50+ scenes, edit your favorite scenes.
   (Note: When you're done editing, be sure to preview and click Save. Next time you open this page, the DIY scene will also be saved.)

4. **Music.** The music can trigger the lights to flash through both the product's MIC and the phone's MIC.



5. **Plan.** The owner can freely set the on/off time of the stringlight every day.

REMOTE CONTROL



The remote control can control both networked and non-networked lights.

1. When the light is not networked & networked, you need to turn off the power of the device for 5 seconds, then turn on the power of the light again and press the on/off button, the light appears to breathe or blink to complete the pairing.
2. If the pairing is not successful, please repeat the steps.



- **Power/Function Button:**
  Long press for 3-5 seconds to enter breathing pairing mode; double-click to turn off; short press to turn on; short press to cycle through modes: R-G-B + WW + CW + Christmas + Thanksgiving + Halloween + Football Day + Wind Chimes + Gaming + Holidays + Dreamy Meteor + Colorful Marbles + Neon World.
- **Microphone:**
  Equipped with power-off memory function, which remembers the color and color temperature before power loss. In pairing mode, key operations are allowed to interrupt the pairing display and enter the corresponding functions associated with the keys.

TROUBLESHOOTING

1. Can't connect to your Wi-Fi network.Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

2. If you fail to bind, you will need two phones, one to set the hotspot and the other to connect the hotspot and add the device through the app. If the device is successfully added, the device is normal. The problem may be in the router, you need to check your router Settings to see if there are MAC and DHCP restrictions. The products do not support 5GHz networks.

NOTES

Detailed operation instructions, Enter the menu: "Guide" Security Information

1.The lighting fixtures are available for indoor and outdoor use.
2.Risk of electric shock.
3.The power adapter and controller should not be exposed to liquids, steam, or rainwater.
4.Stay away from open flames.
5.Avoid rough installation surfaces and ensure that the surface is clean and dry before installation.

CAUTION

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:
(1) this device may not cause harmful interference, and (2) this device must acceptany interference received, including interference that may cause undesiredoperation.Changes or modifications not expressly approved by the partyresponsible for compliance could void the user's authority to operate theequipment.

NOTE: This equipment has been tested and found to comply with the limits for aClass B digital device, pursuant to part 15 of the FCC Rules. These limits aredesigned to provide reasonable protection against harmful interference in aresidential installation.This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with theinstructions, may cause harmful interference to radio communications. However,there is no guarantee that interference will not occur in a particular installation. Ifthis equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user isencouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to whichthe receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC RF exposure statement

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.

Outdoor Eaves Light