







11AC80SISO-Ant1-5610-30~5460-PASS




11AC80SISO-Ant1-5610-5735~40000-PASS




11AC80SISO-Ant1-5775-30~5650-PASS




11AC80SISO-Ant1-5775-5925~40000-PASS




11AX20SISO-Ant1-5180-30~5140-PASS




11AX20SISO-Ant1-5180-5360~40000-PASS




11AX20SISO-Ant1-5200-30~5140-PASS




11AX20SISO-Ant1-5200-5360~40000-PASS




11AX20SISO-Ant1-5240-30~5140-PASS




11AX20SISO-Ant1-5240-5360~40000-PASS




11AX20SISO-Ant1-5260-30~5140-PASS




11AX20SISO-Ant1-5260-5360~40000-PASS




11AX20SISO-Ant1-5280-30~5140-PASS




11AX20SISO-Ant1-5280-5360~40000-PASS




11AX20SISO-Ant1-5320-30~5140-PASS




11AX20SISO-Ant1-5320-5360~40000-PASS




11AX20SISO-Ant1-5500-30~5460-PASS




11AX20SISO-Ant1-5500-5735~40000-PASS




11AX20SISO-Ant1-5580-30~5460-PASS




11AX20SISO-Ant1-5580-5735~40000-PASS




11AX20SISO-Ant1-5700-30~5460-PASS




11AX20SISO-Ant1-5700-5735~40000-PASS




11AX20SISO-Ant1-5745-30~5650-PASS




11AX20SISO-Ant1-5745-5925~40000-PASS




11AX20SISO-Ant1-5785-30~5650-PASS




11AX20SISO-Ant1-5785-5925~40000-PASS




11AX20SISO-Ant1-5825-30~5650-PASS




11AX20SISO-Ant1-5825-5925~40000-PASS




11AX40SISO-Ant1-5190-30~5140-PASS




11AX40SISO-Ant1-5190-5360~40000-PASS




11AX40SISO-Ant1-5230-30~5140-PASS




11AX40SISO-Ant1-5230-5360~40000-PASS




11AX40SISO-Ant1-5270-30~5140-PASS




11AX40SISO-Ant1-5270-5360~40000-PASS




11AX40SISO-Ant1-5310-30~5140-PASS




11AX40SISO-Ant1-5310-5360~40000-PASS




11AX40SISO-Ant1-5510-30~5460-PASS



11AX40SISO-Ant1-5510-5735~40000-PASS



11AX40SISO-Ant1-5550-30~5460-PASS



11AX40SISO-Ant1-5550-5735~40000-PASS