

产品型号	G117
蓝牙版本	5.3
传输半径	10米
音乐时间	约4小时
充电接口	TYPE-C
充电时间	约1.5小时

1. 打开充电仓，L/R耳机自动进入蓝牙配对模式，等待连接。
2. 打开手机上的蓝牙，搜索设备名G117，点击进入连接。
(语音提示：L/R耳机连接提示音)

1. 用一只手按住耳朵，把耳机挂在耳朵上。
2. 旋转调整耳机喇叭位置，上下移动直到耳机完全贴合耳朵的轮廓。
3. 注意区分L/R的佩戴位置，如果拿反则佩戴不上去。

待连接状态
耳机红灯跟蓝灯交替快闪

[illegible]

请勿在移动使用BLUETOOTH®设备使用场所而定, 使用可能引起移动设备无法工作。

请勿在下列场所使用BLUETOOTH®设备, 可能会妨碍您的听力, 为了交通安全, 请勿在驾车或骑行时使用车机系统。

请勿在以下场所使用车机系统造成危险或妨碍他人使用:

- 铁路交叉点、火车站台、行人横道及建筑工地。
- 请勿在本机未上电时随意增加重量, 否则可能会导致本机在长期存放中发生变形。

体内植入医疗设备可能会导致设备操作错误, 穿着天然材料制成的衣服, 可防止衣物静电。

请勿将耳机靠近医疗设备。

请勿使用柔软的材料包裹耳机。

请勿让耳机暴露在水中, 耳机并不防水, 切勿尝试遵守以下预防措施。

- 当心不要让耳机落入洗澡池或其他热水的水中。
- 如果在潮湿的环境下使用车机系统, 如雨天驾车时使用。

如果使用未经认证的蓝牙耳机后遇到卡顿, 请立即停止使用BLUETOOTH®设备, 如果问题仍然存在, 请联络您的经销商。

如果有任何关于本产品的任何问题或疑虑, 而本说明中未涵盖, 请联系您的经销商。

本产品在使用过程中如果出现故障,我们将按照如下程序进行处理:

2. 此次产品故障发生及维修事宜,如出现以下情况,即使保修期已过,我们也将提供免费维修:

(1) 如果是有不可抗力因素,且该情况也已取得证明;

(2) 如果产品超过保质期时间,发生故障而进行维修或更换;

(3) 说明(使用说明书)中说明的注意事项等正常使用;

(4) 其他因造成设备故障的设备故障、损坏,或者由于使用不当造成的故障损坏。

(5) 因火灾、地震、火灾、水灾、电压异常等造成的故障损坏;

(6) 其他意外造成损坏零件,更换零件;

3. 可用时间零件或零件进行维修。此外,维修更换的零件和我们的售后服务。

因此,我们使用本产品造成损失,我们将不予赔偿。

保修条款:

本产品自购买之日起,享有的一年保修期。

原产品的故障发生时,本保修保证书及有效销售凭证,符合下列条件时即可保修:

1. 您的设备必须按照产品使用说明书正确使用;

2. 本保修卡不适用于人为、意外(火灾、外力挤压、坠落等)或者自然灾害(地震、台风、雷电等)所致的故障或损坏等。

3. 本保修卡遗失后不再补发, 请和销售凭证一同妥善保管。

产品名称:	
型号:	
购买时间:	
姓名:	
联系电话:	
购买地点:	
经销商名称及地址:	

请将此凭证妥善保管。若您的设备需要售后服务, 请联系您所购设备的经销商。

警告:

必须将设备与AC电源正确连接, 避免造成以下两个条件:

- (1) 本设备会产生高压电击, 并可能 (2) 本设备会造成损坏或损坏任何软件。

本设备可能因使用不当而损坏, 并可能因使用不当而造成人身伤害或财产损失。

注意: 本设备及其附件, 由安全警告符号, 由安全警告符号, 由安全警告符号。

这组符号在住宅和商业环境中用于提醒用户必须遵守的规则。

可能产生火灾或爆炸危险。必须不得违反规定的警告。

请仔细阅读并严格遵守以下警告。然而, 不得违反在规定的警告中不遵守安全警告。

本设备可能因使用不当而损坏, 并可能因使用不当而造成人身伤害或财产损失。

警告符号形式通过以下一种或多重符号来指示安全警告:

- 可能产生火灾或爆炸危险
- 可能导致人身伤害或财产损失
- 可能导致设备损坏或损坏任何软件

注意: 本设备及其附件, 由安全警告符号, 由安全警告符号, 由安全警告符号。

注意: 本设备及其附件, 由安全警告符号, 由安全警告符号, 由安全警告符号。

警告符号在住宅和商业环境中用于提醒用户必须遵守的规则。


可能产生火灾或爆炸危险。必须不得违反规定的警告。

请仔细阅读并严格遵守以下警告。然而, 不得违反在规定的警告中不遵守安全警告。

本设备可能因使用不当而损坏, 并可能因使用不当而造成人身伤害或财产损失。

警告符号形式通过以下一种或多重符号来指示安全警告:

- 可能产生火灾或爆炸危险
- 可能导致人身伤害或财产损失
- 可能导致设备损坏或损坏任何软件



Model	G117
Bluetooth version	5.3
Transmission Radius	10M
Music time	About 4 hours
Charging interface	TYPE-C
Charging time	About 1.5 hours

1. Open the charging bin, U/R headphones automatically enter Bluetooth pairing mode, waiting for connection.
2. Open the charging bin, U/R headphones automatically enter Bluetooth pairing mode, waiting for connection.

1. Hold Your Ear with one hand and hang the headset over your ear.
2. Rotate the headphone horn and move it up and down until the headphone fits the ear contour perfectly.
3. Pay attention to distinguish L/R wearing position, if the reverse will not wear up..

The headphones flash red and blue lights alternately

[illegible]

1. Depending on the condition of the radio waves and the location where the BLUETOOTH device is used, it may not work on mobile phones.
2. Listening to this earphone at high volume may affect your hearing. For traffic safety, please do not use this earphone while driving or cycling.
3. Do not touch the earphone with your hands. Excessive pressure on the earphone, environmental sound can cause danger, such as railway interferences, train station platforms, pedestrians crossings, and construction sites.
4. Do not place the earphone in a container that is not designed for this earphone, as may cause deformation during long-term storage.
5. The accumulation of static electricity in the body may cause slight ear pain. Wearing clothes made of natural materials can minimize the impact.
6. Do not touch the earphone with your hands.
7. Please use a soft cloth to clean the headphones.
8. Please do not expose the headphones to water. The headphones are not waterproof.
9. Do not throw the earphone into the fire. Do not throw the earphone into the sink or other containers containing water.
10. Do not use headphones in damp areas or harsh weather, such as rain or snow.
11. If you've used unear after using the BLUETOOTH device, please immediately stop using the BLUETOOTH device. If the problem persists, please contact your local distributor.
12. If you have any questions or concerns about this earphone that are not covered in this manual, please contact your local dealer.

If the product breaks down during the warranty period, we will carry out the maintenance free of charge according to this manual:

This document can be re-issued please take good care of it. If the product is damaged due to the following reasons, the following circumstances will be charged:

(1) If no warranty card is shown (2) If the purchase date can not be confirmed

(3) If the product exceeds the warranty time, the fault occurs and the cause is not confirmed

(4) misuse (according to the normal use of the instructions and other relevant documents)

(5) Failure of damage to equipment due to other causes, or failure or damage due to improper maintenance or modification (6) fire, lightning, flood, lightning or other natural disasters, pollution, salt, abnormal voltage caused by such factors or damage caused by other reasons

(7) Replacement of parts

3. Remanufactured parts or replacement parts can be used for maintenance. In addition, repair and replacement of old parts and wear parts are not included in the warranty.

We shall not indemnify you for the loss caused by failure to use this product.

Warranty:

Product warranty:

Warranty period: from the date of purchase, effective is one-year warranty period.

Warranty products: In the repair certificate and valid sales certificate, it is accordance with the following terms can be warranty.

1. Your equipment must be used correctly according to the instructions.

The warranty card is not applicable to faults or damages caused by human activities, accidents, external fire, abnormal falling, etc. or natural disasters (earthquake, typhoon, lightning, etc.). The warranty card will not be issued after it is lost. Please properly keep it together with all touches.

Product name:	
Model:	
Purchase time:	
Full name:	
Contact number:	
Place of purchase:	
Store name and address:	

Please keep this voucher properly. If your equipment needs warranty service, please contact the dealer of the equipment you purchased.

WARNING: This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) it must accept any interference that it may receive. This device includes the following features to help prevent harmful interference, including interference that may cause undesired operation of other devices:

- This device uses frequency hopping to help minimize interference to other devices, and unlicensed devices must be able to co-exist with licensed devices.
- This device cannot be used in areas where licensed operations are responsible for compliance could void the user's authority to operate the equipment.
- This device cannot be used near or in the immediate vicinity of licensed limits for Class 1 digital device, pursuant to Part 15 of the FCC Rules.

These Class 2 devices are designed to provide reasonable protection against harmful interference when they are properly installed and used in accordance with the following instructions:

- Do not install this device near or in the immediate vicinity of sensitive equipment, and can radiate radio frequency energy and, if not installed and used in accordance with the following instructions, may cause interference to radio communications. However there is no guarantee that interference will not occur in a particular installation.
- If you experience interference while using this device, you should attempt to reorient or relocate the receiving antenna.
- If the equipment does cause harmful interference to radio or television reception, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a different electrical outlet, one that is not on the same circuit as the receiver is connected.
- Consult the dealer or a qualified radio/television technician for help.

NOTE: This device and its antenna(s) must NOT be co-located or operated near power lines, power cables, or other electrical equipment.

The device has been evaluated to meet general RF exposure requirement. The device has been evaluated exposure condition without restriction.