

User Manual

Wireless Keyboard



Low-profile Mechanical
Quiet Keys



3-channel Multi
-OS Connectivity



Type-C
Rechargeable

CUQ01

EN


Product Warranty

All Seenda products come with a 24-months warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.


Our email: **support@seenda.com**

Our website: **www.seenda.com**


Product Features




Keyboard Bluetooth Connection



1. Turn on the keyboard.




2. Press the Bluetooth **F1** / **F2** you want to connect, white light flash once, the keyboard enter Bluetooth mode.
Press and hold the selected channel key for 3-5 seconds, white light flash quickly, the keyboard enter pairing mode.



3. Turn on the Bluetooth settings on your device, search or select "SEENDA CUQ01 KB" and start Bluetooth pairing until the connection is completed.


Mode Switch Method

Mouse



After BT1 | BT2 |  are connected, short press channel switch button on the bottom of the mouse, easily switch between multiple devices.


Keyboard



After  |  |  are connected, short press the channel key on the keyboard, easily switch between multiple devices.

Charging Guide

1. When the battery is low, the low battery indicator light on the keyboard or mouse will rapidly flash to indicate low power.
2. Insert the Type-C port into the mouse or keyboard and the USB-A port into the computer to charge, the red light stays on while charging.
3. The indicator light turns off when fully charged.



Notice:

If the mouse or keyboard is low battery, there will be delays, freezes and other problems. Please connect to the power supply for charging in a timely manner to ensure that the mouse or keyboard has sufficient battery power to get normal performance.

Keyboard Multimedia Function Keys

Keys	Windows	Android	iOS	Mac OS
	Light -	Light -	Light -	Light -
	Light +	Light +	Light +	Light +
	Window Switch	Window Switch	/	Multi-window Preview
	Multi-window Preview	/	Application Switch	Application Switch
	Show Desktop	/	/	Show Desktop
	Search	Search	Search	Search
	Previous Track	Previous Track	Previous Track	Previous Track
	Play & Pause	Play & Pause	Play & Pause	Play & Pause
	Next Track	Next Track	Next Track	Next Track
	Mute	Mute	Mute	Mute
	Volume -	Volume -	Volume -	Volume -
	Volume +	Volume +	Volume +	Volume +
	FN+ESC (FN lock) button to turn on or turn off the FN function			

Note: The FN function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).

How to Use Special Characters in British English

On MacOS/iPadOS/iOS system:

Press the key and you can type the symbol shows in the right square frame.

	§		2
	\		/
	\		

Press and hold the key "Shift", then press the corresponding key, you can type the symbol shows in the right square frame.

	±		@
			""
	~		

Press and hold the key " , then press the corresponding key, you can type the symbol shows in the right square frame



€

On Windows/Android system:

Press the key and you can type the symbol shows in the right square frame.



\



2



#



/



\

Press and hold the key " , then press the corresponding key, you can type the symbol shows in the right square frame.



[




”




~



@



Press and hold the key " " (the key on the right side of the keyboard), then press the corresponding key, you can type the symbol " | " and " € ".



Product Specifications

Keyboard Parameters

Operating Voltage	3.7V
Working Current	4 mA
Sleep Current	20 uA
Standby Current	0.1 mA
Standby Time	300 Days
Continuous Working Time	100 Hours
Wake Up Way	Click any key to wake up
Keyboard Size	434.3*137.7*27.2mm/17.1*5.4*1.1in
Keyboard Weight	655g/1.4lb

Sleep Mode

1. When the keyboard stops working for 30 minutes, it will automatically enter the sleep mode for energy saving.
2. When use the keyboard again, you only need to hit any key, and the keyboard will wake up within 3 seconds.
3. The channel key indicator light will turn on again and start working.

Memory Function

The keyboard has a memory function. When a channel is connected normally, the keyboard defaults to this channel after turning off the device and turn back on, and the channel key indicator lights up.

Package Content

- ▶ 1 * Wireless Keyboard
- ▶ 1* Type-C Charging Cable
- ▶ 1 * USB Receiver
- ▶ 1 * User Manual

Frequently Asked Questions

How to deal with disconnection issues, keys repeating or typing & clicking delay?

- Please ensure that the keyboard/mouse is fully charged. A low battery can affect the performance of the keyboard/mouse.
- If using a USB dongle to connect the keyboard/mouse to the device, unplug and replug the USB dongle, trying a different USB port if necessary.
- If connecting the keyboard/mouse to the device via Bluetooth, delete the Bluetooth name from your device's Bluetooth connection list, and restart your device and re-pair the keyboard/mouse by following the steps in the user manual.
- If the issues persist, try to connect the keyboard/mouse to other devices to check if the same issues occur and don't hesitate to contact our customer service for assistance.

How to deal with keyboard/mouse won't turn on or stops working?

- The rated charging voltage for the keyboard and mouse is 5V. It is recommended to use the computer's USB port for charging.
- Try to change another Type-C cable to confirm whether it is a cable issue or a fault with the keyboard and mouse.
- If the power indicator of the keyboard/mouse does not light up at all, please do not hesitate to contact our customer service for assistance.

How to deal with cracked keyboard edges or dropped keys?

- If this happens and it cannot be recovered, please do not hesitate to contact our customer service for assistance.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

-  **Charging Safely:** Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.
-  **Battery Handling:** Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.
-  **Heat Exposure:** Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
-  **Liquid Exposure:** Keep the item away from water and liquids. Do not use if wet until thoroughly dried.
-  **Damage and Leakage:** Cease usage and consult customer service if the item is damaged or the battery leaks.
-  **Correct Disposal:** Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
-  **Radio Frequency Interference:** This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
-  **Child Safety:** Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

EU Declaration of Conformity

Declared Object: Wireless Keyboard
Model: CUQ01
Rating: Keyboard: 3.7V $\approx$ 4mA
Mouse: 3.7V $\approx$ 6mA
Place of Production: Made in China
Manufacturer: Dongguan Lingjie Electronics& Technology Co., Ltd
E-mail: andymo@szforter.com
Address: Building 3, No.23, Zhenxing North Road, Taiyuan,
Xiegang Town, Dongguan City, Guangdong Province,
China, 523590

European Representative:



Business name: g.L.L. GmbH
Business address: Bauernvogtkoppel, 55c, 22393, Hamburg, Germany
Email: g.L.L.DE@outlook.com



Business name: AMANTO INTERNATIONAL TRADE LIMITED
Business address: The Imperial, 31-33 St Stephens Gardens,
Notting Hill, London, United Kingdom, W2 5NA
Email: AmantoUK@outlook.com

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position: Managing Director

Signature:

Andy Mo

Date of Sign: 2022.1.5

EU agent name:

Tong Jia

Date of Sign: 2022.1.5



尺寸：105x148.5mm

折页方式：骑马钉 128g铜版纸

专色



#A7E800

R167 G232 B0

C39 M0 Y90 K0

PANTONE 2290C