

06.11.01.2268

N65Y/乐巢SEENDA/MOU101/说明书 尺寸60x100mm展开120x100mm 材质100克书写纸, 单黑双面印刷
26P+2P空白页骑马钉 空白页留后面两页 (删除充电警告)

SEENDA

2.4G USB + BT Dual Mode
Wireless Mouse
User Manual

MOU101

All Seenda products come with a 12-months warranty policy. Please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.

Our email: support@seenda.com
Our website: www.seenda.com

Product Features

A

B

C

D

E

F

G

H

I

J

A Left Button

B Right Button

C Scroll Wheel

D DPI Button

E Bluetooth Indicator

F USB Indicator

G Mode Switch Button

H Battery Storage

I Power Switch

J USB Receiver

2.4G wireless connection

1

2

3

4

Bluetooth Connection

1

2

3

4

Windows 10 System (Mouse)

4

5

6

7

8

Mac Os System (Mouse)

1

2

3

4

5

6

7

IOS System (Mouse)

6

7

8

9

10

11

Android System (Mouse)

4

5

6

7

8

Product Specifications

Engine	Optical
Mouse DPI	800/1200/1600 DPI
Mouse Keystroke Life	More than 3 million
Operating Voltage	1.5V
Weight	62g
Mouse Size	108*63*39.1mm

2.4G Transmission Specifications:

Transmission Distance	10m
Working Voltage	1.5V
Working Current	10mA
Return Rate	125Hz
System Requirements	An available USB port; Windows XP, Windows 7/8/10 or higher; Mac OS X 10.10 or higher;

Bluetooth Transmission Specifications:

Transmission Distance	10m
Working Voltage	1.5V
Working Current	15mA
Return Rate	115Hz
System Requirements	Bluetooth enabled devices; Windows 8/10 or higher; Mac OS X 10.10 or higher; Android 4.3 or higher;

Sleep Mode

When the mouse are not used for more than 30 minutes, the will automatically enter the sleep mode. Press any button of the mouse, the will wake up in 3-5 seconds, and you can use the mouse again.

Warm Reminder

1. If the mouse fails to connect properly to your device, you can troubleshoot by taking the following steps: power off the mouse, power it on again, restart the Bluetooth functionality on your device, and then attempt to reconnect. Alternatively, you can remove any redundant Bluetooth entries from your device's connection list before establishing a new connection.
2. To switch to a successfully connected channel, begin by pressing the channel button, waiting for 3 seconds, and then continue with your usual operations.
3. The mouse is equipped with a memory function that automatically reverts to the last connected channel when the device is powered off and then back on. The channel indicator will stay illuminated to indicate the active connection.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.
Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.
Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.
For further assistance or information, please contact our customer service.
Email: support@seenda.com

EU Declaration of Conformity

Declared Object:

Model:

Rating:

Place of Production:

Manufacturer:

Email:

Address:

European Representative:

Position:

Signature:

Date of Sign:

EU agent name:

Date of Sign:

FCR Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference from the unauthorized operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment uses frequency modulation (FM) and may cause interference with other electronic equipment. If you experience interference, you may need to increase the distance between the equipment and the equipment causing the interference. If the interference persists, you may need to consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable operation without additional restrictions.

SEENDA

2.4 G USB + BT Dual-Modus
Kabellose Maus
User Manual

MOU101

Alle Seenda-Produkte werden mit einer 12-monatigen Garantie geliefert. Bitte zögern Sie nicht, uns zu kontaktieren, wenn Sie Fragen haben. Unser Support-Team wird unser Bestes geben, um Ihnen ein angenehmes Einkaufserlebnis zu bieten.

Unsere E-Mail: support@seenda.com
Unsere Website: www.seenda.com

Produktmerkmale

A

B

C

D

E

F

G

H

I

J

A Linke Taste

B Rechte Taste

C Scrollrad

D DPI-Taste

E Bluetooth-Anzeige

F USB-Anzeige

G Modus-Umschalttaste

H Batteriespeicher

I Netzschalter

J USB-Empfänger

2.4G drahtlose Verbindung

1

2

3

4

Bluetooth-Verbindung

1

2

3

4

Windows 10 System (Maus)

4

5

6

7

8

Mac OS-System (Maus)

1

2

3

4

5

6

7

IOS-System (Maus)

6

7

8

9

10

11

Android-System (Maus)

4

5

6

7

8

Produktspezifikationen

Steuerung	Optisch
DPI der Maus	800/1200/1600 DPI
Lebensdauer des Maustastenanschlags	Mehr als 3 Millionen
Betriebsspannung	1.5 V
Gewicht	62g
Größe der Maus	108 * 63 * 39,1 mm

Spezifikationen für die 2.4G-Übertragung:

Übertragungsdistanz	10m
Arbeitsspannung	1.5 V
Arbeitsstrom	10mA
Rücklaufquote	125 Hz
Systemanforderungen	Ein verfügbarer USB-Anschluss; Windows XP, Windows 7/8/10 oder höher; Mac OS X 10.10 oder höher.

Spezifikationen für die Bluetooth-Übertragung:

Übertragungsdistanz	10m
Arbeitsspannung	1.5 V
Arbeitsstrom	15mA
Rücklaufquote	115 Hz
Systemanforderungen	Bluetooth-fähige Geräte; Windows 8/10 oder höher; Mac OS X 10.10 oder höher; Android 4.3 oder höher;

Ruhemodus

Wenn die Maus länger als 30 Minuten nicht benutzt wird, wechselt sie automatisch in den Schlafmodus. Drücken Sie eine beliebige Taste der Maus, sie wacht in 3-5 Sekunden auf und Sie können die Maus wieder verwenden.

Warme Erinnerung

1. Wenn die Maus keine ordnungsgemäße Verbindung zu Ihrem Gerät herstellen kann, können Sie eine Fehlerbehebung durchführen, indem Sie die folgenden Schritte ausführen: Schalten Sie die Maus aus, schalten Sie sie wieder ein, starten Sie die Bluetooth-Funktion Ihres Geräts neu und versuchen Sie dann, die Verbindung wiederherzustellen. Alternativ können Sie alle redundanten Bluetooth-Einträge aus der Verbindungsliste Ihres Geräts entfernen, bevor Sie eine neue Verbindung herstellen.
2. Um zu einem erfolgreich verbundenen Kanal zu wechseln, drücken Sie zunächst die Kanaltaste, warten Sie 3 Sekunden und fahren Sie dann mit Ihrem üblichen Operationen.
3. Die Maus ist mit einer Speicherfunktion ausgestattet, die beim Aus- und Wiedereinschalten des Geräts automatisch auf den zuletzt verbundenen Kanal zurückkehrt. Die Kanalanzeige leuchtet weiterhin, um die aktive Verbindung anzuzeigen.

Sicherheitswarnung

WICHTIG: Befolgen Sie diese Sicherheitshinweise, um die Gefahr von Bränden, Stromschlägen oder Verletzungen zu vermeiden.

Hitzezerwirkung: Lassen Sie das Gerät nicht in Umgebungen mit hohen Temperaturen oder direktem Sonnenlicht liegen, da dies zu einer Brandgefahr führen könnte.
Flüssigkeitsexposition: Halten Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.
Beschädigung und Auslaufen: Stellen Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.
Korrekte Entsorgung: Befolgen Sie die örtlichen Vorschriften für die Entsorgung von elektronischen Geräten und Batterien. Entsorgen Sie sich nicht mit dem Hausmüll.
Radiofrequenz-Interferenz: Dieses Gerät kann Störungen bei anderen elektronischen Geräten verursachen. Halten Sie einen Sicherheitsabstand zu empfindlichen Geräten ein.
Sicherheit für Kinder: Bewahren Sie den Artikel und seine Komponenten außerhalb der Reichweite von Kindern auf, um das Gefahr des Verschlückens oder Verschluckens von Batterien zu vermeiden. Lassen Sie Kinder das Gerät niemals unbeaufsichtigt handhaben.

VORSICHT: Die Nichtbeachtung der oben genannten Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.
Für weitere Hilfe oder Informationen wenden Sie sich bitte an unseren Kundendienst.
Email: support@seenda.com

EU KONFORMITÄTSERKLÄRUNG

Produktname:

Modell:

Normwert:

Produktionsort:

Hersteller:

E-Mail:

Address:

Europäischer Vertreter:

Position:

Unterschrift:

Datum der Unterzeichnung:

EU agenten:

Datum der Unterzeichnung:

Es liegt in unserer alleinigen Verantwortung zu erklären, dass die oben genannten Produkte der Konformität mit den CE-Marken (CE, RoHS, REACH) entsprechen.