

尺寸：90x100mm 材质：100g书纸 双面印刷 风琴折

SEENDA

User Manual

2.4G Wireless Keyboard & Mouse Combo

Model: SK38

Package Contents

1 * Wireless Keyboard
1 * Wireless Mouse
1 * USB Receiver (Inserted on the back of the keyboard)
1 * User Manual

LED Indicator for Keyboard

FN Lock Indicator

Number Lock Indicator

Power Indicator

Caps Lock Indicator

Pairing Indicator

Pairing

1. Insert AAA batteries for keyboard & mouse, and toggle switch on for both the keyboard and mouse;
2. Remove the nano usb receiver from the battery compartment of the keyboard, (1 USB Receiver for both keyboard & mouse);
3. Plug the receiver into an available USB port of your computer, and the device will be connected automatically;

Mouse

Power Switch

The Battery Hole

DPI Switch Button

Middle Scroll Wheel

Low Battery Reminder

Keyboard

Power Switch

ON OFF

USB Receiver

The Battery Hole

Multimedia Function

Key	Windows	Key	Windows
Fn +	FN lock		Light down
	Mute		Light up
	Volume Down		Favorites
	Volume Up		Toggle screen
	Previous		Search
	Play&Pause		Sharing
	Next track		Number Lock
	Browser		Wireless Epmt
	Setting		

Specifications

Working Current: ≤8mA
Working Range: Within 8m(Front); Within 7m(Back)
DPI of the Mouse: 800, 1200, 1600 dpi
Key Lifespan: 3 million strokes
Batteries: 2 AAA batteries required for both the keyboard and the mouse
Sleep Mode: Will turn to sleep mode if no operation in 10 minutes

Troubleshooting

1. Keyboard & mouse don't work properly:
Pls make sure the nano receiver is plugged into your device's USB port, if it's still unresponsive, pls pull it out and re-plug it to another USB Port on your device to check if it could work properly;

2. How to activate the keyboard and mouse if turn to sleep mode:
The keyboard and mouse will turn to sleep mode after 10 minutes of inactivity for energy saving, you are able to wake the keyboard and mouse up in 3 seconds by pressing any key on the keyboard and the left or right button on the mouse

3. For any other issues while using, you are welcome to contact us via: customer-service@seenda.com or Amazon email system for further assistance.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

Charging Safely: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.

Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.
Email: support@seenda.com

EU Declaration of Conformity

Declared Object:

Model:

Rating:

Place of Production:

Manufacturer:

E-mail:

Address:

European Representative:

2.4G Wireless Keyboard & Mouse Combo

SK38

3V=10mA

Made in China

Shenzhen Hangshi Electronic Technology Co., LTD

chen.zhao@bow.cn

Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

EC

REP

Business name: g.l.l., GmbH

Business address: Bauernvogelkoppel, 55c, 22393, Hamburg, Germany

Email: g.l.l.DE@outlook.com

UK

REP

Business name: AMANTO INTERNATIONAL TRADE LIMITED

Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 3NA

Email: AmantoUK@outlook.com

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position: Managing Director

Signature: ZHAO CHEN

Date of Sign: 2022.1.5

EU agent name: Tang Jia

Date of Sign: 2022.1.5

UK

CA

FC

CE

RoHS

SEENDA

Benutzerhandbuch

2.4G Kabellose Tastatur Maus Set

Model: SK38

Packungsinhalt

1 * kabellose Tastatur
1 * Kabellose Maus
1 * USB-Empfänger (auf der Rückseite der Tastatur eingefügt)
1 * Benutzerhandbuch

LED-Anzeige für Tastatur

FN Lock Anzeiger

Num Lock Anzeiger

Betriebsanzeiger

Feststelltaste Anzeiger

Verbindungsanzeiger

Verbindung

1. Legen Sie die AAA-Batterie ein und schalten Sie Tastatur und Maus ein;
2. Nehmen Sie den Nano-USB-Empfänger aus dem Batteriefach der Tastatur aus. (1 USB-Empfänger für Tastatur und Maus);
3. Schließen Sie den Empfänger an einen freien USB-Port Ihres Computers an, und das Gerät wird automatisch verbunden.

Maus

Stromschalter

Das Batteriefach

DPI-Umschalttaste

Scrollrad

Batteriestandsanzeiger

Tastatur

Stromschalter

ON OFF

USB-Empfänger

Das Batteriefach

Multimedia Funktion

Taste	Windows	Taste	Windows
Fn +	FN Lock		Verdunkeln
	Stumm		Aufhellen
	Lautstärke runter		Favoriten
	Lautstärke erhöhen		Bildschirm umschalten
	Bisherige		Suche
	Spielen&pausen		Teilen
	Nächster Titel		Nummer Lock
	Browser		Suche nach drahtlosen Geräten
	Einstellung		

Spezifikationen

Arbeitsstrom: ≤8mA
Arbeitsbereich: Innerhalb von 8 m (Front); Innerhalb von 7 m (Zurück)
DPI der Maus: 800, 1200, 1600 dpi
Tasten Lebensdauer: 3 Millionen Schläge
Batterien: Für die Tastatur und die Maus werden 2 AAA Batterien benötigt
Schlafmodus: Schaltet in den Schlafmodus, wenn 10 Minuten lang keine Operation erfolgt

Fehlerbehebung

1. Tastatur und Maus funktionieren nicht richtig:
Bitte stellen Sie sicher, dass der Nano-Empfänger an den USB-Port Ihres Geräts angeschlossen ist, falls er immer noch nicht reagiert, ziehen Sie ihn heraus und stecken Sie ihn erneut an einen anderen USB-Port Ihres Geräts, um zu überprüfen, ob er richtig funktioniert.

2. So aktivieren Sie die Tastatur und die Maus, wenn sie in den Energiesparmodus wechseln: Die Tastatur und die Maus schalten nach 10 Minuten Inaktivität in den Energiesparmodus. Sie können Tastatur und Maus in 3 Sekunden durch Drücken einer beliebigen Taste auf der Tastatur und der linken oder rechten Taste auf der Maus aufwärmen.

3. Für weitere Probleme während der Nutzung können Sie uns gerne kontaktieren unter: customer-service@seenda.com oder Amazon E-Mail-System für weitere Unterstützung.

Sicherheitswarnung

WICHTIG: Befolgen Sie diese Sicherheitshinweise, um die Gefahr von Bränden, Stromschlägen oder Verletzungen zu vermeiden.

Sicheres Aufladen: Verwenden Sie nur das mitgelieferte Kabel. Laden Sie das Gerät in einem gut belüfteten, trockenen Bereich und nicht in der Nähe von brennbaren Materialien auf.

Handhabung der Batterie: Versuchen Sie nicht, die Lithiumbatterie des Geräts selbst zu ersetzen. Der Batteriewechsel sollte von qualifiziertem Personal durchgeführt werden, um Gefahren zu vermeiden.

Hitzeinwirkung: Lassen Sie das Gerät nicht in Umgebungen mit hohen Temperaturen oder direktem Sonnenlicht liegen, da dies zu einer Brandgefahr führen könnte.

Flüssigkeitsexposition: Halten Sie den Artikel von Wasser und Flüssigkeiten fern. Verwenden Sie es nicht, wenn es nass ist, bis es gründlich getrocknet ist.

Beschädigung und Auslaufen: Stellen Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.

Korrekte Entsorgung: Befolgen Sie die örtlichen Vorschriften für die Entsorgung von elektronischen Geräten und Batterien. Entsorgen Sie sie nicht mit dem Hausmüll.

Radiofrequenz-Interferenz: Dieses Gerät kann Störungen bei anderen elektronischen Geräten verursachen. Halten Sie einen Sicherheitsabstand zu empfindlichen Geräten ein.

Child Safety: Bewahren Sie den Artikel und seine Komponenten außerhalb der Reichweite von Kindern auf, um die Gefahr des Verschluckens oder Verschluckens von Batterien zu vermeiden. Lassen Sie Kinder das Gerät niemals unbeaufsichtigt handhaben.

VORSICHT: Die Nichtbeachtung der oben genannten Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.

Für weitere Hilfe oder Informationen wenden Sie sich bitte an unseren Kundendienst.
Email: support@seenda.com

EU KONFORMITÄTSERKLÄRUNG

Produktname:

Model:

Neenwert:

Produktionsort:

Hersteller:

E-mail:

Adresse:

Europäisch Vertreter:

2.4G Kabellose Tastatur Maus Set

SK38

3V=10mA

Made in China

Shenzhen Hangshi Electronic Technology Co., LTD

chen.zhao@bow.cn

Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

EC

REP

Business name: g.l.l., GmbH

Business address: Bauernvogelkoppel, 55c, 22393, Hamburg, Germany

Email: g.l.l.DE@outlook.com

UK

REP

Business name: AMANTO INTERNATIONAL TRADE LIMITED

Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 3NA

Email: AmantoUK@outlook.com

Es liegt in unserer alleinigen Verantwortung zu erklären, dass die oben genannten Produkte der Richtlinie 2014/53/EU, 2011/65/EU (in der jeweils gültigen Fassung) vollständig entsprechen.

Position: Geschäftsführer

Unterschrift: ZHAO CHEN

Datum der Unterzeichnung: 2022.1.5

Name des EU-Agenten: Tang Jia

Datum der Unterzeichnung: 2022.1.5

UK

CA

FC

CE

RoHS

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.