

尺寸：105 * 148.5 mm 材质：100g书纸 工艺：骑马钉

英语

User Manual

Wireless Keyboard&Wireless Mouse

VssoPlor

Thank you very much for purchasing this keyboard and mouse combo, please read this user manual carefully to ensure your new keyboard and mouse combo functions correctly.

Package Contents

1 x Wireless Keyboard
1 x Wireless Mouse
1 x Micro-USB Charging Cable
1 x 2.4G USB Receiver
1 x User Manual

Specification of Keyboard


Define the name	Instructions
Operate system	Windows 7 and above
Battery	280mAh
Sleep time	5s after stop using keyboard
Battery life	1000 times charge and discharge
Key life	3 million strokes
Standby time	30 days
Continuous working time	35 hours of continuous use
Wake up way	Click any key
Dimensions	428.1*125.7*16.2mm
Operating distance	Within 8 meters
Low voltage	1 second 1 flash
Working current	Open the Caps lock ≤ 8mA

Specification of Mouse


Connect Method	2.4G Wireless
Dimensions	107.2*60*25.5mm
Operating Range	< 8 meters
DPI	1000. 1600. 2400
Charge time	2~3 H

Operating current	≤6mA
Sleeping current	≤0.02mA
Charging current	200mA
Wake up method	Press any keys
Battery specification	Li-Ion battery 3.7V, 280mAh
Keys Life	10 million clicks
Working temperature	-10 ~ +55 ℃
Uninterrupted Work Time	90 hours
Stand-by time	60 days

Product Layout



Charging Indicator



Mouse Battery Status Indicator

Solid red: mouse is charging.
Red indicator light goes off: mouse is fully charged
Blinking red: battery is low. Please charge the mouse

Product Indicators

- Caps Lock Indicator:** Green indicator light is on when the Caps Lock is activated.
- Keyboard battery status indicator**
When keyboard is turned on, battery status indicator lights up green for 1 second, then turns off.
 - Solid red: Keyboard is charging
 - Red indicator light goes off: Keyboard is fully charged
 - Blinking red: Battery is low. Please charge the keyboard.
- Power Switch:** Slide to the right to turn on the keyboard and slide to left to turn off.
- Micro USB port:** Charge the keyboard/mouse with the charging cable.
- Fn lock:** Blue indicator light is on when Fn Lock is activated.
- Num lock:** Green indicator light is on when Num Lock is activated.
- USB hole:** USB Receiver slot.
Open the cover and see the receiver slot.

Keys and Function

Key	Windows	Key	Windows
Fn +	FN Lock		Previous
	Play & Pause		Next Track
	Mute		Volume -
	Volume +		Browser
	Search		Email
	Favorite		Save
	Set		Print
	Calculator		Brightness Down
	Brightness Up		Lock Screen

System Requirements

Windows 7 or above , Windows with USB port (for the USB receiver).

Connection Steps

- Step 1. Set power switches of the keyboard and mouse to "On"
- Step 2. Connect the USB receiver to the computer.

Keyboard Features

- The USB nano receiver is on the bottom of the mouse.
- Plug and Play.
- Rechargeable and portable.
- Enhanced scissor keys, more sensitive and durable.
- Slim spill-resistant design with low profile keys for a comfortable typing experience.

Safety Instructions

- ⚠ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed
🔥 Danger (high risk) ⚠ Warning (Moderate risk) ⚠ Note (Poor risk)
- ✗ 1. Away from edge tool
 - ✗ 2. Away from microwave radiation source
 - ✗ 3. Do not place heavy objects on this product
 - ✗ 4. No shocking and bending
 - ⚠ 5. Away from oil, chemical, or organic solvents

This product is not fireproof or waterproof, please keep the keyboard and mouse away from fire or water. Non-professionals do not disassemble the product.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

- ⚠ Charging Safely: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.
 - ⚠ Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.
 - ⚠ Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
 - ⚠ Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.
 - ⚠ Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.
 - ⚠ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
 - ⚠ Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
 - ⚠ Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.
- CAUTION:** Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.

德语

Benutzerhandbuch

Kabellose Tastatur&kabellose Maus

VssoPlor

Vielen Dank für den Kauf dieses Tastatur und Maus Sets. Bitte lesen Sie diese Bedienungsanleitung sorgfältig durch, um sicherzustellen, dass Ihr neues Tastatur Maus Set ordnungsgemäß funktioniert.

Im Lieferumfang

1 x kabellose Tastatur
1 x kabellose Maus
1 x Micro-USB-Ladekabel
1 x 2.4G USB-Empfänger
1 x Benutzerhandbuch

Spezifikation der Tastatur


Definieren Sie den Namen	Anweisungen
Betriebssystem	Windows 7 und höher
Batterie	280 mAh
Ruhezeit	5 Sekunden nach Beendigung der Tastaturbenutzung
Batterielebensdauer	1000 Mal laden und entladen
Lebensdauer der Taste	3 Millionen Anschläge
Standby-Zeit	30 Tage
Kontinuierliche Arbeitszeit	35 Stunden Dauerbetrieb
Weckmodus	Auf eine beliebige Taste klicken
Abmessungen	428.1 * 125.7 * 16.2 mm
Betriebsreichweite	Innerhalb von 8 Metern
Niederspannung	1 Sekunde 1 Blitz
Arbeitsstrom	Öffnen Sie die Feststelltaste ≤ 8 mA

Spezifikation der Maus


Verbindungsmethode	2.4G Wireless
Abmessungen	107.2 * 60 * 25.5 mm
Betriebsreichweite	< 8 Meter
DPI	1000. 1600. 2400
Ladezeit	2~3 Stunden

Betriebsstrom	≤ 6mA
Schlafstrom	≤ 0.02 mA
Ladestrom	200mA
Weckmethode	Auf eine beliebige Taste klicken
Batteriespezifikation	Li-Ionen-Akku 3.7 V, 280 mAh
Lebensdauer der Taste	10 Millionen Klicks
Arbeitstemperatur	-10 ~ + 55 ℃
Ununterbrochene Arbeitszeit	90 Stunden
Standby-Zeit	60 Tage

Produktdatayout



Ladeanzeige



Batteriestatusanzeige der Maus

Leuchtet rot: Die Maus wird aufgeladen.

Rote Kontrollleuchte erlischt: Maus ist vollständig aufgeladen.

Rot blinkend: Batterie ist schwach, Bitte laden Sie die Maus auf.

Produktindikatoren

- Anzeige der Feststelltaste:** Die grüne Anzeileuchte leuchtet, wenn die Feststelltaste aktiviert ist.
- Batteriestatusanzeige der Tastatur**
Wenn die Tastatur eingeschaltet ist, leuchtet die Akkustatusanzeige 1s lang grün und erlischt dann.
 - Leuchtet rot: Die Tastatur wird aufgeladen
 - Rote Kontrollleuchte erlischt: Tastatur ist vollständig aufgeladen
 - Rot blinkend: Batterie ist schwach. Bitte laden Sie die Tastatur auf
- Stromschalter:** Nach rechts schieben, um die Tastatur einzuschalten, und nach links schieben, um sie auszuschalten.
- Micro-USB-Anschluss:** Laden Sie die Tastatur/Maus mit dem Ladekabel auf.
- Fn-Sperre:** Die blaue Anzeileuchte leuchtet, wenn die Fn-Sperre aktiviert ist.
- Num-Sperre:** Die grüne Anzeileuchte leuchtet, wenn die Num-Sperre aktiviert ist.
- USB-Lock:** USB-Empfängersteckplatz.
Öffnen Sie die Abdeckung und sehen Sie sich den Empfängersteckplatz an.

Tasten und Funktion

Tasten	Windows	Tasten	Windows
Fn +	FN-Sperre		Rückwärts
	Play & Pause		Vorwärts
	Stumm		Leiser
	Lauter		Browser
	Suchen		Email
	Favorit		Speichern
	Einstellen		Druck
	Kalkulator		Helligkeit Schwächen
	Helligkeit Verstärken		Sperren

System Anforderungen

Windows 7 oder höher; Windows mit USB-Anschluss (für den USB-Empfänger)

Verbindungsschritte

- Schritt 1. Stellen Sie Stromschalter von Tastatur und Maus auf „Ein“ ein.
- Schritt 2. Schließen Sie den USB-Empfänger an den Computer an.

Tastaturfunktionen

- Der USB-Nano-Empfänger befindet sich auf der Unterseite der Maus.
- Plug und Play.
- Wiederaufladbar und tragbar.
- Verbesserte Scherentasten, empfindlicher und langlebiger.
- Schlankes, spritzwassergeschütztes Design mit flachen Tasten für ein komfortables Tipperlebnis.

Sicherheitshinweise

- ⚠ Warnung: Wenn die folgenden Anweisungen nicht befolgt werden, kann es zu Bränden, Stromschlägen oder Schäden an der Tastatur kommen.
🔥 Gefahr (hohes Risiko) ⚠ Warnung (mittleres Risiko) ⚠ Hinweis (geringes Risiko)
- ✗ 1. Vom Kantenwerkzeug weg
 - ✗ 2. Von Mikrowellenstrahlungsquellen fernhalten
 - ✗ 3. Stellen Sie keine schweren Gegenstände auf dieses Produkt
 - ✗ 4. Kein Erschüttern und Verbiegen
 - ⚠ 5. Von Öl, chemischen oder organischen Lösungsmitteln fernhalten
- Dieses Produkt ist nicht feuerfest oder wasserdicht, Bitte halten Sie Tastatur und Maus von Feuer und Wasser fern. Laien dürfen das Produkt nicht zerlegen.

Sicherheitswarnung

WICHTIG: Befolgen Sie diese Sicherheitshinweise, um die Gefahr von Bränden, Stromschlägen oder Verletzungen zu vermeiden.

- ⚠ Sicheres Aufladen: Verwenden Sie nur das mitgelieferte Kabel, Laden Sie das Gerät in einem gut belüfteten, trockenen Bereich und nicht in der Nähe von brennbaren Materialien auf.
- ⚠ Handhabung der Batterie: Versuchen Sie nicht, die Lithiumbatterie des Geräts selbst zu ersetzen. Der Batteriewechsel sollte von qualifiziertem Personal durchgeführt werden, um Gefahren zu vermeiden.
- ⚠ Hitzeinwirkung: Lassen Sie das Gerät nicht in Umgebungen mit hohen Temperaturen oder direktem Sonnenlicht liegen, da dies zu einer Brandgefahr führen könnte.
- ⚠ Flüssigkeitsexposition: Halten Sie den Artikel von Wasser und Flüssigkeiten fern. Verwenden Sie es nicht, wenn es nass ist, bis es gründlich getrocknet ist.
- ⚠ Beschädigung und Auslaufen: Stellen Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.
- ⚠ Korrekte Entsorgung: Befolgen Sie die örtlichen Vorschriften für die Entsorgung von elektronischen Geräten und Batterien, Entsorgen Sie sie nicht mit dem Hausmüll.
- ⚠ Radiofrequenz-Interferenz: Dieses Gerät kann Störungen bei anderen elektronischen Geräten verursachen. Halten Sie einen Sicherheitsabstand zu empfindlichen Geräten ein.
- ⚠ Sicherheit für Kinder: Bewahren Sie den Artikel und seine Komponenten außerhalb der Reichweite von Kindern auf, um die Gefahr des Verschluckens oder Verschluckens von Batterien zu vermeiden. Lassen Sie Kinder das Gerät niemals unbeaufsichtigt handhaben.

VORSICHT: Die Nichtbeachtung der oben genannten Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.
Für weitere Hilfe oder Informationen wenden Sie sich bitte an unseren Kundendienst.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.