

英语

SEENDA

WGJP-031B

2.4G Wireless Keyboard & Mouse Combo

User Manual

Thank you very much for purchasing this keyboard and mouse combo, please read this user manual carefully to ensure your new keyboard and mouse combo functions correctly.

Package Contents

1 x Wireless Keyboard
1 x Wireless Mouse
1 x Type-C Charging Cable
1 x 2.4G USB Receiver
1 x User Manual

Specification of Keyboard

Define the name	Instructions
Operate system	Windows 7 and above
Battery	280mAh
Sleep time	5s after stop using keyboard
Battery life	1000 times charge and discharge
Key life	3 million strokes
Standby time	30 days
Continuous working time	35 hours of continuous use
Wake up way	Click any key
Dimensions	366*125*16.2 mm
Operating distance	Within 8 meters
Low voltage	1 second 1 flash
Working current	Open the Caps lock ≤ 8mA

Specification of Mouse

Connect Method	2.4G Wireless
Dimensions	59*108*23.3 mm
Operating Range	< 8 meters
DPI	1200
Charge time	2~3 H

Operating current

≤9 mA

Sleeping current

≤0.05 mA

Charging current

100 mA

Wake up method

Press any keys

Battery specification

Li-ion battery 3.7V,300mAh

Keys Life

10 million clicks

Working temperature

-10 ~ +55 °C

Uninterrupted Work Time

90 hours

Stand-by time

60 days

Product Layout

② Fn lock Indicator

③ Number lock Indicator

④ Caps Lock Indicator

⑤ Power Indicator

⑥ Power Switch

⑦ Type-C Port

⑧ Power Switch

⑨ USB Receiver

⑩ Battery status indicator

Charging Indicator

Type-C Charging Cable

Mouse Battery Status Indicator

Solid red: mouse is charging.
Red indicator light goes off: mouse is fully charged
Blinking red: battery is low. Please charge the mouse

Keyboard indicators

1. Caps Lock Indicator: Green indicator light is on when the Caps Lock is activated.

2. State Indicator: Flashes Green and enter into pairing mode.

3. Keyboard battery status indicator

When keyboard is turned on, battery status indicator lights up green for 3 second, then turns off.

•Solid red: Keyboard is charging

•Blinking Green: Battery is low. Please charge the keyboard.

4. Power Switch: Slide to the right to turn on the keyboard and slide to left to turn off.

5. Type-C USB Port : For charging the keyboard/ mouse by using the charging cable.

6. Fn lock: Blue indicator light is on when Fn Lock is activated.

7. Num lock: Green indicator light is on when Fn Lock is activated.

Connection Steps

Step 1. Set power switches of the keyboard and mouse to "On"

Step 2. Connect the USB receiver to the computer.

NOTE: If your keyboard or mouse is not working, see the Troubleshooting section.

Keyboard Features

1. The USB nano receiver is on the bottom of the mouse.

2. Plug and play.

3. Rechargeable and portable.

4. Enhanced scissor keys, more sensitive and durable.

5. Slim spill-resistant design with low profile keys for a comfortable typing experience.

Safety Instructions

△ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed

⚡ Danger (high risk) ⚡ Warning (Moderate risk) △Note (Poor risk)

✖ 1. Away from edge tool

⚡ 2. Away from microwave radiation source

✖ 3. Do not place heavy objects on this product

✖ 4. No shocking and bending

△ 5. Away from oil, chemical, or organic solvents

Troubleshooting

If you have problems with your keyboard or mouse:

• Check if the keyboard's or mouse's power switch is set to "On".

• Remove and reconnect the USB receiver on your computer.

• Connect the USB receiver into another USB port on your computer.

• Restart your computer.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

⚠ Charging Safely: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

⚠ Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

⚠ Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

⚠ Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.

⚠ Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

⚠ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

⚠ Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

⚠ Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.
Email: support@seenda.com

EU Declaration of Conformity

Declared Object:

2.4G Wireless Keyboard & Mouse Combo

Model:

WGJP-031B

Rating:

3.7V ~10mA

Input:

5V ~250mA

Place of Production:

Made in China

Manufacturer:

Shenzhen Hangshi Electronic Technology Co., LTD

Email:

chen.zhao@bow.cn

Address:

Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

European Representative:

EC REP

UK REP

Business name: g.L.L. GmbH
Business address: Bauernglockenpl. 55c, 22393, Hamburg, Germany
Email: g.L.L.DE@outlook.com

Business name: AMANTO INTERNATIONAL TRADE LIMITED
Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 2HA
Email: AmantoUK@outlook.com

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position:

Managing Director

Signature:

Date of Sign:

2022.1.5

EU agent name:

Date of Sign:

2022.1.5

德语

SEENDA

WGJP-031B

2,4 G Kabellose Tastatur & Maus Combo

Benutzerhandbuch

Vielen Dank für den Kauf dieser Tastatur- und Maus Combo. Bitte lesen Sie dieses Benutzerhandbuch sorgfältig durch, um sicherzustellen, dass Ihre neue Tastatur- und Maus Combo richtig funktioniert.

Packungsinhalt

1 x kabellose Tastatur
1 x kabellose Maus
1 x Type-C-Ladekabel
1 x 2.4G USB-Empfänger
1 x Benutzerhandbuch

Spezifikation der Tastatur

Namen	Anweisungen
Betriebssystem	Windows 7 und höher
Batterie	280 mAh
Schlafzeit	5 Sekunden nach dem Ende der Benutzung der Tastatur
Akkulaufzeit	1000 mal aufladen und entladen
Tasteleben	3 Millionen Tippen
Standby-Zeit	30 Tage
Kontinuierliche Arbeitszeit	35 Stunden Dauerbetrieb
Weckruf	Klicken Sie auf eine beliebige Taste
Abmessungen	366 * 125 * 16,2 mm
Reichweite	innerhalb von 8 Metern
Niederspannung	1 Sekunde 1 Blitz
Arbeitsstrom	Öffnen Sie die Caps locks 8 mA

Specification of Mouse

Verbindungsmethode	2.4G Wireless
Abmessungen	59 * 108 * 23,3 mm
Reichweite	<8 Meter
DPI	1200
Ladezeit	2 ~ 3 Stunden

Betriebsstrom

≤9 mA

Schlafstrom

≤0,05 mA

Ladestrom

100 mA

Weckmethode

Drücken Sie eine beliebige Taste

Batteriespezifikation

Li-Ionen-Akku 3.7 V, 300mAh

Tasteleben

10 Millionen Klicks

Arbeitstemperatur

-10 ~ +55 °C

Ununterbrochene Arbeitszeit

90 Stunden

Standby-Zeit

60 Tage

Produktlayout

② Fn lock Anzeige

③ Num lock Anzeige

④ Caps lock Anzeige

⑤ Stromanzeige

⑥ Netzschalter

⑦ Type-C-Anschluss

⑧ Netzschalter

⑨ USB-Empfänger

⑩ Batteriezustandsanzeige

Ladeanzeige

Type-C-Ladekabel

Maus Batteriestatusanzeige

Solid rot: Maus lädt.
Rote Anzeigeleuchte erlischt: Maus ist voll geladen
Blinkt rot: Batterie ist schwach. Bitte laden Sie die Maus

Tastaturanzeigen

1. Caps Lock-Anzeige: Die grüne Anzeigeleuchte leuchtet, wenn die Caps Lock aktiviert ist.

2. Statusanzeige: Blinkt grün und wechselt in den Pairing-Modus.

3. Batteriestatusanzeige der Tastatur

Wenn die Tastatur eingeschaltet ist, leuchtet die Batteriestatusanzeige 3 Sekunden lang grün und erlischt dann.

• Rot: Die Tastatur lädt sich auf

• Grüne: Tastatur ist voll aufgeladen

• Grüne blinkend: Batterie ist schwach, laden Sie die Tastatur auf

4. Netzschalter: Nach rechts schieben, um die Tastatur einzuschalten, und zum Ausschalten nach links schieben.

5. Type-C -USB-Port: Zum Laden der Tastatur / Maus mit dem Ladekabel.

6. Fn lock: Die blaue Anzeige leuchtet, wenn die Fn-Sperre aktiviert ist.

7. Num Lock: Die grüne Kontrollleuchte leuchtet, wenn Num Lock aktiviert ist.

Keys and Function

Key	Windows	Key	Windows
Fn +	Fn lock		Verdunkeln
	Stumm		Aufhellen
	Lautstärke runter	Prtsctn	Bildschirmaufnahme
	Lautstärke erhöhen	ScrLK	Scroll lock
	Letzt		Suche
	Spiel&Pause		Taschenrechner
	Nächster Titel	NumLK	Num lock

System Anforderungen

Windows 7 oder höher, Windows mit USB-Anschluss (für den USB -Empfänger).

Verbindungsschritte

Schritt 1. Stellen Sie die Netzschalter von Tastatur und Maus auf "On"

Schritt 2. Schließen Sie den USB-Empfänger an den Computer an.

HINWEIS: Wenn Ihre Tastatur oder Maus nicht funktioniert, lesen Sie die Fehlerbehebung.

Tastatureigenschaften

1. Der USB-Nano-Empfänger befindet sich an der Unterseite der Maus.

2. Plug-and-Play.

3. Wiederaufladbar und tragbar.

4. Verbesserte Scherentaste, empfindlicher und haltbar.

5. Schlankes, spritzwassergeschütztes Design mit flachen Tasten für ein komfortables Tipgefühl.

Sicherheitshinweise

△ Warnung: Wenn die folgenden Anweisungen nicht befolgt werden, kann es zu einem Brand, Stromschlag oder Schäden am Keyboard-Gerät kommen

⚡ Gefahr (hohes Risiko) ⚡ Warnung (mittleres Risiko) △Hinweis (geringes Risiko)

✖ 1. Weg vom Kantenwerkzeug

⚡ 2. Weg von der Mikrowellenstrahlungsquelle

✖ 3. Stellen Sie keine schweren Gegenstände auf dieses Produkt

✖ 4. Kein Schocken und Beugen

△ 5. entfernt von Öl, chemischen oder organischen Lösungsmitteln

Fehlerbehebung

Wenn Sie Probleme mit Ihrer Tastatur oder Maus haben:

• Überprüfen Sie, ob der Netzschalter der Tastatur oder der Maus auf "On" gestellt ist.

• Entfernen Sie den USB-Empfänger an Ihrem Computer und schließen Sie ihn erneut an.

• Schließen Sie den USB-Empfänger an einen anderen USB-Anschluss Ihres Computers an.

• Starte deinen Computer neu.

Sicherheitswarnung

WICHTIG: Befolgen Sie diese Sicherheitshinweise, um die Gefahr von Bränden, Stromschlägen oder Verletzungen zu vermeiden.

⚠ Sicheres Aufladen: Verwenden Sie nur das mitgelieferte Kabel. Laden Sie das Gerät in einem gut belüfteten, trockenen Bereich und nicht in der Nähe von brennbaren Materialien auf.

⚠ Handhabung der Batterie: Versuchen Sie nicht, die Lithiumbatterie des Geräts selbst zu ersetzen. Der Batteriewechsel sollte von qualifiziertem Personal durchgeführt werden, um Gefahren zu vermeiden.

⚠ Hitzeinwirkung: Lassen Sie das Gerät nicht in Umgebungen mit hohen Temperaturen oder direktem Sonnenlicht liegen, da dies zu einer Brandgefahr führen könnte.

⚠ Flüssigkeitsexposition: Halten Sie den Artikel von Wasser und Flüssigkeiten fern. Verwenden Sie es nicht, wenn es nass ist, bis es gründlich getrocknet ist.

⚠ Beschädigung und Auslaufen: Stellen Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.

⚠ Korrekte Entsorgung: Befolgen Sie die örtlichen Vorschriften für die Entsorgung von elektronischen Geräten und Batterien. Entsorgen Sie sie nicht mit dem Hausmüll.

⚠ Radiofrequenz-Interferenz: Dieses Gerät kann Störungen bei anderen elektronischen Geräten verursachen. Halten Sie einen Sicherheitsabstand zu empfindlichen Geräten ein.

⚠ Sicherheit für Kinder: Bewahren Sie den Artikel und seine Komponenten außerhalb der Reichweite von Kindern auf, um die Gefahr des Verschlückens oder Verschlückens von Batterien zu vermeiden. Lassen Sie Kinder das Gerät niemals unbeaufsichtigt handhaben.

VORSICHT: Die Nichtbeachtung der oben genannten Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.

Für weitere Hilfe oder Informationen wenden Sie sich bitte an unseren Kundendienst.
Email: support@seenda.com

EU KONFORMITÄTSERKLÄRUNG

Produktname:

2.4G Kabellose Tastatur & Maus Combo

Modell:

WGJP-031B

Nennwert:

3.7V ~10mA

Eingang:

5V ~250mA

Produktionsort:

Made in China

Hersteller:

Shenzhen Hangshi Electronic Technology Co., LTD

Email:

chen.zhao@bow.cn

Adresse:

Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

Europäisch Vertreter:

EC REP

UK REP

Business name: g.L.L. GmbH
Business address: Bauernglockenpl. 55c, 22393, Hamburg, Germany
Email: g.L.L.DE@outlook.com

Business name: AMANTO INTERNATIONAL TRADE LIMITED
Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 2HA
Email: AmantoUK@outlook.com

Es liegt in unserer alleinigen Verantwortung zu erklären, dass die oben genannten Produkte der Richtlinie 2014/53/EU, 2011/65/EU (in der jeweils gültigen Fassung) vollständig entsprechen.

Position:

Geschäftsführer

Unterschrift:

Datum der Unterzeichnung:

2022.1.5

Name des EU-Agenten:

Datum der Unterzeichnung:

2022.1.5

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.