


User manual

vibrō

Hidden Pleasure

www.myvibro.com



- Bluetooth vibrator with remote control (1)
- USB charging cable (1)
- User's manual (1)
- Quick user guide (1)

Product information

Product Name: Wearable Vibrator with App Control
Power Supply: USB Magnetic Suction Charging
Battery Type: Rechargeable Lithium Battery
Charging Time: About 2.5 hours
Utility Time: About 60 minutes (full power state)
Main Material: Silicone, ABS
Waterproof Grade: IPX7
Product Color: Purple/Pink
Product Size: 958535mm
Product Weight: 71.5g
Suitable Crowd: Pregnant women and people under 18 years old are not allowed to use it.
Packing Specifications: 1 loading/1 PCS

Product characteristics

Medical-grade silicone: soft, comfortable, and odorless.
Ergonomic Design: long-lasting comfort with no discomfort.
Low Noise: enjoy a quiet and gentle experience.
Precision Motor: provides powerful performance.
USB Magnetically Charged: convenient charging anytime.
Supports 9 languages and can be controlled via the app.



Charging method

1. The magnetic suction charging port at the bottom of the product is adsorbed on the charging connector.
2. Connect the USB interface of the power line to the USB charging plug with a voltage of 5V and a current of 1-2A.
3. The LED white light on the power key flickers slowly when charging.
4. The charging time is about 2.5 hours. After charging, the LED white light on the power button will be on. The product can be used for about 1 hour after being fully charged.

Announcements

1. For the first operation, it must be fully charged before use.
2. Please select and use a USB charging plug of national standard with a voltage of 5-5.5V and a current of 1-1.2A for charging.
3. Do not operate any function keys while charging. Do not touch water.
4. If the power cord is lost, please contact the manufacturer. Self-matching and purchasing are prohibited.

Operation method

1. Press the power button for 2 seconds. The breathing light flashes, indicating that it's on.
2. In the startup state, the product can be switched to different vibrating frequencies by pressing the power button. There are 9 different vibration frequencies in this product.
3. After use, press the power button for 2 seconds, and the product stops vibrating. At this time, the product has been shut down.

4. Please use warm water with bath lotion (or utensil disinfectant) to clean the product and dry it. Store it in a cool and dry place.

Common problem

Can't open or close?

Answer: Please follow the steps in the product instructions. Please recharge the product. Please check the status of the product indicator.

What to do if the product's power is weak?

Answer: If the power is not enough, please charge it.

What to do if the product cannot charge?

Answer: Please check whether the power supply is connected. Please check whether the power cord is damaged. Please check whether the power cord is connected to the product correctly. If you can't solve the problem, please call our after-sales service staff. Please do not privately dismantle it.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Made in China