





Ai Printer Manual

Switch roles, switch voices, get news, get weather, print images, alarm clock, perpetual calendar, check stocks, continuous questions, multi-language, processing, sensitive topics, print multiple copies, AI drawing, printing title commands, AI painting, print story commands, print ancient poems commands, print creative content, out of paper prompt, print composition commands.



Partial functional use cases

scene	Voice sample	Features
Print text	Print the words "XX" for me	Precision Printing
Print image	Print a photograph of Andy Lau for me	Quick drawing output
AI Painting	Draw an image of a puppy with butterfly	Quick drawing output
Print essays	Write a 200-word essay titled "Spring"	AI Generation
classical poetry	Print "Ascending the Stork Tower"	Automatic Layout
Print stories	Print the story "Snow White"	Precision Printing
Adjust volume	Set the volume to thirty per cent	Accurate Adjustment

1. Wake/Interrupt

During AI voice interaction, briefly press the power button to wake or interrupt the system. A flashing green light indicates readiness for dialogue.

2. Reset

Should the device experience automatic shutdown, failure to power off, or inability to boot during operation, connect the Type-C charging cable to perform a reset. After disconnecting the cable, power on to restore functionality.

Note: Do not operate the device while charging!

Download app

1. Android users may download the app by searching for 'Fun Print' directly within their device's app store. For international Android devices, search for 'Fun Print' on Google Play.

2. iPhone users may download the app by searching for

'Fun Print' within the App Store.


3. Scan the QR code displayed on the test page or within the instruction manual to download.



Configure Network

1. Press and hold the power button for 3 seconds to switch on. Upon hearing the prompt 'Please configure the network via the app', commence network setup. Open the app's home screen, switch devices to select AI Printer → Tap 【Set Device Network】 → Enter 【2.4G Wi-Fi name & password】 → Begin 【Configuration】 → 【Configuration successful】

(Note: 5G Wi-Fi is not currently supported)



2. Upon successful network configuration, the device will announce 【Network connection established】. Press and hold the power button to shut down and restart the unit. It will then automatically connect to the currently configured Wi-Fi network. Once connected, the device will voice prompt 【Network connection successful. Ready for conversation】. When the green indicator light flashes, you may commence AI voice interaction.

Unpair device

When different mobile phones need to connect to the same device on the same network, you may unbind the device within the app on the first connected phone. Subsequently, download and log into the app on another mobile phone to reconfigure the network connection.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.