



X7S

USER MANUAL



Scan To Learn More

Catalog

I Precautions 01

I Product Features 02-06

Apple CarPlay	02
Android Auto	02
Steering Wheel Control	02
Split Screen	02
Subwoofer	02
SIM Card	02
Front Camera	02
Backup Camera	02
OBD2	02
OTA	02
Customizable Boot Logo	02
Radio	03-04
GPS Antenna	05
4G	06

I Settings 07-11

I Specifications 12

I FAQ 13-19

Precautions

- This car stereo can only be installed in vehicles with a DC12V power system. Before installation, ensure the vehicle's power is turned off and disconnect the positive terminal of the car battery to prevent potential damage to the product or fire due to high voltage. After installation, use electrical tape to insulate all wires and prevent short circuits, which could damage the product or cause a fire.
- Please avoid using this product for extended periods after the engine is turned off, as it may drain the battery.
- Do not disassemble or modify the unit without professional expertise. For any questions about installation or usage, please consult your dealer or Eonon customer service.
- Keep the product away from liquids. If you notice water, foreign objects, unusual smells, or abnormal screen behavior, turn off the device immediately to prevent fire, electric shock, or other malfunctions. Contact your dealer or Eonon customer service for assistance.
- Do not clean the screen with a damp cloth or diluted detergent. Avoid prolonged exposure to direct sunlight when the vehicle head unit is not in use, as it may cause the screen to malfunction.
- Please use this product under the premise of complying with traffic regulations.
- We reserve the right of final explanation.

Key Features

Apple CarPlay

Android Auto

Steering Wheel Control

Backup Camera

Split Screen

Front Camera

Subwoofer


OBD2

4G SIM Card

OTA Online Upgrade

Customizable Boot Logo

Scan the QR code to see the setup steps.



Radio

System Settings->General->Radio area->(Select Radio Area)



Switch between mono and stereo channels using the icon [] :

● When the radio signal is strong, tap the icon [] to switch to the stereo channel.

● When the radio signal is weak, tap the icon [] to switch to the mono channel; the icon [**MONO**] will appear on the screen.

[] LOC/DX switch.

LOC mode: Reduces reception of distant broadcast signals and prioritizes strong signals from nearby stations. This helps minimize interference from far-off stations, improving the clarity of local broadcasts.

Radio

DX mode: Enhances reception of distant broadcast signals, allowing you to receive stations from further away.

This mode is typically used to listen to remote stations, but it may also result in more interference and noise.

[] Alternative frequency.

Click to automatically switch to another station with the same program from the current station to ensure the playback continuity when the signal is weak.


[] Prestored radio stations.

Press and hold for 2 seconds to store the current radio station in the corresponding position.

GPS Antenna

The GPS antenna can be mounted either inside or outside the vehicle, such as on the dashboard, windshield, or roof.

Note: Place the GPS antenna in an open area. If your windshield has an explosion-proof or thermal insulation film, it may weaken the GPS signal. In such cases, consider installing the GPS antenna outside the vehicle.



4G

Please verify the information according to your product model.

Network Types	E (supported bands)	U (supported bands)
GSM	GSM850/EGSM900/ PCS1900/DCS1800	/
WCDMA	B1/B2/B5/B8	B2/4/5
TDD-LTE	B38/B40/B41(2496-2690MHz)	B41(2496-2690MHz)
FDD-LTE	B1/B3/B5/B7/B8/B20/B28	B2/B4/B5/B7/B12/B13/ B14/B17/B25/B26/B66/ B71
WIFI	2.4G/5G,802.11 a/b/g/n/ac/ax ready	

Settings

System Settings-> General	Language		
	Radio Area		Used to adjust the radio area
	Navigation App Settings		Used to set the navigation key app
	Home Window Application Settings		Used to set the app on the home window
	Voice App Settings		Used to set the voice assistant app
	Voice Control Floating Button	ON/OFF	Voice Control Floating Button Switch
	Quick Control Button	ON/OFF	Quick Control Button Switch
	Sidebar Float Button	OFF/ Apps Button/ Quick Control Button	Sidebar Floating Button Switch OFF / Apps Button / Quick Control Button
	Video Out Float Button Enable	ON/OFF	Video Out Floating Button Switch 1.TYPE-C to HDMI, USB to CVBS, USB to HDMI 2.Used to set the head unit and input device to same-screen or independent-screen modes.

Settings

System Settings-> General	Video in Motion	ON/OFF	Video Playback While Driving Prohibition Switch
	Automatic Brightness Control	ON/OFF	Headlight Detection Function Switch ON: Automatically adjusts the head unit screen backlight and key light based on the car's headlight status. OFF: The head unit screen and key light are not affected by the headlights and remain at their default settings.
	Key Learning	Touch key learning/SWC key learning/ Panel key learning/CAN bus key learning	
	Multi-touch Gesture Operation	Multi-Touch Gesture Control Switch	
	Key Light Color	Used to adjust the key light color	

Settings

System Settings-> Audio	Beep	ON/OFF	
	Phone Volume	1~40	Used to adjust the volume you hear during a phone call
	Music Volume	1~40	Used to adjust the media volume
	Navigation Volume	1~40	Used to adjust the navigation volume
	Music Drop Ratio While Navigation	1~100	Used to adjust the volume ratio between navigation voice and media when both are playing. The smaller the value, the lower the media volume; the larger the value, the higher the media volume.
	Music Drop Ratio While Reverse	1~100	Used to adjust the volume ratio between reversing voice prompts and media when both are playing. The smaller the value, the lower the media volume; the larger the value, the higher the media volume.
System Settings-> Display	Brightness	1~255	Used to adjust the screen brightness
	AUX Video Format		Used to select the AUX video format

Settings

System Settings-> Display	Switch Theme	Moonlight White/Night Black/ Automatically activate day and night mode	
System Settings-> Reverse	Rear Camera & AVM Camera Video Frame Rate		Used to select the frame rate for the rear and AVM cameras. Alternatively, while in reverse gear, press and hold the display to make the selection.
	Reverse Mode		Used to select the reversing mode
	Rear Camera Parking Lines	ON/OFF	Parking Guidelines Switch Note: The parking guidelines can be adjusted in the rearview camera interface.
	Rear Camera Mirroring	ON/OFF	Rear Camera Mirroring Switch
	Rear Camera Type		Used to select the rear camera type. Alternatively, while in reverse gear, press and hold the display to make the selection.