



5.5" 2-WAY P.A. SPEAKER  
4001969


USER MANUAL



- 1. Accessories**  
The speaker include:  
1x portable speaker  
1x 3M Type C cable  
1x Manual  
1x remote control

- 2.Feature**  
Speaker Type: Battery Speaker  
Frequency response: 60Hz-18KHz Max  
Sensitivity : 86db (+-3dB)  
High frequency: 13mm Driver  
Low frequency: 5.5"  
Magnet: 10 OZ  
Voice coil: 1" KSV  
Amplifier: Class D  
Input: 5V type C

**3.Control Button**



1. Pause: Press to pause current song / Press and hold 3 S to quit TWS function
2. Short Press: Last song, long press: Vol-
3. Short Press: Next song, long press: Vol+
4. Mic: Press Mic +&-
5. ECHO: Press ECHO+&-.
6. Mode: Press to choose mode
7. Microphone input
8. USB input
9. 3.5 Aux input
10. LED mode
11. BT light: The indicator blinks when the device is not connected, when the device is connected, the indicator light is on and not blinks.
12. Power indicator light
13. DC5 V: Type C DC 5V power input
14. Power on off switch
15. Charge light: Red is charging, Green is full

TWS: Put two speakers in Bluetooth mode, long press the MODE key in one of speaker for 3 seconds to enter TWS MODE, long press the MODE key of the speaker defaults it as the master speaker, and the master speaker will broadcast the voice as RIGHT CHANNEL. LEFT CHANNEL sounds from another speaker then you can process Bluetooth connection as usual. Long press 3 S pause key to exit the TWS, there will be a "ding doing" prompt.

**4. Remote control**



1. Press to play a song or pause while playing a song.
2. In play mode press to set one equalizer mode.
3. Vol+ /Vol-
4. Previous: Press once to jump previous song,(in USB mode only) press and hold to rewind.
5. Next: Press once to jump next song, (in USB mode only ) press and hold to fast-forward.
6. Keys: Use this key to select the number of a desired track.
7. Pick song: Allows you to select the song you want to listen to so direct, for example: if you want to hear the song no.11, first press the number 11 then press this button.
8. ENTER: Choose repeat mode.
9. MODE: Select an operating modality, the options are Bluetooth and line in & USB
10. Battery compartment (CR2025)

**CAUTION:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.  
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
--Reorient or relocate the receiving antenna.  
--Increase the separation between the device and receiver.  
--Connect the device into an outlet on a circuit different from that to which the receiver is connected.  
--Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment