

B066T

全尺寸折叠蓝牙键盘

说明书

注意：正确操作本产品，请仔细阅读用户手册。

支持系统
Win10/Android

● iOS系统连接使用说明

1. 打开键盘电源开关，蓝色灯亮起。按Fn + C/Enter键进入配对状态。
2. 打开“设置”->“蓝牙”模式。
3. 直到发现“Bluetooth 5.1 Keyboard”，然后点击配对连接。
4. 显示连接成功，您现在可以使用您的设备了。

● Win 10系统连接使用说明

1. 打开键盘电源开关，蓝色灯亮起。按Fn + C/Enter键进入配对状态。
2. 打开设置，打开蓝牙，点击添加蓝牙设备。
3. 在设备列表选择“蓝牙”->进行连接。
4. 直到发现“Bluetooth 5.1 Keyboard”，然后点击配对连接。
5. 显示连接成功，您现在可以使用您的设备了。

● Android系统连接使用说明

1. 打开键盘电源开关，蓝色灯亮起。按Fn + C/Enter键进入配对状态。
2. 打开设置，然后点击“连接”。
3. 打开设置，进行配对连接。
4. 点击发现“Bluetooth 5.1 Keyboard”，然后点击。
5. 显示连接成功，您现在可以使用您的设备了。

产品功能

iOS/Android	Windows	Windows	对应英文
Esc	灯效功能	Fn +	直接按
F1	返回/前页	Esc	主类
F2	搜索	F1	搜索
F3	全选	F2	全选
F4	复制	F3	复制
F5	粘贴	F4	粘贴
F6	窗口	F5	窗口
F7	上一组	F6	上一组
F8	下一组	F7	下一组
F9	静音	F8	静音
F10	音量减小	F9	音量减小
F11	音量增大	F10	音量增大
F12	休眠	F11	休眠

三系统切换语言：

iOS：control + 空格键 切换语言
Windows：Alt + Shift 切换语言
Android：Shift + 空格键 切换语言

三系统输入法切换：

iOS：control + 空格键
Windows：control + Shift
Android：control + Shift

	单击物品 - 鼠标左键		鼠标左键/右键 - 放大/缩小
	鼠标上下/左右滚动 - 鼠标滚轮		三指向上/左按键 - 活动窗口切换
	三指点击 - 搜索		三指向上/左按键 - 活动窗口切换
	三指向上轻扫 - 打开语音搜索窗口		三指向下扫 - 返回桌面
	四指双击 - 执行Action - center		

设置-辅助功能-触控-辅助触控-设备-点击键盘对应名，然后对单指点/三指点击进行功能自定义。

触控板功能说明(Android),须切换到Android系统

 单点点击-鼠标左键

 单点双击-光标滑动

 双指上下/左右滑动-鼠标滑轮

故障分析

请与售后服务人员联系

知识产权信息

未经本公司的许可，禁止复制本用户手册的内容。

安全提醒

请不要打开或修理该设备，请不要在潮湿环境中使用设备，请用于布擦拭该设备。

质保条款

本设备自购买之日起，提供1年保修服务。

- 键充电后再使用。
2. 键盘指示灯在使用途中一直闪烁？
键盘指示灯在使用途中一直闪烁，表示电池即将没电，请尽快将键盘充电。
3. 设备显示蓝牙键盘断开连接？
蓝牙键盘在一段时间内不使用，设备为了省电将自动关闭蓝牙功能，按键盘任意键唤醒，蓝牙连接自动恢复。

购买日期: _____

若有新发现不属于以下所列原因造成的损失或损坏:

- (1) 操作事件、疏忽、操作不当或违反操作规程所致、加载或卸载不当;
- (2) 操作不当或不当、使用不当或不当产品或配件或不当使用不当配件;
- (3) 其他造成或造成本公司或供应商的损失 (如超载使用)、不当使用或不当使用造成或造成其他损失。

禁止在正常操作期间使用本产品。

警告

警告

Keyboard size: 342.35 × 114.7 × 10.9mm (open)	182.25 × 114.7 × 18.5mm (closed)
Working distance: 10 cm (no obstacles)	Touchpad size: 54.8 × 73.8 mm
Lithium battery capacity: 640 mAh	Weight: 222 g
Use working voltage: 3.7 V	Key working current: 1.2-5.0 mA
Use sleeping time: 12 min	Standby current: 1-2.5 mA
Use timeout: 10 minutes	Sleep current: 350A
Charger specifications: 5V $\frac{1}{2}$ 1A or 2A	Awaken way: Press key

Touchpad function description (Windows10), must be switched to Windows system

	Tap Tap the left of mouse button		Two-finger separation / collapse → Zoom in / out
	Two-finger slides vertically / horizontally → Mouse wheel		Three-finger slide to the left → Switch the active window
	Two-finger tap → Search		Three-finger slide to the right continuously → Active window switch
	Three-finger slides up → Open the browser window		Four-finger slide → Open the (Active + Center)
	Three-finger slides down → Go home		

Touch pad function description (iOS 13.4.1 and above), must be switched to iOS system

	Tap – Tap – Single finger		Drag – Mouse cursor – Single finger – Dragging – Dragging – Dragging
	Tap and hold – Tap and hold – Tap and hold		Two finger slide vertically and horizontally – Double – Tap and hold – Tap and hold
	Three finger slide vertically and horizontally – Tap and hold – Tap and hold		Three finger tap – Tap and hold – Tap and hold
	Three finger slide vertically – Active window containing vertical – Tap and hold – Tap and hold		Three finger slide horizontally – Active window containing horizontal – Tap and hold – Tap and hold
	Four finger slide vertically and horizontally – Tap and hold – Tap and hold		Four finger slide vertically – Active window containing vertical – Tap and hold – Tap and hold

User-defined:

Settings - Auxiliary Functions - Touch - Auxiliary Touches - Device - Click the keyboard's pairing name, and then customize the function "single finger, three-finger".

Touch pad function description (Android), must be switched to Android system

	Tap – The left of mouse button		Drag – Mouse cursor
	Two-finger slides vertically / horizontally – Mouse wheel		

1. Please turn on the keyboard power switch. When the blue light is on, press the **F10** () to select channel and the press **F12** code. The blue light flashes to enter the code receiving state.
2. Turn on Bluetooth to enter the search mode.
3. you find the "Bluetooth 5.1 Keyboard" and then click the pen name to connect.
4. There is a tip for connecting successfully, you can use your keyboard comfortably.

1. Press the **power** on the keyboard power switch. When the blue light is on, press the **F1** **F2** **F3** to select channel and the **F4** to exit. The size light feature is to enter the code matching state.
2. Turn on settings, turn on Bluetooth, and click Add Bluetooth or other devices.
3. Select "Bluetooth 2.1 Keyboard" and assign to 8.
4. You find the "Bluetooth 2.1 Keyboard" and click the pair name to connect.
5. There is a tip for connecting successfully, you can see the keyboard connectivity.

iOS/Android		Windows		Windows	
Press power	Return to home screen	F14	Corresponding function	Press power	Corresponding function
	Return to Desktop				
	Search		Search		
	Select all		Select all		
	Copy		Copy		
	Paste		Paste		
	Cut		Cut		
	Previous track		Previous track		
	Play/Pause		Play/Pause		
	Next track		Next track		
	Mute		Mute		
	Volume+		Volume+		
	Volume-		Volume-		
	Lock		Lock		

System switching language

Control: Alt+Shift switch language

Windows: Alt+Shift switch language

Control: Shift+Space switch language

These system input method switch

iOS: Control+Space switch

Windows: Control+Shift switch

Android: Control+Shift switch

Keyboard size: 342.35 × 114.7 × 10.9mm (open)	182.25 × 114.7 × 18.5mm (closed)
Working distance: 10 cm (no obstacles)	Touchpad size: 54.8 × 73.8 mm
Lithium battery capacity: 640 mAh	Weight: 222 g
Use working voltage: 3.7 V	Key working current: 1.2-5.0 mA
Use sleeping time: 12 min	Standby current: 1-2.5 mA
Use timeout: 10 minutes	Sleep current: 350A
Charger specifications: 5V $\frac{1}{2}$ 1A or 2A	Awaken way: Press key

Touchpad function description (Windows10), must be switched to Windows system

	Tap Tap the left of mouse button		Two-finger separation / collapse → Zoom in / out
	Two-finger slides vertically / horizontally → Mouse wheel		Three-finger slide to the left → Switch the active window
	Two-finger tap → Search		Three-finger slide to the right continuously → Active window switch
	Three-finger slides up → Open the browser window		Four-finger slide → Open the (Active + Center)
	Three-finger slides down → Go home		

	Two-finger pinch (Pinch-to-zoom)		Drag — Mouse cursor		Long Press (Long-press to open context menu)
	Tap gesture (Tap-to-zoom)		Two-finger slides — Mouse wheel		Two-finger drag (Two-finger drag to scroll horizontally and vertically)
	Three-finger slides (Three-finger slide to scroll horizontally and vertically)		Three-finger drag (Three-finger drag to scroll horizontally and vertically)		Four-finger drag (Four-finger drag to scroll horizontally and vertically)
	User-defined: (User-defined)		Two-finger slides (Two-finger slides to scroll horizontally)		Two-finger drag (Two-finger drag to scroll horizontally and vertically)

User-defined:

Settings - Auxiliary Functions - Touch - Auxiliary Touches - Device - Click the keyboard's pairing name, and then customize the function "single finger, Three-finger".

Touch pad function description (Android), must be switched to Android system

	Tap — The left of mouse button		Drag — Mouse cursor
	Two-finger slides vertically / horizontally — Mouse wheel		

- Connect: Open the power switch, blue lights up, press the connect button, blue light flashes.
- Charging: Indicator light will be on red, after fully charging, the light crush out.
- Low Voltage Indicator: When the voltage is below 3.3 V, red light flashes.

Multi-channel connection

- When connecting the first device, first press the Fn + F1 select channel and then press Fn + C to start the connection.
- Before connecting the second device, press the Fn + F2 select channel and then press Fn + C to start the connection.
- Before connecting the third device, press the Fn + F3 select channel and then press Fn + C to start the connection.

To use multiple devices at the same time, press Fn + $\text{F1} / \text{F2} / \text{F3} / \text{F4}$ to switch to the connected devices freely .

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this manual without the permission of seller.

Safety instructions

Do not open or repair this device. Do not use the device in a damp environment. Clean the device with a dry cloth.

The device is provided with one-year limited hardware warranty from the purchase date.

Keyboard Maintenance

1. Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet or soaked.
2. Please don't expose the keyboard at too high or too low temperature condition.
3. Please don't put keyboard under sun for a long time.
4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.

5. Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

FAQ

1. The tablet PC can't connect the BT keyboard?
2. At first check the BT keyboard is into match code state, then open the tablet PC Bluetooth searching.
3. Check the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need to charge.
4. The keyboard indication light always flashing when use?

Keyboard indication always flashing when use, is means the keyboard is low power, please charge the power as soon as possible.

The tablet PC display BT keyboard is disconnected?

The Bluetooth keyboard is not used for a period of time, the device will enter the sleep state in order to save power. Warranty from the time you opened the keyboard to wake up, and the Bluetooth connection will be automatically restored.

portable exposure condition without restriction. Declaration of compliance with the European Union (EU) EMC Directive 2014/53/EU (the EMC Directive) is required for the equipment to be placed on the market in the EU. The EMC Directive (2014/53/EU) is implemented with Directives 2014/53/UE and 2011/65/UE. The full text of the EU declaration of conformity is available at the following internet address: <https://www.dgnc.com>

FCM Warning

This device complies with part 15 of the FCC Rules. Operation is guaranteed without interference if certain conditions are met, including: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. These conditions are intended to ensure that the user is responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the following requirements: Part 15 of the FCC Rules, Section 15.21, Class B digital devices. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment has been tested and found to comply with the following requirements: Part 15 of the FCC Rules, Section 15.21, Class B digital devices. This equipment must be installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been designed to meet general FCC exposure limits for the device. The device complies with portable exposure condition without restriction.

Warranty Card

User information

Company or personage full name _____

Contact address _____

TEL _____ Zip _____

The purchased product name and model NO. _____

Purchased date _____

This return card is for product broken and damage to be include on the warranty.
Therefore, please attach return product in good condition and fill in the following information.

(1) Customer name and telephone number (2) Product model number and serial number
(3) Customer address and delivery date (4) Date of purchase and place of purchase

(5) Do not use consumable items like spare batteries, that are not provided by the company. The applicable laws, please refer to the instruction manual provided.

WARRANTY CARD

DATE OF PURCHASE

DATE OF RETURN

PRODUCT MODEL

SERIAL NUMBER

NAME OF CUSTOMER

PHONE NUMBER

ADDRESS