


65mm

Nobis




NOBIS CLIP N1
Wireless Speaker
User Manual
Model No. : N6301


Catalog

English	2
Français	9
Deutsch	15
Español	21
日本語	27
Italiano	33

Packing List



At a Glance




Note: The rubber flap needs to be closed to keep the speaker water resistant.


Specifications

- Output power-----5W RMS
 - Frequency response-----90Hz-20KHz
 - Signal-to-noise ratio----->90dB
 - Battery-----Lithium-ion 6.66Wh
 - Battery charge time-----3.5 hours(5V/1A)
 - Music playtime-----up to 24 hours(varies by volume level and audio content)
 - Bluetooth version-----5.3
 - IP Rating-----IP68
 - Dimensions(WxHxD)-----80.4x52.5x138mm
 - Weight-----250.7g
- Specifications are subject to change without notice.


Using Your Wireless Speaker



1. Charging




2. Powering On/Off




- Press and hold down the power button for 1 second to power on.
 - Press and hold down the Power button for 1 second to power off.
- The speaker will power off automatically 20 minutes after no audio input or button inactivity.


3. Pairing




4. Controls



5. Beat Function




6. Stereo Link Function



7. Clear the speaker pairing list



8. Factory Reset




9. Forced Reset




10. IP68 Waterproof and Dustproof



Safety and Precautions



FCC Statement



Customer Service

