

USER MANUAL

SPEAKER



Operation Instructions

- **Power on/off:** Press and hold the power button for 3 seconds.



- **Select lights/Turn off:** Short press to select lights or turn off lights.
- **Call back:** Double click call back.

- **Play/Pause:** Press the button briefly.

- **Next song:** Double-click the button.

- **Previous song:** Triple-click the button.



- **Mode switch:** Press and hold for 2 seconds to switch the BT/MicroSD/FM/AUX mode in sequence.
- **Answer or hang up:** Press the button briefly.



- **Volume +:** Long Press /Short Press the button.
- **TWS connection/disconnection:** Double-click the button.



- **Volume -:** Long Press /Short Press the button.
- **TWS connection/disconnection:** Double-click the button.

External connection

MicroSD card Slot: Insert MicroSD card (MP3, WAV audio only).

Type-C port (DC-5V/2A): Charging.

Connect the USB cable to the PC/ power bank/adaptor to obtain power. When the indicator light shows red, it indicates that charging is in progress. The light going out indicates that it is full.

Audio Input Interface: Insert a 3.5mm audio cable and connect an external audio source input.

Instructions for Use

Power On/Off

Power On: Press and hold the power button for 3 seconds.

Power Off: Press and hold the power button for 3 seconds.

FM

Plug the power cable into the Type-C port to use it as an external FM antenna.

* In FM mode, briefly press the ▷ button to search for channels.

* Double-click ▷ button to go to the next channel.

* Triple-click ▷ button to go to the previous channel.

Mobile phone BT mode

Set the speaker to BT mode, turn on the BT function of the mobile phone, click Search Device for the first connection, then find WP-05B(host model name) in the available devices and pair and connect. When you hear that BT is connected, the mobile phone and the host BT are successfully paired, and you can use the mobile phone to play music.

Note: Before wireless connection, the blue light blinks, and once paired, it will automatically connect when used again.

TWS settings

1. Turn on two speakers of the same model and do not connect them to your phone for the time being.

2. Double click the "+" or "-" button on one of the speakers and release it when you hear the "du du" sound. After 3-4 seconds, you will hear a "ding ding" prompt sound, indicating a successful TWS connection. Connect your phone BT to the "WP-05B" device. Two speakers will play music synchronously to achieve a surround sound effect.
3. In TWS connection mode, the left and right channel devices can synchronize operations: play/pause, next song/previous song, volume up/ volume down, etc.
4. When restarting, the TWS will reconnect automatically.
5. TWS disconnection: Double click the "+" or "-" button, and when you hear a "din" sound, it will disconnect.
6. When the main speaker is turned off, the secondary speaker will also be turned off at the same time. To restart, you need to turn on both speakers separately.

Product parameters

Model	WP-05B
BT	BT5.3
Micro SD card	Support MP3, WAV
TWS	Support
BT receiving distance	Straight line accessibility ≥ 10 meters
Charging Voltage	DC 5V/2A
Battery life	Up to 10 hours(affected by volume and playback content)
Charging time	About 3 hours
Battery Capacity	4000mAh
Output Power	20W
Channel system	Stereo
Frequency	20Hz-20KHz
AUX	Audio input
Waterproof performance	IPX5

Warnings and precautions when using the product

- Do not use corrosive cleaning agents to clean the product.
- Do not allow this product to be heated or close to fire.
- Do not allow this product to be exposed to direct sunlight for a long time.
- Do not dispose of this product in the fire to avoid explosion.
- Do not attempt to remove this product for any modification.
- If you do not use this product for a long time, please store it in a dry environment, and charge the speaker at least once every 2 months to extend the life and avoid extreme temperature and dust.

Note:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.