

Sunrise Alarm Clock

User Manual



After-sales Email: support@luckyiris.com

Thank you for choosing our product.
Please read the user manual carefully before using the device.

Scan the QR code to jump to our youtube channel and get video tutorials.



Contents

1. Functional Buttons	1
2. Function introduction	2
3. Product Power On/Off	3
4. Remote Control Functions	4
5. Function Setting	5
I. Time Setting (Automatic/Manual)	5
1.1 Automatic Setup	5
1.2 Manual Setup	5
II. Time Display Brightness Adjustment	7
III. Alarm Grouping	8
IV. Alarm Setting	9
V. One Touch Alarm On/Off	11
VI. Snooze and Alarm Stop	12
VII. Lighting Function	13
VIII. Music Function	14
IX. Timer Function sleep	15
6. Parameters	16
7. Instructions	17


Functional Layout



Function Description


- 1. Lighting Control Button**
 - Single click to turn On/Off the light.
 - Double click to switch the light color.
 - Long-press to adjust light brightness.
- 2. Sleep Timer With Memory Function**
 - (Setting the sleep timer to turn off music and lights)
 - Click the button to set the sleep timer duration (5 minutes/15 minutes/20 minutes/40 minutes/90 minutes)
 - Long-press to cancel the Sleep timer setting
- 3. Music Play/Alarm Stop Button**
 - When the device is powered on and the alarm is not activated:
 - Single click to play/pause music.
 - Long-press for 2S to switch Bluetooth mode and local mode.
 - When the alarm is activated:
 - Single click to cancel the current alarm.
- 4. Track Switching/Volume Adjustment Button**
 - When playing music, click to switch tracks/long press to adjust the music volume.
- 5. Power On/Off Switch**

Product Power On/Off



- Product Power On/Off**
- Properly connect the provided power cable to the product and plug the other end into an AC 110V power outlet.
 - After powering on, slide the switch to the "ON" position. The display will light up to indicate the device is powered on.

Remote Control Functions



Function Setting

I. Time Setting (Automatic/Manual)

1.1 Automatic Setup

Long-press " " on the device/

long-press " " on the remote control

- turn on Bluetooth and connect to your phone
 - select "Allow" to permit the Bluetooth device to access your information.
- (Once connected, the device time will automatically adjust.)

1.2 Manual Setup

(All operations below are performed when the device is powered on.)


Step 1:
Single click " " on the remote control to enter the settings
the "Hour" digit in the display area of the device will start flashing
use the " " and " " on the remote to adjust the hour



Function Setting

Step 2:

Single click " " on the remote control to confirm and proceed to the next level
the "Minute" digit in the display area of the device will start flashing
use the " " and " " on the remote to adjust the Minute



Step 3:

Single click " " on the remote control to confirm and proceed to the next level
the "12H" digit in the display area of the device will start flashing
use the " " and " " on the remote to select 12H or 24H



Step 4:

Single click " " on the remote control to confirm and proceed to the next level
the "MOT" digit in the display area of the device will start flashing
use the " " and " " on the remote to select the day of the week
press " " again to confirm once the setting is complete
settings are finalized



Note: In the above steps, if there is no operation within 5s, the system will automatically confirm and return to the normal display state.

Function Setting

II. Time Display Brightness Adjustment

When the device is powered on:

- Single click " " to increase display brightness.
 - Single click " " to decrease display brightness.
- (The default setting is maximum brightness)

Brightness levels:




Function Setting

III. Alarm Grouping

This product has two sets of alarm clocks, and you can set different alarm clocks according to your needs.

For example, you can designate Alarm 1 as a weekday alarm and Alarm 2 as a weekend alarm. The usage and settings for both alarm groups are identical. This manual uses Alarm 1 as an example for explanation.



Function Setting

IV. Alarm Setting

(All operations below are performed when the device is powered on.)

Step 1:
Single click " " on the remote control to enter the settings
the " " or " " digit in the display area of the device will start flashing
use the " " and " " buttons on the remote to adjust the hour.



Step 2:

Single click " " on the remote control to confirm
the "Minute" digit in the display area of the device will start flashing
use the " " and " " buttons on the remote to adjust the hour.



Step 3:

Single click " " on the remote control to confirm
the "Week" icon in the display area of the device will start flashing
use the " " and " " buttons on the remote to select "Monday to Friday", "Saturday and Sunday", "Monday to Sunday".



Function Setting

Step 4:
Single click " " on the remote control to confirm
the "Sound" digit in the display area of the device will start flashing
use the " " and " " buttons on the remote to adjust the sound effect (S-00 to S-34)
(Note: S-00 is silent, and S-01 to S-34 can be set as alarm ring tones.)



Step 5:
Single click " " on the remote control to confirm
the "Minute" digit in the display area of the device will start flashing
use the " " and " " on the remote to adjust the pre-lighting time (range: 10 to 60 min)
single click Button " " on the remote control again to confirm
" " will show the lit status - Alarm setting completed.



Function Setting

V. One-touch On/Off Alarm



Here we take Alarm 1 as an example. The operations of Alarm 1 and Alarm 2 are the same.

Long-press " " on the remote control activate Alarm 1
the " " icon in the display area of the device turns on
Alarm 1 is successfully activated.
Long-press " " on the remote control to deactivate Alarm 1
the " " icon off
Alarm 1 is successfully deactivated.

Function Setting

VI. Snooze and Alarm Stop

After the alarm is activated, the wake-up light will gradually light up according to the set "pre-light time" to simulate sunrise.
Tip: When the alarm time is reached, the alarm will sound. During the alarm, you can turn on the snooze function to exit the current alarm, but the light and music functions cannot be operated.

1. Snooze

When the alarm goes off, tap the device to enter snooze mode. The ringing sound will be turned off and the light will gradually brighten again. The ringing sound will sound again after 10 minutes. (Up to 5 snooze times)



2. Alarm Stop

When the alarm light is on/the alarm is ringing
press " " on the device to stop the alarm.

Tip: If no operation is performed within 30 minutes, the current alarm will be terminated.

Function Setting

VII. Lighting Function



1. Turn On/Off the Light

When the device is powered on, single click " " on the device or " " on the remote control to turn on the light/turn off the light.

2. Switch Color

When the light is on, double click " " on the device or single click " " on the remote control to switch lighting colors.

3. Brightness Adjustment

When the light is on, single click or long-press " " and " " on the remote control to adjust the brightness.
Long-press " " on the device to adjust the brightness (the display shows L1 to L20).

Function Setting

VIII. Music Function



1. Music Playback/Stop/Switching

Play/Stop Music: When the device is powered on, Single click " " on the device or " " on the remote control to play or stop music.
Switch Track: Single click " " / " " on the remote control or " " / " " on the device to select the previous or next track.

2. Music Volume Adjustment

When the device is powered on, single click or long-press " " / " " on the remote control, or long-press " " / " " on the device to increase or decrease the volume.

3. Bluetooth Speaker Mode Connection


When the device is powered on, long-press " " on the device for 2 seconds to switch between Bluetooth speaker mode and local mode.

(Note: The music play/stop/switch/volume adjustment operations in Bluetooth mode are the same as those in local mode.)

Function Setting

IX. Timer Function sleep

Setting the sleep timer to turn off music and lights



1. Sleep Timer Setting

When the light or music is on, single click " " on the device to set the sleep timer duration (5 minutes/15 minutes/20 minutes/40 minutes/90 minutes).
Long-press to turn off the memory function.

2. Remote Control Sleep Timer Setting

When the light or music is on, single click " " on the remote control to start the timer - the " " icon on the device display area starts flashing - click " " and " " on the remote control to select the timer duration (six levels: 5 min/15 min/20 min/40 min/90 min) - Timer setting completed.
click " " again to turn off the timer.

Note:
When the timer starts, the " " icon on the device display area lights up; when the timer ends, the icon goes out.
If both the lights and music are on, they will both turn off at the same time when the timer ends.
One minute before the timer ends, the " " icon flashes, the light gradually dims, and the sound gradually fades away.

Parameters

Product Name	Sleep Sound Machine
Product Model	YMX-1022
Timer Duration	5MIN/15MIN/20MIN/40MIN/90MIN
Light Brightness	20 levels
Color Light Mode	15 groups
Volume Level	16 levels
Display Brightness	4 levels
Number of Alarms	2
Alarm Sound Effect	10-60MIN/10-minute interval)
Sensitive Simulation Duration	10-60MIN/10-minute interval)
Alarm Mode	Light & Sound, Light Only
Alarm Duration	30 MIN
Snooze Time	10MIN
Snooze Count	Five times
Sound Effect	
Product Material	Light-shielding ABS+PC material
Operating Temperature	0°C-40°C(32°F-104°F)
Input Voltage	5V/2A

Instructions

1. Precautions

- Place the product on a stable horizontal surface and non-slip surface.
- The stand of this product is a vulnerable component; please install and disassemble it carefully.
- Do not use the product in rooms where the temperature is below 0°C or above 40°C.
- Do not use this product to reduce your sleep. It is mainly designed to help you wake up more easily without reducing your need for sleep.
- This appliance is for household use only, including in hotels.

2. Device Storage

- Wipe the product with a soft cloth.
- Do not use abrasive cleaners, scouring pads, or solvents such as alcohol and acetone, as they may damage the product's surface.
- Store the product in a safe, dry place free from crushing, bumping, or damage.
- When storing the product, do not wrap the power cord around the appliance.

Warranty & Customer Support

If you need any assistance, please contact our support team at the address below with your Amazon order number.

After-sales Email: support@luckyiris.com

RFI Codes:

The design complies with part 3 of the RFI Code. Operator is subject to the following two conditions: (1) that device may not cause harmful interference, and (2) that device must accept any interference received, including interference that may cause restricted operation.

Any changes or modifications are subject to approval by the party responsible for compliance with the user's liability to operate the equipment.

RFI 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. There are no frequency restrictions with regard to the operation of this equipment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Move the equipment away from power lines or wiring.

— Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC and CE Emissions guidelines. This equipment should be installed and operated with minimum distance between them: do not place your body. Use only the supplied antenna.