



TOY SERIES MANNUAL

Please charge the product when you receive it to ensure that the product has enough power to use! If the walkie talkie is low in power, there may be no way to call. If the walkie talkie is not successfully called, it needs to be charged.



This product has a built-in lithium battery, please keep away from fire and water, do not place in wet places. Do not clean directly with water, just clean the dirty area with a wet rag.



Intercom mode: After the Toy is turned on, the indicator on the watch lights up, indicating that it is in the intercom state. If there is no need to talk, please turn off the Walkie-talkie switch. You can save watch power.

Steps to use the intercom function: 1. Push up the two Walkie-talkie switches to turn on
2. Press and hold the PPT button 1 to speak

Note: 1. When one walkie talkie presses and speaks, the other one cannot press the PPT key, otherwise the other one cannot be heard.

2. Press the PPT key twice quickly, the other walkie talkie's watch will ring

3. The communication distance in the open area is greater than 200M. When there are many obstacles, the communication distance is about 100M.

4. When using a strong radio signal nearby, it may be affected by interference and affect the call quality

Display function description:



Display screen: time display

Middle two keys function:

Left key(A): setting

Right key(B): 1.Press once to display the date

2.Press twice to display the seconds;

3.Press three times to return to display the time

1.Set up the time: display the time, press the left button to set, then use the right button to set up the hour/minute, finish the setting by pressing the left button to complete the setting

2.Set up the date: display the date, press the left button to set, then press the right button to set up the month/day, press the left button to complete the setting

3.Set up the seconds: display the seconds, press the left button to return to zero to re-reading the seconds.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.